

VOLVO
for life



VOLVO
WIRING DIAGRAM V70/V70R/XC70/XC90

TP 3989202

2006

Vehicles with SRS (Airbag)/SIPS bag/ IC (Inflatable Curtain)

Warning!

Extra caution must be exercised when working on vehicles equipped with SRS/SIPS bag/IC in order to avoid:

1. Personal injuries when performing repair work.
2. Damage or malfunction of the SRS/SIPS bag/IC system.

Work involving the SRS/SIPS bag/IC systems or other components in the vehicle that may affect the SRS/SIPS bag/IC systems must always be performed by an authorized Volvo workshop.

In case of doubt, consult the SRS and SIPS bag/IC service manual.

Is the vehicle equipped with SRS/SIPS bag/IC?

Vehicles with SRS are most easily recognized by the letters SRS in the center of the steering wheel. If the vehicle also has a passenger side airbag, the letters SRS are stamped on the dashboard above the glove compartment. SRS vehicles from 1993 and onward also have explosive seat belt tensioners. SIPS bags are only installed on SRS vehicles from 1995 and onward. SIPS bag decals are located on the windshield and seat compartment. Vehicles with IC can be recognized by the letters IC on the C/D panel (4 door) or the B panel (5 door).

General recommendations

- Be especially careful when working on or around SRS, SIPS, and IC components.
- Make sure that no wires are pinched, frayed, or pierced.
- Never install accessories by the sensors.
- Where applicable, work on the steering wheel, steering shaft, or steering gear must be done in accordance with the methods in the SRS section of VIDA.
- Certain components of the aforementioned systems must be grounded while working. Read the appropriate sections in VIDA.
- Install no accessories in the areas between the A and B pillars, the B and C pillars, and the C and D pillars.

Test terminal

Data link connector in the passenger compartment.

Changes introduced up to June 2005

Any changes made to the vehicles after this date are not included in the manual. If necessary refer to service bulletins.

Volvo models are sold in versions adapted for different markets. These adaptations depend on factors such as legal requirements, taxation, and market demands.

This manual may therefore include illustrations and text that do not apply to the vehicles in your country.

Order number TP 3989202

Replaces previous publication 3989201 of Electronic Wiring Diagram (EWD) TP 3991001
Also available at Electronic Wiring Diagram (EWD) TP 3991002

We reserve the right to make modifications.

Table of Contents 1:3

Vehicles with SRS (Airbag)/SIPS bag/IC (Inflatable Curtain).....	2
Abbreviations.....	7
How to use the wiring diagrams 1:2.....	8
Electrical distribution, V70 1:2	10
Electrical distribution, XC90 1:2.....	12
Fuses	
Engine compartment 11A/1-5.....	14
Engine compartment 11B/1-11.....	15
Engine compartment 11B/12-14.....	16
Engine compartment 11B/15.....	17
Engine compartment 11B/16-20.....	18
Passenger compartment 11C/1-4.....	19
Passenger compartment 11C/5-7.....	20
Passenger compartment 11C/8-11.....	21
Passenger compartment 11C/12-14.....	22
Cargo compartment 11E/1-7	23
Cargo compartment 11F/1-2.....	24
Central Electronic Module (CEM) F1-F14.....	25
Central Electronic Module (CEM) F15-F34.....	26
Rear Electronic Module (REM) F1-F7	27
Rear Electronic Module (REM) F8-F28	28
Rear Electronic Module (REM) F29-F38	29
Relays	
Ignition switch and relays.....	30
Engine compartment FMA1 - FST3	31
Other relays	32
Ground connections	
Overview.....	33
31/1 - 31/44	34
31/46 - 31/67	35
31/70 - 31/73	36
31/83 - 31/84	37
31/88 - 31/91	38
31/93 - 31/94	39
31/95 - 31/100	40
31/102 - 31/120	41
Control modules	
Overview positions V70	42
Overview designations V70	43
Overview positions XC90.....	44
Overview designations XC90	45
Central Electronic Module (CEM) 1:2	46
Rear Electronic Module (REM) 1:2	48
Data communication high speed CAN V70.....	50
Data communication high speed CAN XC90	51
Data communication low speed CAN V70	52
Data communication low speed CAN XC90	53
Data communication, LIN 1:2.....	54
Data communication MOST, XC90.....	56
Group 23 Fuel system	
Engine management system, I5D 1:3.....	57
Engine management system, 5-cyl. 1:2.....	60
Engine management system, 5-cyl. Turbo 1:2	62
Engine management system, 6-cyl. 1:2.....	64
Engine management system, Bi-fuel 1:2	66
Engine management system, diesel 1:2	68
Engine management system, 8-cyl. 1:2.....	70
Emission control, 5-cyl.....	72
Emission control, 5-cyl. turbo & 6-cyl.....	73
Emission control, 8-cyl. XC90	74
Group 26 Cooling system	
Cooling fan.....	75
Cooling fan, I5D & 8-cyl.....	76
Group 27 Engine control	
Cruise control	77
Cruise control, I5D & 8-cyl	78
Group 32 Alternator and voltage regulator	
Power supply	79
Group 33 Starting system	
Starting system	80

Table of Contents 2:3

Group 35 Lighting

High and low beams/Bi-Xenon & Daytime running lights V70	81
High and low beams/Bi-Xenon & Daytime running lights XC90	82
Fog lights	83
Brake lights	84
Reversing lights	85
Follow-me-home lighting	86
Running/parking lights, tail lights & license plate lighting V70	87
Running/parking lights, tail lights & license plate lighting XC90	88
Interior lighting V70	89
Interior lighting XC90	90
Beam length adjustment V70	91
Beam length adjustment XC90	92
Auxiliary lights	93

Group 36 Additional electrical equipment

Rain sensor	94
Direction indicators and flashing hazard lights V70	95
Direction indicators and hazard warning flashers XC90	96
Wiper/washer, windshield	97
Wiper/Washer Headlights V70	98
High pressure headlight washer	99
Wiper/washer, rear window	100
Horn	101
Electronic immobilizer	102
Anti-theft alarm V70	103
Anti-theft alarm XC90	104
Parking assistance	105
Accessory Electronic Module (AEM) 1:2	106

Group 37 Wiring and fuses

Diagnostics system	108
12V outlet	109
Tow hitch cable harness, 4-pin	110
Tow hitch cable harness, 4/7-pin	111
Tow hitch cable harness, 7-pin	112
Tow hitch cable harness, 13-pin	113

Group 38 Instruments

Seat belt reminder	114
Driver information module	115

Driver information module, Bi-Fuel	116
Driver information module, I5D	117
Driver information module, 8-cyl.	118

Group 39 Other

Audio V70	119
Audio with auxiliary amplifier V70 1:2	120
Audio XC90	122
Road Traffic Information module (RTI) V70	123
Turn-by-Turn, navigation system V70	124
Road Traffic Information module (RTI) XC90	125
Handsfree V70	126
Handsfree XC90	127
Handsfree MAX V70	128
Handsfree MAX XC90	129
CD-Changer V70	130
RTI & CD changer V70	131
MP3 player, V70	132
CD/MD player XC90	133
Cellular phone V70	134
Subwoofer V70	135
Subwoofer XC90	136
Infotainment XC90	137
Satellite radio V70	138
Rear Seat Entertainment XC90	139
Rear Seat Entertainment XC90 1:2	140

Group 43 Transmission

Automatic transmission	
AW55-50/51SN/AW50/51AWD	142
Automatic transmission 4T65AWD XC90	143
Automatic transmission TF-80SC AWD	144
Automatic transmission	
TF-80SC / TF-80SC AWD, I5D	145
Geartronic	146
Shift lock	147
Differential Electronic Module (DEM)	148

Group 59 Brake system

Brake control system	149
----------------------------	-----

Group 64 Steering

Electronic power steering	150
---------------------------------	-----

Group 76 Shock absorbers

Four-C V70	151
------------------	-----

Table of Contents 3:3

Group 83 Doors and openings	
Central locking system V70	152
Central locking system XC90.....	153
Power windows.....	154
Power sunroof.....	155
Group 84 Exterior decorative elements, etc.	
Power exterior rearview mirrors.....	156
Heated exterior rearview mirrors with camera function.....	157
Heated exterior rearview mirrors	158
Heated rear window.....	159
Group 85 Interior equipment	
Power driver's seat	160
Power passenger seat.....	161
Heated seats.....	162
Group 87 Climate control system	
Rear climate control system XC90	163
Climate control system 1:2	164
Climate control system, I5D & 8-cyl. 1:2.....	166
Parking heater, auxiliary heater	168
Relay, electric engine heater	169
Remote parking heater start V70.....	170
Parking heater call start V70.....	171
Auxiliary heater V70.....	172
Group 88 Internal equipment	
Remote garage door opener.....	173
Supplemental Restraint System module (SRS) V70	174
Supplemental Restraint System module (SRS) XC90	175
Connectors.....	176
Branching points	205
Cable harness routine in vehicle	
Engine harness, gasoline	218
Engine harness, diesel	219
Engine harness, I5D	220
Engine compartment harness LHD, V70	221
Engine compartment harness RHD, V70.....	222
Engine compartment harness LHD, XC90.....	223
Engine compartment harness RHD, XC90	224
Passenger compartment harness LHD, V70	225
Passenger compartment harness RHD, V70.....	226
Passenger compartment harness LHD, XC90.....	227
Passenger compartment harness RHD, XC90	228
Cargo compartment harness V70	229
Cargo compartment harness XC90	230
Roof harness & Inflatable curtain harness V70.....	231
Tailgate harness V70	231
Roof harness XC90	232
Tailgate harness XC90	232
Door harness V70	233
Door harness XC90	234
Bi-Fuel harnesses V70.....	235
Rear seat entertainment XC90	236
Component illustrations	237
Index 1:2.....	317
List of components 1:9	

Explanations

Abbreviations

Groups

Group 23	= Fuel system
Group 26	= Cooling system
Group 27	= Engine controls
Group 32	= Alternator and voltage regulator
Group 33	= Starting system
Group 35	= Lighting
Group 36	= Additional electrical equipment
Group 37	= Wiring and fuses
Group 38	= Instruments
Group 39	= Other
Group 43	= Transmission
Group 59	= Brake system
Group 64	= Steering
Group 76	= Shock absorbers
Group 83	= Doors and openings
Group 84	= Exterior decorative elements, etc.
Group 85	= Interior equipment
Group 87	= Climate control system
Group 88	= Internal equipment

Ignition switch symbols

X	= Accessories (audio position)
S	= Powered upon insertion of key
15	= Contact remains connected during start
15I	= Contact is broken while starting
30	= Constant power from the battery
50	= Start

Countries/Markets

A	= Austria
AUS	= Australia
B	= Belgium
CDN	= Canada
CH	= Switzerland
D	= Germany
DK	= Denmark
E	= Spain
EU/OS	= Markets outside USA and Canada
FIN	= Finland
GB	= Great Britain
ISR	= Israel
J	= Japan
KOR	= Korea
N	= Norway
NL	= Netherlands
S	= Sweden
USA	= United States of America
WEU	= Western Europe

Other

ACC	= Accessory
AMP	= Amplifier
AUDIO	= Audio system
AUTO	= Automatic transmission
Bi-X	= Bi-Xenon
BLIS	= Blind spot information system
CEM	= Central Electronic Module
DRL	= Daytime Running Lights
DSTC	= Dynamic Stability Traction Control
ECC	= Electronic climate control system
ECPS	= Electronic power steering
EXC	= Exclusive
EXT. D	= Extended electrical distribution
HISPEED	= High speed data bus
I5D	= D5244 T4/T5/T6/T7
LH	= Left-hand side
LHD	= Left-hand drive
LOSPEED	= Low speed data bus
MAN	= Manual transmission
MCC	= Manual Climate Control
OPN	= Option (factory-installed)
PCL	= Power Child Lock
GASOLINE	= Gasoline
REM	= Rear Electronic Module
RH	= Right-hand side
RHD	= Right-hand drive
RTI	= Road Traffic Information
SRS	= Airbag
SUBWOOF	= Bass speaker
SULEV	= Super Ultra Low Emission Vehicle
SUM	= Suspension Module (SUM)
T	= Turbocharged engine
ULEV	= Ultra Low Emission Vehicle
W/O	= Without
5CYL	= 5-cylinder engine
6CYL	= 6-cylinder engine
8CYL	= 8-cylinder engine

Colors

BL	= Blue
BN	= Brown
GN	= Green
GR	= Gray
LBL	= Light Blue
LGN	= Light Green
OR	= Orange
P	= Pink
R	= Red
SB	= Black
VO	= Violet
W	= White
Y	= Yellow

How to use the wiring diagrams 1:2

The descriptions below apply in general to all wiring diagram manuals, although not all sections are necessarily contained in this manual.

A. Component designation

Every component has a component designation that consists of two parts.

The first part is a type number that describes the type of component in question, for example 3/xx.

The second part of the designation is a serial number, e.g. x/2.

Together, this constitutes a component designation, e.g. 3/2.

At the end of the manual is a list of components, where, with the help of the component designation, you can read off the name of the component, for example, 3/2 = light switch.

List of type numbers

The list shows which type of component that respective type numbers refer to, for example, 3/x = switch, 6/x = electric motor, etc.

- 1 Battery
- 2 Relay
- 3 Switch
- 4 Control module
- 5 Driver information module
- 6 Electric motor
- 7 Sensor
- 8 Actuator
- 9 Heating element
- 10 Light
- 11 Fuse
- 15 Electrical distribution rail/box
- 16 Audio
- 17 Service/diagnostics
- 18 Contact reel
- 19 Meter
- 20 Ignition component/shunt
- 26 Converter
- 27 Optics
- 31 Ground connection
- 53 Branching point
- 54 Connector

B. Branching points

The wiring diagrams contain numbered junction points, e.g. 53/352.

This manual contains a section with a list of branching points. This list shows all the components that are connected to each branching point.

The location of the branching points is shown in the "Cable harness routing in vehicle" section.

C. Connectors

Connectors provide a bridge between two cable harnesses and are described in the "Connectors" section.

D. Electrical distribution

Operation of the fuses and relays is shown in the "Electrical distribution" section.

E. Data communication

Today's cars are equipped with CAN, LIN & MOST networks that transmit information. Connections to these networks are shown in their entirety on the respective wiring diagram. Complete information on Data communication can be found in the section entitled "Control modules".



F. Abbreviations

A number of different abbreviations are used in the manual. These are explained in the section "Abbreviations".

G. Component location

There is a section at the end of the manual in which the appearance and location of components is described in numerical order.

How to use the wiring diagrams 2:2




List of symbols

- = System voltage
- = Ground connection via wiring
- = Ground connection in component/chassis
- = Screened wire
- = Junction point
- = Twisted cable
- = Electrical connection
- = Variant
- = CAN communication
- = CAN high data signal (CAN H)
- = CAN low data signal (CAN L)
- = LIN communication
- = DIN cable, coaxial cable, etc.
- = Data communication
- = CAN communication
- = MOST communication
- = MOST communication
- = Connection with distribution box
- = Further connection to...
- = Connector between cable harnesses
- = Connector connected in component

Electrical distribution, V70 1:2


Overview

15/31



Electrical distribution, V70 2:2


Overview



Electrical distribution, XC90 1:2


Overview

15/31




Electrical distribution, XC90 2:2

Overview



Fuses

Engine compartment 11A/1-5




11A Fuses in engine compartment

No.	Fuse function	via	A
1	4/109 Glow plug control module, I5D 20/22-26 Glow plug 20/22-26 Glow plug, I5D	- 2/14 4/109	60
2	6/29 Motor, electric cooling fan	4/71	60
3	-	-	-
4	-	-	-
5	-	-	-

Fuses

Engine compartment 11B/1-11




11B Fuses in engine compartment

No.	Fuse function	via	A
1	4/16 Brake Control Module (BCM)	-	30
2	4/16 Brake Control Module (BCM)	-	30
3	6/104 High pressure headlight washer motor	2/182	35
4	6/35 Fuel pump, auxiliary heater 6/73 Coolant pump, auxiliary heater 9/30 Auxiliary heater	4/7 4/7 4/7	25
5	54/8 Connector, cable harness, auxiliary lights, 30-feed	-	20
6	6/25 Starter motor	2/35	35
7	2/90 Relay, windshield wiper, low/high speed 2/91 Relay, intermittent wiping 6/1 Windshield wiper motor	2/91 - 2/90, 2/91	25
8	4/28 Transmission Control Module (TCM), TF-80SC/TF-80SC AWD	-	15
9	4/83 Control module fuel pump 6/31 Feed pump, ejectors 6/33 Fuel pump	4/56 4/56 4/56	15
10	2/14 Relay, glow plug unit 4/46 Engine Control Module (ECM), diesel 8/6-10 Injection valves, diesel 8/111 High-pressure solenoid valve, diesel not I5D 20/3-8 Spark plug and ignition coil, not 8-cyl. 20/14 Condenser, ignition coils, 8-cyl. 20/46-53 Spark plug with ignition coil, 8-cyl.	- - 4/46 - - -	20
11	6/44 Cooling fan, electrics box, engine compartment 7/51 Accelerator pedal sensor 8/3 Electromagnetic clutch, climate control system	- - 2/22	10

continues

Fuses

Engine compartment 11B/12-14




11B Fuses in the engine compartment

No.	Fuse function	via	A
12	7/17 Mass air flow sensor (MAF), Diesel	-	5
	4/46 Engine Control Module (ECM), gasoline not 8-cyl.	-	15
	7/17 Mass air flow sensor (MAF), gasoline not 8-cyl.	-	
	8/6-11 Injection valves, gasoline not 8-cyl.	-	
	8/146-153 Injection valves, 8-cyl.	-	
13	4/46 Engine Control Module (ECM), 5-cyl. normally aspirated/8-cyl.	-	10
	4/50 Electronic Throttle Module (ETM), Bi-Fuel	-	
	6/120 Throttle body motor, 5-cyl. normally aspirated/8-cyl.	4/46	
	4/46 Engine Control Module (ECM), I5D	-	15
	6/118 Fuel, swirl pump, I5D	4/46	
	6/120 Throttle body motor, I5D	4/46	
14	8/98 Fuel, pressure regulator, I5D	4/46	
	8/111 High-pressure solenoid valve, I5D	4/46	
	7/15 Heated oxygen sensor, I5D	-	10
	4/46 Engine Control Module (ECM), Bi-Fuel	-	20
	7/15 Heated oxygen sensor	-	
	7/82 Heated oxygen sensor, diagnosis 1	-	
	7/103 Heated oxygen sensor 3	-	
	7/15 Front heated oxygen sensor, bank 2, 8-cyl.	-	20
	7/82 Front heated oxygen sensor, bank 1, 8-cyl.	-	
	7/103 Rear heated oxygen sensor, bank 2, 8-cyl.	-	
	7/104 Rear heated oxygen sensor, bank 1, 8-cyl.	-	
	continues		

Fuses

Engine compartment 11B/15




11B Fuses in the engine compartment

No.	Fuse function	via	A
15	6/67 Pump, fuel leakage control 6/105 Fuel distributor gas, Bi-Fuel 8/17 EGR valve, diesel not I5D 8/18 EVAP valve 8/19 Solenoid, variable valve timing, intake 8/28 Turbocharger control valve 8/64 Solenoid valve, engine pad, diesel not I5D 8/75 Valve, fuel cut-off DFCO 8/81 Solenoid, variable valve timing outlet 8/82 Solenoid, variable turbo geometry, diesel not I5D 9/32 PTC-resistor air preheating	-	10
	4/46 Engine Control Module (ECM), 8-cyl. 6/67 Pump, fuel leakage control, 8-cyl. 7/17 Mass air flow sensor (MAF), 8-cyl. 8/3 Electromagnetic clutch, climate control system, 8-cyl. 8/18 EVAP valve, 8-cyl. 8/19 Solenoid, variable valve timing, intake, bank 2, 8-cyl. 8/81 Solenoid, variable valve timing, exhaust, bank 2, 8-cyl. 8/107 Valve, variable intake, 8-cyl. 8/117 Solenoid, variable valve timing, intake, bank 1, 8-cyl. 8/118 Solenoid, variable valve timing, exhaust, bank 1, 8-cyl.	-	15
	4/109 Glow plug control module, I5D 6/143 Regulator motor, turbo, I5D 8/64 Solenoid valve, engine pad, I5D 8/113 Vacuum valve, EGR cooler, I5D 8/120 EGR valve, I5D	-	15
continues			

Fuses

Engine compartment 11B/16-20




11B Fuses in the engine compartment

No.	Fuse function	via	A
16	10/1 Left front lamp housing, daytime running lights 10/70 Low beam, left	4/56 4/56	20
17	10/2 Right front lamp housing, daytime running lights 10/66 Low beam, right	4/56 4/56	20
19	2/32 Main relay, engine management system 4/46 Engine Control Module (ECM)	- -	5
20	10/11 Running/parking light, front left 10/12 Running/parking light, front left 10/71 Side running light, front left 10/73 Side running light, front right	4/56 4/56 4/56 4/56	15

Fuses

Passenger compartment 11C/1-4




11C Fuses in the passenger compartment

No.	Fuse function	via	A
1	4/52 Power Seat Module (PSM), V70	-	25
	6/16 Driver seat motor, backrest angle, V70	4/52	
	6/17 Driver seat motor, up/down front edge, V70	4/52	
	6/18 Driver seat motor, up/down rear edge, V70	4/52	
	6/19 Driver seat motor, forward/backward, V70	4/52	
	6/28 Motor, passenger compartment fan, XC90	4/31	30
2	6/20 Passenger seat motor, forward/backward, V70	3/27	25
	6/64 Passenger seat motor, backrest angle, V70	3/27	
	6/65 Passenger seat motor, up/down front edge, V70	3/27	
	6/66 Passenger seat motor, up/down rear edge, V70	3/27	
	16/105 Audio Module (AUD), XC90	-	30
3	6/28 Motor, passenger compartment fan, V70	4/31	30
	4/52 Power Seat Module (PSM), XC90	-	
	6/16 Driver seat motor, backrest angle, XC90	4/52	
	6/17 Driver seat motor, up/down front edge, XC90	4/52	
	6/18 Driver seat motor, up/down rear edge, XC90	4/52	
	6/19 Driver seat motor, forward/backward, XC90	4/52	
4	3/75 Lock unit, right front door, V70	3/127	25
	3/127 Passenger/Driver Door Module (PDM)/(DDM), V70	-	
	6/60 Front right power window motor, V70	3/127	
	6/63 Right power exterior rearview mirror, V70	3/127	
	9/34 Right heated exterior rearview mirror, V70	3/127	
	10/149 Right exterior rearview mirror lighting, V70	3/127	
	6/20 Passenger seat motor, forward/backward, XC90	3/27	
	6/64 Passenger seat motor, backrest angle, XC90	3/27	
	6/65 Passenger seat motor, up/down front edge, XC90	3/27	
	6/66 Passenger seat motor, up/down rear edge, XC90	3/27	

Fuses

Passenger compartment 11C/5-7




11C Fuses in the passenger compartment

No.	Fuse function	via	A
5	3/74 Lock unit, left front door, V70	3/126	25
	3/126 Driver/Passenger Door Module (DDM)/(PDM), V70	-	
	6/58 Front left power window motor, V70	3/126	
	6/62 Left power exterior rearview mirror, V70	3/126	
	9/33 Left heated exterior rearview mirror, V70	3/126	
	10/148 Left exterior rearview mirror lighting, V70	3/126	
	3/74 Front left door lock unit, XC90	3/126	
	3/126 Driver/Passenger Door Module (DDM)/(PDM), XC90	-	
	6/58 Front left power window motor, XC90	3/126	
	6/62 Left power exterior rearview mirror, XC90	3/126	
6	9/33 Left heated exterior rearview mirror, XC90	3/126	
	10/148 Left exterior rearview mirror lighting, XC90	3/126	
	3/117 Ceiling light switch unit, V70	4/70	10
	4/33 Sun Roof Module (SRM), V70	4/70	
	4/70 Upper Electronic Module (UEM), V70	-	
	4/76 Remote controlled garage door opener, V70	4/70	
	7/149 Rain Sensor Module (RSM), V70	4/70	
	10/25 Ceiling light, cargo compartment, V70	4/70	
	10/114 Left-hand vanity mirror lighting, V70	4/70	
	10/115 Right-hand vanity mirror lighting, V70	4/70	
7	10/150 Rear reading light, V70	4/70	
	3/75 Lock unit, front right door, XC90	3/127	25
	3/127 Passenger/Driver Door Module (PDM)/(DDM), XC90	-	
	6/60 Front right power window motor, XC90	3/127	
	6/63 Right power exterior rearview mirror, XC90	3/127	
	9/34 Right heated exterior rearview mirror, XC90	3/127	
7	10/149 Right exterior rearview mirror lighting, XC90	3/127	
	6/15 Sunroof motor, V70	4/33	15

continues

Fuses

Passenger compartment 11C/8-11




11C Fuses in the passenger compartment

No.	Fuse function	via	A
8	3/157 Switch airbag passenger side, V70 4/9 Supplemental Restraint System module (SRS), V70 4/28 Transmission Control Module (TCM), V70 4/46 Engine Control Module (ECM), V70 4/56 Central Electronic Module (CEM), V70 4/58 Rear Electronic Module (REM), V70 16/65 Antenna ring/ignition switch lighting, V70	3/1 3/1 3/1, 4/56 3/1, 4/56 3/1 3/1 3/1	7.5
9	3/111 Light Switch Module (LSM), V70 3/254 Steering Wheel Module (SWM), V70 4/68 Steering Wheel Angle Sensor Module (SAS), V70 17/13 Data link connector, V70 16/46 Multimedia display, XC90 16/106 CD Player Module (MP2), XC90 16/107 MD Player Module (MP1), XC90 54/112 Connector, Infotainment cable harness, 30-feed, XC90	- - 3/254 - - - - -	5 10
10	16/1 Audio Module (AUM), V70 16/93 Control module, cellular phone handsfree, V70 3/111 Light Switch Module (LSM), XC90 3/254 Steering Wheel Module (SWM), XC90 4/68 Steering Wheel Angle Sensor Module (SAS), XC90 17/13 Data link connector, XC90	- - - - 3/254 -	20 5
11	16/2 Amplifier, V70 3/157 Switch airbag passenger side, XC90 4/9 Supplemental Restraint System module (SRS), XC90 4/28 Transmission Control Module (TCM), XC90 4/46 Engine Control Module (ECM), XC90 4/56 Central Electronic Module (CEM), XC90 4/58 Rear Electronic Module (REM), XC90 16/65 Antenna ring/ignition switch lighting, XC90	- 3/1 3/1 3/1, 4/56 3/1, 4/56 3/1 3/1 3/1	30 7.5

continues

Fuses

Passenger compartment 11C/12-14




11C Fuses in the passenger compartment

No.	Fuse function	via	A
12	16/46 RTI display, V70 3/117 Ceiling light switch unit, XC90 4/33 Sun Roof Module (SRM), XC90 4/70 Upper Electronic Module (UEM), XC90 4/76 Remote controlled garage door opener, XC90 7/149 Rain Sensor Module (RSM), XC90 10/114 Left-hand vanity mirror lighting, XC90 10/115 Right-hand vanity mirror lighting, XC90 10/150 Rear reading light, XC90 10/172 Reading light, third row of seats, XC90	- 4/70 4/70 - 4/70 4/70 4/70 4/70 4/70 4/70	10
13	16/60 Phone Module (PHM), V70 6/15 Sunroof motor, XC90	- 4/33	5 15
14	16/60 Phone Module (PHM), XC90	-	5

Fuses

Cargo compartment 11E/1-7




11E Fuses by battery

No.	Fuse function	via	A
1	4/58 Rear Electronic Module (REM) Main fuse for: F1-F38	-	60
2	11 F/1 Fuse in cargo compartment auxiliary fuse box	-	40
4	4/56 Central Electronic Module (CEM) Main fuse for: F1-F2, F11, F13-F16, F26-F30, F33	-	50
5	4/56 Central Electronic Module (CEM) Main fuse for: F3, F5-F10, F17-F23, F31-F32, F34	-	50
6	11C/1-5 Fuses in the passenger compartment fuse box, V70 11C/1, 3-6 Fuses in the passenger compartment fuse box, XC90	-	50
7	11C/6-13 Fuses in the passenger compartment fuse box, V70 11C/2, 9-14 Fuses in the passenger compartment fuse box, XC90	-	50

Fuses

Cargo compartment 11F/1-2




11F/1-2 Fuses in extra fuse box cargo compartment, XC90

No.	Fuse function	via	A
1	16/122 Rear Audio Separation module (RAS), XC90 16/124 Rear Seat Entertainment module (RSE), 30 feed	-	10
2	16/124 Rear Seat Entertainment module (RSE), X feed	-	5

Fuses

Central Electronic Module (CEM) F1-F14




4/56 Central Electronic Module (CEM)

No.	Fuse function	via	A
F1	9/13 Seat Heating Module (SHM), right-hand	-	15
F2	9/12 Seat Heating Module (SHM), left-hand	-	15
F3	16/10 Horn 1	-	15
	16/11 Horn 2, V70	-	
F5	16/46 Multimedia display, XC90	-	10
	16/94 Infotainment Control Module (ICM), XC90	-	
	16/106 CD Player Module (MP2), XC90	-	
	16/107 MD Player Module (MP1), XC90	-	
	16/108 Multimedia Module (MMM), XC90	-	
	54/112 Connector, Infotainment cable harness, extended D-feed, XC90	-	
F8	16/35 Siren Control Module (SCM)	-	5
F9	3/9 Contact brake light	-	5
F10	3/112 Climate Control Module (CCM)	-	10
	4/7 Combustion Preheater Module (CPM)	-	
	4/52 Power Seat Module (PSM)	-	
	5/1 Driver Information Module (DIM)	-	
	6/48 Damper Motor Module (DMM), recirculation	-	
	6/69 Damper Motor Module (DMM), ventilation/floor/defroster	-	
	6/95 Damper Motor Module (DMM), temperature, left-hand side	-	
	6/96 Damper Motor Module (DMM), temperature, right-hand side	-	
	6/102 Damper Motor Module (DMM), defroster	-	
	6/103 Damper Motor Module (DMM), floor/ventilation	-	
F11	7/93 Occupant Weight Sensor (OWS)	-	15
	7/159 Air Quality Sensor (AQS)	-	
	9/1 Outlet 12V front	-	
F14	9/25 Outlet 12V rear	-	15
	11 F/2 Fuse in cargo compartment auxiliary fuse box	-	

continues

Fuses

Central Electronic Module (CEM) F15-F34




4/56 Central Electronic Module (CEM)

No.	Fuse function	via	A
F15	4/16 Brake Control Module (BCM)	-	5
F16	4/99 Electronic Power Steering module 6/38 Motor, left headlight adjustment 6/39 Motor, right headlight adjustment 8/88 Solenoid, fuel tank, Bi-Fuel, rear 8/89 Solenoid, fuel tank, Bi-Fuel, front left 8/90 Solenoid, fuel tank, Bi-Fuel, front right 10/1 Left front lamp housing, Bi-Xenon 10/2 Right front lamp housing, Bi-Xenon	- - - 4/58 4/58 4/58 -	10
F17	10/5 Fog light, front left	-	7.5
F18	10/6 Fog light, front right	-	7.5
F20	6/113 Coolant pump, 8-cyl.	-	5
F21	3/156 Gear Selector Module (GSM) 4/28 Transmission Control Module (TCM) 8/36 Solenoid shift lock 8/134 Solenoid, reverse interlock, manual	- - 3/156 -	10
F22	10/68 High beam, left	-	10
F23	10/64 High beam, right	-	10
F28	3/27 Switch unit, power passenger seat 16/1 Audio Module (AUM), V70 16/46 RTI display, accessory, V70 16/93 Control module, cellular phone handsfree, V70	- - -	5
F30	27/3 Left Camera Module (LCM) 27/4 Right Camera Module (RCM)	- -	5
F33	6/114 Vacuum pump	8/84	20
F34	6/3 Right-hand headlight wiper motor, V70 6/4 Left-hand headlight wiper motor, V70 6/127 Washer motor	- - -	15

Fuses

Rear Electronic Module (REM) F1-F7




4/58 Rear Electronic Module (REM)

No.	Fuse function	via	A
F1	10/48 Reversing light, right 10/55 Reversing light, left 54/98 Connector, cable harness, rear seat entertainment, reverse gear signal, XC90	- - -	10
F2	10/3 License plate lighting 10/19 Auxiliary brake light 10/44 Tail light 1, right 10/46 Fog light, right rear 10/51 Tail light 1, left 10/53 Fog light, left rear 10/45 Tail light 2, right, V70 10/52 Tail light 2, left, V70 10/173 Cargo compartment lighting, tailgate, XC90	- - - - - - - - -	20
F3	4/78 Accessory Electronic Module (AEM) 4/106 Control module, remote parking heater start	- -	15
F5	4/58 Rear Electronic Module (REM)	-	10
F6	16/15 CD changer, V70 16/36 TV receiver, V70 16/45 Road Traffic Information module (RTI), V70 16/46 RTI display, accessory, V70 16/149 MP3 player, V70 16/110 Antenna module (ATM), XC90 54/98 Connector cable harness Rear Seat Entertainment, 30-feed, XC90	- - - - - - - -	7.5 16/45
F7	17/39 13-pin outlet, tow hitch cable harness 2/238 Relay, audio disconnection, V70 16/45 Traffic information module, Turn-by-Turn 16/49 Traffic Message Channel module, V70	- - - -	15

continues

Fuses

Rear Electronic Module (REM) F8-F28




4/58 Rear Electronic Module (REM)

No.	Fuse function	via	A
F8	17/19 12V outlet, cargo compartment	-	15
F9	2/139 Deadlock relay, right-hand rear door 3/86 Power window switch, right rear door 6/93 Motor, rear right power window	- - 3/86	20
F10	2/138 Deadlock relay, left-hand rear door 3/85 Power window switch, left rear door 6/92 Motor, rear left power window	- - 3/85	20
F13	8/85 Thermostatic switch and fuel filter heating	-	15
F14	16/79 Bass speaker, V70 6/76 Climate control system, rear XC90 16/79 Subwoofer Module (SUB), XC90	- - -	15
F17	16/145 Satellite radio receiver, V70	-	5
F19	6/32 Rear window wiper motor	-	15
F20	17/38 7-pin outlet, tow hitch cable harness 17/39 13-pin outlet, tow hitch cable harness 16/45 Traffic information module, Turn-by-Turn 16/49 Traffic Message Channel module, V70	- - - -	20
F21	Spare	-	10
F23	4/82 Differential Electronic Module (DEM)	-	7.5
F24	4/84 Suspension Module (SUM), V70	-	15
F26	4/86 Parking Assistance Module (PAM)	-	5
F27	Main fuse for F20, F21, F23, F24, F26	-	30
F28	3/76 Lock unit, left rear door 3/77 Lock unit, right rear door 3/78 Lock unit, tailgate 6/37 Lock motor, fuel filler flap	- - - -	15

continues

Fuses

Rear Electronic Module (REM) F29-F38






4/58 Rear Electronic Module (REM)

No.	Fuse function	via	A
F29	4/110 - running light - left-hand direction indicator	-	25
	26/4 Converter, direction indicators & brake lights, USA - running light - left-hand direction indicator	-	
F30	4/110 - brake lights - fog lights - right-hand direction indicator	-	25
F31	Main fuse for F37-F38	-	40
F37	9/2 Heated rear window	-	20
F38	9/2 Heated rear window	-	20

Relays

Ignition switch and relays




Term.	Color
1	BL-R
2	-
3	Y
4	R-SB
5	-
6	VO
7	Y-W
8	BL



Position	Terminal					
	30	15	15	X	15̄	S
Key Out	X					
0	*					*
I	*	*		*	*	*
II	*	*	*	*	*	*
III	*	*	*			*


Relays, general

The diagram indicates two or three different designations for the relay's position. This is described below.



Relays

Engine compartment FMA1 - FST3



Relays in the engine compartment

Pos	Relay function
FMA1	2/35 Relay, starter motor
FMA2	2/14 Relay, glow plug unit
FMA3	2/32 Main relay, engine management system
FMI2	2/22 Relay, climate control system
FST1	2/90 Relay, windshield wiper, low/high speed
FST2	2/91 Relay, intermittent wiping
FST3	2/182 Relay, high pressure headlight washer motor

Relays

Other relays

Other relays


Pos	Relay function
Left-hand rear door	2/138 Deadlock relay, left-hand rear door
Right-hand rear door	2/139 Deadlock relay, right-hand rear door
By front seat	2/237 Disconnect relay, rear speaker

Relays accessories

Pos	Relay function
Engine compartment	2/64 Relay auxiliary lights
Cargo compartment	2/191 Relay, remote parking heater start, radio signal
Front member	2/192 Relay, electric engine heater
Dashboard	2/238 Relay, audio disconnection

Ground connections

Overview



Ground connections

31/1 - 31/44

31/1 Right MacPherson strut tower	
6/3	Right-hand headlight wiper motor, V70
6/104	High pressure headlight washer motor
7/5	Washer fluid level sensor

31/2 Left MacPherson strut tower	
4/46	Engine Control Module (ECM), 8-cyl./I5D
4/71	Cooling fan control module

31/4 Engine	
31/44	Ground connection

31/6 A-pillar, left-hand side	
3/6	Switch, hazard warning flashers
4/31	Fan control module, RHD
4/56	Central Electronic Module (CEM), LHD
6/15	Sunroof motor
10/29	Glove compartment lighting
10/125	Left-hand front courtesy lighting
10/126	Right-hand front courtesy lighting
16/65	Antenna ring/ignition switch illumination

31/10 A-pillar, right-hand side	
4/31	Fan control module, LHD
4/56	Central Electronic Module (CEM), RHD
4/84	Suspension Module (SUM), V70
9/1	Outlet 12V front
9/25	Outlet 12V rear
10/72	Front ashtray lighting, V70

31/44 Left-hand side member, lower engine compartment	
31/4	Ground connection

Ground connections

31/46 - 31/67

31/46 Rear seat riser, left-hand side	
2/138	Deadlock relay, left-hand rear door, PCL
3/27	Switch unit, power passenger seat, RHD
3/76	Lock unit, left rear door
3/85	Power window switch, left rear door
4/52	Power Seat Module (PSM), LHD
4/82	Differential Electronic Module (DEM)
8/51	Front left side airbag igniter
9/12	Seat Heating Module (SHM), left-hand

31/47 Rear seat riser, left-hand side	
4/58	Rear Electronic Module (REM)
8/66	Left-hand inflatable curtain igniter, V70

31/48 Rear seat riser, right-hand side	
4/83	Control module fuel pump
6/31	Feed pump, ejectors
6/33	Fuel pump

31/53 Firewall	
1/1	Battery

31/66 Front seat riser, left-hand side	
3/126	Driver/Passenger Door Module (DDM)/(PDM)
10/15	Direction indicator, left front door, XC90
27/3	Left Camera Module (LCM)

31/67 Front seat riser, right-hand side	
2/139	Deadlock relay, right-hand rear door, PCL
3/27	Switch unit, power passenger seat, LHD
3/77	Right-hand rear door lock unit, PCL
3/86	Power window switch, right rear door
3/127	Passenger/Driver Door Module (PDM)/(DDM)
4/52	Power Seat Module (PSM), RHD
6/35	Fuel pump, auxiliary heater
7/93	Occupant Weight Sensor (OWS)
8/52	Front right side airbag igniter
9/13	Seat Heating Module (SHM), right-hand
10/16	Direction indicator, right front door, XC90
27/4	Right Camera Module (RCM)

Ground connections

31/70 - 31/73

31/70 Left-hand side member, lower engine compartment	
10/65	Auxiliary light, front right, accessories
10/69	FL auxiliary light, accessory

31/72 Cargo compartment	
4/58	Rear Electronic Module (REM)
4/86	Parking Assistance Module (PAM)
6/32	Rear window wiper motor
6/76	Climate control system, rear XC90
7/100	Inclination Sensor Module (ISM)
7/137	Glass breakage sensor, tailgate, V70
8/66	Left-hand inflatable curtain igniter, XC90
9/2	Heated rear window
10/18	Lamp housing, rear left
16/15	CD-changer, accessory, V70
16/45	Road Traffic Information module (RTI), V70
16/149	MP3 player, accessory, V70

31/73 Rear seat riser, right-hand side	
2/191	Relay, remote parking heater start, radio signal, accessory, V70
4/78	Accessory Electronic Module (AEM)
4/106	Control module, remote parking heater start, accessory, V70
8/85	Thermal switch and electric fuel filter heating, Diesel
8/88	Solenoid, fuel tank, Bi-Fuel, rear
8/89	Solenoid, fuel tank, Bi-Fuel, front left
8/90	Solenoid, fuel tank, Bi-Fuel, front right
10/17	Lamp housing, rear right
10/218	Indicator light, remote start, accessory, V70
16/79	Bass speaker, V70
16/79	Subwoofer Module (SUB), XC90
16/81	TV display, accessory, XC90
16/82	DVD player, accessory, XC90
17/19	12V outlet, cargo compartment
54/98	Connector, cable harness, rear seat entertainment, XC90

Ground connections

31/83 - 31/84

31/83 A-pillar, left-hand side	
3/117	Switch unit, ceiling light
4/33	Sun Roof Module (SRM)
4/70	Upper Electronic Module (UEM)
4/76	Remote control unit for garage door opener
5/1	Driver Information Module (DIM)
7/122	Mass Movement Sensor (MMS), front
7/149	Rain Sensor Module (RSM)
7/158	Mass movement sensor (MMS), rear, XC90
10/25	Ceiling light, cargo compartment, V70
10/114	Vanity mirror lighting, left
10/115	Vanity mirror lighting, right
10/150	Rear reading light
10/172	Reading light, third row of seats, XC90
16/65	Antenna ring/ignition switch illumination
16/108	Multimedia Module (MMM), XC90
31/98	Ground connection

31/84 A-pillar, right-hand side	
3/111	Light Switch Module (LSM)
3/112	Climate Control Module (CCM)
3/254	Steering Wheel Module (SWM)
4/68	Steering Wheel Angle Sensor Module (SAS)
6/48	Damper Motor Module (DMM), recirculation
6/69	Damper Motor Module (DMM), ventilation/floor/defroster
6/95	Damper Motor Module (DMM), temperature, left-hand side
6/96	Damper Motor Module (DMM), temperature, right-hand side
6/102	Damper Motor Module (DMM), defroster
6/103	Damper Motor Module (DMM), floor/ventilation
7/159	Air Quality Sensor (AQS)
16/1	Audio Module (AUM), V70
16/2	Amplifier, V70
16/46	RTI display, V70
16/46	Multimedia display, XC90
16/60	Phone Module (PHM)
16/93	Control module, cellular phone handsfree, accessory
16/94	Infotainment Control Module (ICM), XC90
16/105	Audio Module (AUD), XC90
16/106	CD Player Module (MP2), XC90
16/107	MD Player Module (MP1), XC90
17/13	Data link connector
54/112	Connector, Infotainment cable harness, XC90

Ground connections

31/88 - 31/91

31/88 Engine ignition coils	
20/3	Spark plug and ignition coil, not 8-cyl.
20/4	Spark plug and ignition coil, not 8-cyl.
20/47	Spark plug with ignition coil, 8-cyl.
20/49	Spark plug with ignition coil, 8-cyl.

31/89 Engine ignition coils	
20/5	Spark plug and ignition coil, not 8-cyl.
20/6	Spark plug and ignition coil, not 8-cyl.
20/7	Spark plug and ignition coil, not 8-cyl.
20/8	Spark plug with ignition coil, 6-cyl.
20/14	Condenser, ignition coil, 8-cyl.
20/51	Spark plug with ignition coil, 8-cyl.
20/53	Spark plug with ignition coil, 8-cyl.

31/90 Engine ignition coils	
20/46	Spark plug with ignition coil, 8-cyl.
20/48	Spark plug with ignition coil, 8-cyl.

31/91 Engine	
4/50	Electronic Throttle Module (ETM), Bi-Fuel
9/32	PTC resistor - air preheating, Bi-Fuel

Ground connections

31/93 - 31/94

31/93 Left MacPherson strut tower	
3/10	Reversing light contact, MAN
3/62	Hood alarm contact
3/156	Gear Selector Module (GSM), TF-80SC / TF-80SC AWD
4/7	Combustion Preheater Module (CPM)
4/28	Transmission Control Module (TCM), TF-80SC / TF-80SC AWD
4/56	Central Electronic Module (CEM)
4/99	Electronic power steering control module
6/1	Windshield wiper motor
6/4	Left-hand headlight wiper motor, V70
6/38	Motor, left headlight adjustment
6/113	Coolant pump, 8-cyl.
6/114	Vacuum pump
7/4	Brake fluid level sensor
7/51	Accelerator pedal sensor
7/73	Coolant level sensor
8/36	Shift lock solenoid, TF-80SC / TF-80SC AWD
8/37	Automatic transmission
8/134	Solenoid, reverse interlock, manual
9/30	Auxiliary heater
10/1	Lamp housing, front left
10/5	Fog light, front left
10/11	Front left parking light, XC90
10/13	Direction indicator, front left
10/15	Direction indicator front fender left, EU/OS, V70
10/71	Side running light, front left
16/10	Horn 1
16/11	Horn 2, V70
20/16	Capacitor, Bi-Fuel

31/94 Right MacPherson strut tower	
3/156	Gear Selector Module (GSM)
4/28	Transmission Control Module (TCM)
6/39	Motor, right headlight adjustment
8/36	Solenoid shift lock
10/2	Lamp housing, front right
10/6	Fog light, front right
10/12	Front right parking light, XC90
10/14	Direction indicator, front right
10/16	Direction indicator front fender right, EU/OS, V70
10/73	Side running light, front right
16/35	Siren Control Module (SCM)

Ground connections

31/95 - 31/100

31/95 Left MacPherson strut tower
--

4/16 Brake Control Module (BCM)

31/96 Right MacPherson strut tower

4/46 Engine Control Module (ECM)
4/71 Cooling fan control module, 8-cyl./I5D
6/105 Fuel distributor gas, Bi-Fuel
9/32 PTC-resistor air preheating

31/98 Windshield member, upper

3/117 Switch unit, ceiling light
4/33 Sun Roof Module (SRM)
4/70 Upper Electronic Module (UEM)
4/76 Remote control unit for garage door opener
5/1 Driver Information Module (DIM)
7/122 Mass Movement Sensor (MMS), front
7/149 Rain Sensor Module (RSM)
7/158 Mass Movement Sensor (MMS), rear, XC90
10/25 Ceiling light, cargo compartment, V70
10/114 Vanity mirror lighting, left
10/115 Vanity mirror lighting, right
10/150 Rear reading light
10/172 Reading light, third row of seats, XC90
16/65 Antenna ring/ignition switch illumination
16/108 Multimedia Module (MMM), XC90
31/83 Ground connection

31/99 Left-hand side window

7/135 Glass breakage sensor, left-hand, V70

31/100 Engine ignition coils

20/50 Spark plug with ignition coil, 8-cyl.
20/52 Spark plug with ignition coil, 8-cyl.


Ground connections

31/102 - 31/120

31/102 Front member	
2/192	Relay (230V), engine heater, accessory
31/118 Between front seats under the armrest	
2/237	Disconnect relay, rear speaker
16/122	Rear Audio Separation module (RAS)
16/124	Rear Seat Entertainment module (RSE)
31/120 Cargo compartment, accessory	
4/110	Trailer Module
16/15	CD changer, V70
16/45	Road Traffic Information module (RTI), V70
16/45	Traffic information module, Turn-by-Turn
16/46	RTI display, V70
16/49	Traffic Message Channel module, V70
16/79	Bass speaker, V70
16/79	Subwoofer Module (SUB), XC90
16/145	Satellite radio receiver, V70
17/37	4-pin outlet, tow hitch cable harness
17/38	7-pin outlet, tow hitch cable harness
17/39	13-pin outlet, tow hitch cable harness
26/4	Converter, direction indicators & brake lights, USA

Control modules

Overview positions V70




Control modules

Overview designations V70

Unit	Designation
ACM	6/26 Alternator Control Module (ACM)
AEM	4/78 Accessory Electronic Module (AEM)
AQS	7/159 Air Quality Sensor (AQS)
AUM	16/1 Audio Module (AUM)
BCM	4/16 Brake Control Module (BCM)
BSC	7/164 Body Sensor Cluster Stability Sensor (BSC)
CCM	3/112 Climate Control Module (CCM)
CEM	4/56 Central Electronic Module (CEM)
CPM	4/7 Combustion Preheater Module (CPM)
DDM/PDM	3/126 Driver/Passenger Door Module (DDM)/(PDM)
DEM	4/82 Differential Electronic Module (DEM)
DIM	5/1 Driver Information Module (DIM)
DMM	Damper Motor Module (DMM) -6/48 Damper Motor Module (DMM), recirculation -6/69 Damper Motor Module (DMM), ventilation/floor/defroster -6/95 Damper Motor Module (DMM), temperature, left-hand side -6/96 Damper Motor Module (DMM), temperature, right-hand side -6/102 Damper Motor Module (DMM), defroster -6/103 Damper Motor Module (DMM), floor/ventilation
ECM	4/46 Engine Control Module (ECM)
ETM	4/50 Electronic Throttle Module (ETM)
GSM	3/156 Gear Selector Module (GSM)
ISM	7/100 Inclination Sensor Module (ISM)
LCM	27/3 Left Camera Module (LCM)
LSM	3/111 Light Switch Module (LSM)
OWS	7/93 Occupant Weight Sensor (OWS)
PAM	4/86 Parking Assistance Module (PAM)
PDM/DDM	3/127 Passenger/Driver Door Module (PDM)/(DDM)
PHM	16/60 Phone Module (PHM)
PSM	4/52 Power Seat Module (PSM)
RCM	27/4 Right Camera Module (RCM)
REM	4/58 Rear Electronic Module (REM)
RSM	7/149 Rain Sensor Module (RSM)
RTI	16/45 Road Traffic Information module (RTI)
SAS	4/68 Steering Wheel Angle Sensor Module (SAS)
SCM	16/35 Siren Control Module (SCM)
SHM	Seat Heating Module (SHM) -9/12 Seat Heating Module (SHM), left-hand -9/13 Seat Heating Module (SHM), right-hand
SRM	4/33 Sun Roof Module (SRM)
SRS	4/9 Supplemental Restraint System module (SRS)
SUM	4/84 Suspension Module (SUM)
SWM	3/254 Steering Wheel Module (SWM)
TCM	4/28 Transmission Control Module (TCM)
UEM	4/70 Upper Electronic Module (UEM)
4/31	4/31 Fan control module
4/71	4/71 Cooling fan control module
4/110	4/110 Trailer Module
17/13	17/13 Data link connector

Control modules

Overview positions XC90




Control modules

Overview designations XC90

Unit	Designation
ACM	6/26 Alternator Control Module (ACM)
AEM	4/78 Accessory Electronic Module (AEM)
ATM	16/110 Antenna module (ATM)
AQS	7/159 Air Quality Sensor (AQS)
AUD	16/105 Audio Module (AUD)
BCM	4/16 Brake Control Module (BCM)
BSC	7/164 Body Sensor Cluster Stability Sensor (BSC)
CCM	3/112 Climate Control Module (CCM)
CEM	4/56 Central Electronic Module (CEM)
CPM	4/7 Combustion Preheater Module (CPM)
DDM/PDM	3/126 Driver/Passenger Door Module (DDM)/(PDM)
DEM	4/82 Differential Electronic Module (DEM)
DIM	5/1 Driver Information Module (DIM)
DMM	Damper Motor Module (DMM) -6/48 Damper Motor Module (DMM), recirculation -6/69 Damper Motor Module (DMM), ventilation/floor/defroster -6/95 Damper Motor Module (DMM), temperature, left-hand side -6/96 Damper Motor Module (DMM), temperature, right-hand side -6/102 Damper Motor Module (DMM), defroster -6/103 Damper Motor Module (DMM), floor/ventilation
ECM	4/46 Engine Control Module (ECM)
GSM	3/156 Gear Selector Module (GSM)
ICM	16/94 Infotainment Control Module (ICM)
ISM	7/100 Inclination Sensor Module (ISM)
LCM	27/3 Left Camera Module (LCM)
LSM	3/111 Light Switch Module (LSM)
MMM	16/108 Multimedia Module (MMM)
MP1	16/107 MD Player Module (MP1)
MP2	16/106 CD Player Module (MP2)
OWS	7/93 Occupant Weight Sensor (OWS)
PAM	4/86 Parking Assistance Module (PAM)
PDM/DDM	3/127 Passenger/Driver Door Module (PDM)/(DDM)
PHM	16/60 Phone Module (PHM)
PSM	4/52 Power Seat Module (PSM)
RCM	27/4 Right Camera Module (RCM)
REM	4/58 Rear Electronic Module (REM)
RSM	7/149 Rain Sensor Module (RSM)
SAS	4/68 Steering Wheel Angle Sensor Module (SAS)
SCM	16/35 Siren Control Module (SCM)
SHM	Seat Heating Module (SHM) -9/12 Seat Heating Module (SHM), left-hand -9/13 Seat Heating Module (SHM), right-hand
SRM	4/33 Sun Roof Module (SRM)
SRS	4/9 Supplemental Restraint System module (SRS)
SUB	16/79 Subwoofer Module (SUB)
SWM	3/254 Steering Wheel Module (SWM)
TCM	4/28 Transmission Control Module (TCM)
UEM	4/70 Upper Electronic Module (UEM)
4/31	4/31 Fan control module
4/71	4/71 Cooling fan control module
4/110	4/110 Trailer Module
17/13	17/13 Data link connector


Control modules

Central Electronic Module (CEM) 1:2




Control modules

Central Electronic Module (CEM) 2:2



Control modules


Rear Electronic Module (REM) 1:2



Control modules


Rear Electronic Module (REM) 2:2

4/58




Control modules

Data communication high speed CAN V70




Control modules
Data communication high speed CAN XC90




Control modules

Data communication low speed CAN V70




Control modules

Data communication low speed CAN XC90




Control modules

Data communication, LIN 1:2




Control modules

Data communication, LIN 2:2




Control modules

Data communication MOST, XC90




Group 23 Fuel system

Engine management system, I5D 1:3



Group 23 Fuel system


Engine management system, I5D 2:3



Group 23 Fuel system


Engine management system, I5D 3:3

4/46




Group 23 Fuel system

Engine management system, 5-cyl. 1:2




Group 23 Fuel system

Engine management system, 5-cyl. 2:2




Group 23 Fuel system Engine management system, 5-cyl. Turbo 1:2




Group 23 Fuel system

Engine management system, 5-cyl. Turbo 2:2




Group 23 Fuel system

Engine management system, 6-cyl. 1:2




Group 23 Fuel system

Engine management system, 6-cyl. 2:2




Group 23 Fuel system


Engine management system, Bi-fuel 1:2



Group 23 Fuel system




Group 23 Fuel system Engine management system, diesel 1:2




Group 23 Fuel system

Engine management system, diesel 2:2




Group 23 Fuel system

Engine management system, 8-cyl. 1:2




Group 23 Fuel system

Engine management system, 8-cyl. 2:2




Group 23 Fuel system Emission control, 5-cyl.




Group 23 Fuel system

Emission control, 5-cyl. turbo & 6-cyl.




Group 23 Fuel system Emission control, 8-cyl. XC90




Group 26 Cooling system

Cooling fan




Group 26 Cooling system

Cooling fan, I5D & 8-cyl.




Group 27 Engine control

Cruise control




Group 27 Engine control

Cruise control, I5D & 8-cyl.




Group 32 Alternator and voltage regulator Power supply




Group 33 Starting system

Starting system




Group 35 Lighting

High and low beams/Bi-Xenon & Daytime running lights V70




Group 35 Lighting

High and low beams/Bi-Xenon & Daytime running lights XC90




Group 35 Lighting

Fog lights




Group 35 Lighting

Brake lights




Group 35 Lighting Reversing lights




Group 35 Lighting

Follow-me-home lighting




Group 35 Lighting

Running/parking lights, tail lights & license plate lighting V70




Group 35 Lighting

Running/parking lights, tail lights & license plate lighting XC90




Group 35 Lighting

Interior lighting V70




Group 35 Lighting

Interior lighting XC90




Group 35 Lighting

Beam length adjustment V70




Group 35 Lighting

Beam length adjustment XC90




Group 35 Lighting, Accessories

Auxiliary lights




Group 36 Additional electrical equipment

Rain sensor




Group 36 Additional electrical equipment

Direction indicators and flashing hazard lights V70




Group 36 Additional electrical equipment

Direction indicators and hazard warning flashers XC90




Group 36 Additional electrical equipment

Wiper/washer, windshield




Group 36 Additional electrical equipment

Wiper/Washer Headlights V70




Group 36 Additional electrical equipment

High pressure headlight washer




Group 36 Additional electrical equipment

Wiper/washer, rear window




Group 36 Additional electrical equipment

Horn




Group 36 Additional electrical equipment

Electronic immobilizer




Group 36 Additional electrical equipment

Anti-theft alarm V70




Group 36 Additional electrical equipment

Anti-theft alarm XC90




Group 36 Additional electrical equipment

Parking assistance




Group 36 Additional electrical equipment, Accessories

Accessory Electronic Module (AEM) 1:2



Group 36 Additional electrical equipment, Accessories


Accessory Electronic Module (AEM) 2:2



Pos	Function	Type
A:1	Electrical distribution	Ground
A:2	Electrical distribution	Feed
A:3	CAN communication	Input/output signals
A:4	CAN communication	Input/output signals
B:1	Remote heater start, minicall	Feed
B:2	Remote heater start, minicall	Ground
B:3	Remote heater start, minicall	Input signal
	Remote heater start, radio signal	
B:5	Electric engine heater	Steering, alternating current feed
B:6	Parking assistance	Feed
B:7	Parking assistance	Input signal
B:8	Parking assistance	Ground
B:11	Handsfree, audio disengage	Input signal
B:12	Audio disengage	Output signal
B:13	Rheostat, audio	Output signal
B:14	Speed signal, audio	Output signal
	Speed signal, RTI Japan	
B:15	Alarm signal	Output signal
B:16	Alarm signal	Output signal
B:30	Antenna amplifier, audio	Feed
	dimmer, RTI Japan	Output signal
B:33	Alarm signal	Output signal
	RTI Japan	Steering, X-feed
B:34	Alarm signal	Output signal
	Reverse gear signal, RTI Japan	


Group 37 Wiring and fuses

Diagnostics system




Group 37 Wiring and fuses

12V outlet




Group 37 Wiring and fuses Tow hitch cable harness, 4-pin




Group 37 Wiring and fuses, Accessories

Tow hitch cable harness, 4/7-pin




Group 37 Wiring and fuses, Accessories

Tow hitch cable harness, 7-pin




Group 37 Wiring and fuses, Accessories

Tow hitch cable harness, 13-pin




Group 38 Instruments

Seat belt reminder




Group 38 Instruments

Driver information module




Group 38 Instruments

Driver information module, Bi-Fuel




Group 38 Instruments

Driver information module, I5D




Group 38 Instrument

Driver information module, 8-cyl.




Group 39 Other Audio V70




Group 39 Other

Audio with auxiliary amplifier V70 1:2




Group 39 Other


Audio with auxiliary amplifier V70 2:2




Group 39 Other Audio XC90



Group 39 Other Road Traffic Information module (RTI) V70




Group 39 Other, Accessories
Turn-by-Turn, navigation system V70




Group 39 Other, Accessories

Road Traffic Information module (RTI) XC90




Group 39 Other, Accessories

Handsfree V70




Group 39 Other, Accessories

Handsfree XC90




Group 39 Other, Accessories

Handsfree MAX V70




Group 39 Other, Accessories

Handsfree MAX XC90




Group 39 Other, Accessories


CD-Changer V70



Group 39 Other, Accessories RTI & CD changer V70





Group 39 Other, Accessories
MP3 player, V70




Group 39 Other, Accessories

CD/MD player XC90




Group 39 Other

Cellular phone V70




Group 39 Other, Accessories

Subwoofer V70




Group 39 Other, Accessories


Subwoofer XC90



Group 39 Other Infotainment XC90




Group 39 Other, Accessories
Satellite radio V70




Group 39 Other, Accessories

Rear Seat Entertainment XC90




Group 39 Other Rear Seat Entertainment XC90 1:2




Group 39 Other

Rear Seat Entertainment XC90 2:2




Group 43 Transmission

Automatic transmission AW55-50/51SN/AW50/51AWD




Group 43 Transmission Automatic transmission 4T65AWD XC90




Group 43 Transmission

Automatic transmission TF-80SC AWD




Group 43 Transmission

Automatic transmission TF-80SC / TF-80SC AWD, I5D




Group 43 Transmission

Geartronic




Group 43 Transmission Shift lock




Group 43 Transmission

Differential Electronic Module (DEM)




Group 59 Brake system

Brake control system




Group 64 Steering

Electronic power steering




Group 76 Shock absorbers

Four-C V70




Group 83 Doors and openings

Central locking system V70




Group 83 Doors and openings

Central locking system XC90




Group 83 Doors and openings

Power windows




Group 83 Doors and openings

Power sunroof




Group 84 Exterior decorative elements, etc.

Power exterior rearview mirrors




Group 84 Exterior decorative elements, etc.

Heated exterior rearview mirrors with camera function




Group 84 Exterior decorative elements, etc.

Heated exterior rearview mirrors




Group 84 Exterior decorative elements, etc.

Heated rear window




Group 85 Interior equipment

Power driver's seat




Group 85 Interior equipment

Power passenger seat




Group 85 Interior equipment

Heated seats




Group 87 Climate control system

Rear climate control system XC90




Group 87 Climate control system

Climate control system 1:2




Group 87 Climate control system

Climate control system 2:2




Group 87 Climate control system

Climate control system, I5D & 8-cyl. 1:2




Group 87 Climate control system

Climate control system, I5D & 8-cyl. 2:2




Group 87 Climate control system

Parking heater, auxiliary heater




Group 87 Climate control system, Accessories

Relay, electric engine heater




**Group 87 Climate control system, Accessories
Remote parking heater start V70**




Group 87 Climate control system, Accessories

Parking heater call start V70




Group 87 Climate control system, Accessories

Auxiliary heater V70




Group 88 Internal equipment

Remote garage door opener




Group 88 Internal equipment

Supplemental Restraint System module (SRS) V70



Group 88 Internal equipment Supplemental Restraint System module (SRS) XC90



Connectors

54/1 - 54/1B

54/1

1-pin gray

No.	Engine compartment harness		Engine harness, diesel		
1	2:14:3	Relay, glow plug unit	R	53/374	Branching point

54/1B

14-pin gray

No.	Engine harness		Engine compartment harness		
1	-	-	-	-	-
2	7/17:1 7/17:2 53/315 54/99:11	Mass air flow sensor (MAF), I5D Mass air flow sensor (MAF), Diesel Branching point, 5&6-cyl. Connector, 8-cyl.	GN	11B/12:2 Fuse in engine compartment fuse box	GN
3	53/309 54/129:5 53/335 53/335	Branching point Connector, 8-cyl. Branching point, I5D Branching point, disel	GN-GR GN-W	11B/15:2 53/396 Fuse in engine compartment fuse box Branching point, 8-cyl.	GN-GR
4	-	-	-	-	-
5	53/328	Branching point	GN-W	11B/10:2 Fuse in engine compartment fuse box	GN-W
6	8/3:1 8/3A:1	Electromagnetic clutch, climate control system Electromagnetic clutch, climate control system, 8-cyl.	GR	2/22:1 Relay, climate control system	GR
7	7/15:4 53/304 53/373	Heated oxygen sensor, I5D Branching point Branching point, disel	GN-BN R	11B/14:2 11B/10:2 Fuse in engine compartment fuse box Fuse in engine compartment fuse box, diesel	GN-BN R
8	6/25:2	Starter motor	GN-R	2/35:3 Relay, starter motor	GN-R
9	-	-	-	-	-
10	7/62:1	Output speed sensor	Y	4/28A:57 Transmission Control Module (TCM)	Y
11	7/62:2	Output speed sensor	SB	4/28A:39 Transmission Control Module (TCM)	SB
12	6/26B:1	Alternator Control Module (ACM)	GN-W	4/56C:16 Central Electronic Module (CEM)	GN-W
13	4/71:4	Cooling fan control module	VO	4/46A:7 4/46A:8 Engine Control Module (ECM) Engine Control Module (ECM), diesel	VO
14	4/50:6 53/314	Electronic Throttle Module (ETM) Branching point	GN-SB GN	11B/13:2 Fuse in engine compartment fuse box	GN-SB

Connectors

54/1C - 54/3.1:1-14

54/1C

2-pin gray

No.	Engine compartment harness		I5D engine harness		
1	11A/1:2	Main fuse in engine compartment fuse box	R	4/109:11	Glow plug control module
2	-	-	-	-	-

54/3.1

36-pin gray

No.	Passenger compartment harness		Engine compartment harness		
1	4/9B:18/46	Supplemental Restraint System module (SRS)	OR	54/4:5 54/113:1	Connector, V70 Connector, XC90
2	4/9B:19/47	Supplemental Restraint System module (SRS)	OR-SB	54/4:6 54/113:2	Connector, V70 Connector, XC90
3	4/9B:21/49	Supplemental Restraint System module (SRS)	GN-OR	54/4:7 54/122:1	Connector, V70 Connector, XC90
4	4/9B:20/48	Supplemental Restraint System module (SRS)	OR	54/4:8 54/122:2	Connector, V70 Connector, XC90
5	3/156A:2	Gear Selector Module (GSM)	GN-W	4/28B:21 4/28A:7 54/57.1:3	Transmission Control Module (TCM) Transmission Control Module (TCM), TF-80SC (AWD) Connector, I5D
6	54/10:6	Connector	BN	4/46B:4 4/46B:9 53/324	Engine Control Module (ECM) Engine Control Module (ECM), 8-cyl. Branching point
7	54/10:5	Connector	W	4/46B:29 4/46B:29	Engine Control Module (ECM) Engine Control Module (ECM), 8-cyl.
8	54/36:6	Connector	Y	4/46B:20 4/46B:47	Engine Control Module (ECM), 8-cyl. Engine Control Module (ECM)
9	7/56:1	Sensor ABS, rear left	BN	4/16:36	Brake Control Module (BCM)
10	7/56:2	Sensor ABS, rear left	Y	4/16:37	Brake Control Module (BCM)
11	4/56D:32 54/74:4	Central Electronic Module (CEM), V70 Connector	W	4/16:11	Brake Control Module (BCM)
12	4/56D:47 54/74:2	Central Electronic Module (CEM), V70 Connector	GN	4/16:15	Brake Control Module (BCM)
13	-	-	-	-	-
14	4/58C:4	Rear Electronic Module (REM)	Y	54/4:3 3/62:1	Connector, V70 Hood alarm contact, XC90

continues

Connectors

54/3.1:15-36

54/3.1

36-pin gray

No.	Passenger compartment harness		Engine compartment harness		
15	54/13:15	Connector	P	16/35:2	Siren Control Module (SCM)
16	5/1:6	Driver Information Module (DIM)	Y-R	7/4:1	Brake fluid level sensor
17	6/35:1	Fuel pump, auxiliary heater	Y	54/9:2	Connector
18	5/1:2	Driver Information Module (DIM)	GR	4/46B:37 4/46B:46 4/46B:55	Engine Control Module (ECM), I5D Engine Control Module (ECM) Engine Control Module (ECM), 8-cyl.
19	7/57:1	Sensor ABS, rear right	BN-W	4/16:43	Brake Control Module (BCM)
20	7/57:2	Sensor ABS, rear right	Y-W	4/16:42	Brake Control Module (BCM)
21	7/164:1	Body Sensor Cluster Stability Sensor (BSC)	GN	4/16:25	Brake Control Module (BCM)
22	7/164:2	Body Sensor Cluster Stability Sensor (BSC)	W	4/16:29	Brake Control Module (BCM)
23	7/164:3	Body Sensor Cluster Stability Sensor (BSC)	GR	4/16:6	Brake Control Module (BCM)
24	7/164:5	Body Sensor Cluster Stability Sensor (BSC)	GR-W	4/16:39	Brake Control Module (BCM)
25	5/1:5	Driver Information Module (DIM), XC90	Y	3/47:1	Parking brake contact, XC90
26	3/156A:6	Gear Selector Module (GSM)	SB	4/28A:54 53/329	Transmission Control Module (TCM) Branching point
27	4/84A:9	Suspension Module (SUM), V70	GR-R	8/21:1	Shock absorber, Four-C, front right, V70
28	4/84A:8	Suspension Module (SUM), V70	BN-W	8/21:2	Shock absorber, Four-C, front right, V70
29	4/84A:27	Suspension Module (SUM), V70	BN	7/119:2	Acceleration sensor, shock absorber, Four-C, front right, V70
30	53/570	Branching point, V70	SB	53/355	Branching point, V70
31	53/569	Branching point, V70	R	53/354	Branching point, V70
32	4/84A:22	Suspension Module (SUM), V70	VO	7/88:1	Acceleration sensor, Four-C, front right, V70
33	4/84A:10	Suspension Module (SUM), V70	VO-W	7/87:1	Acceleration sensor, Four-C, front left, V70
34	4/84A:12	Suspension Module (SUM), V70	Y-W	7/118:2	Acceleration sensor, shock absorber, Four-C, front left, V70
35	4/84A:6	Suspension Module (SUM), V70	GN	8/20:1	Shock absorber, Four-C, front left, V70
36	4/84A:7	Suspension Module (SUM), V70	BL-R	8/20:2	Shock absorber, Four-C, front left, V70

Connectors

54/3.2 - 54/8

54/3.2

6-pin gray, LHD

No.	Passenger compartment harness		Engine compartment harness		
1	54/34:1	Connector	GN-GR	11B/15:2 53/396	Fuse in engine compartment fuse box Branching point, 8-cyl.
2	54/34:2	Connector	GN-R	4/46B:23 4/46B:34	Engine Control Module (ECM), 8-cyl. Engine Control Module (ECM)
3	54/34:3	Connector	GN	4/46B:40 4/46B:48	Engine Control Module (ECM) Engine Control Module (ECM), 8-cyl.
4	54/34:4	Connector	BL-SB	4/46B:7 4/46B:33	Engine Control Module (ECM) Engine Control Module (ECM), 8-cyl.
5-6	-	-	-	-	-

54/4

8-pin gray, V70

No.	Engine compartment harness		Front harness		
1	4/56B:15	Central Electronic Module (CEM)	R-SB	16/10:1	Horn 1
2	4/56B:15	Central Electronic Module (CEM)	R-SB	16/11:1	Horn 2
3	54/3.1:14	Connector	Y	3/62:1	Hood alarm contact
4	53/331	Branching point	SB	53/382	Branching point
5	54/3.1:1	Connector	OR	7/179:1	Front impact sensor, left
6	54/3.1:2	Connector	OR-SB	7/179:2	Front impact sensor, left
7	54/3.1:3	Connector	GN-OR	7/178:1	Front impact sensor, right
8	54/3.1:4	Connector	OR	7/178:2	Front impact sensor, right

54/7

3-pin gray, V70

No.	Engine compartment harness		Bi-Fuel engine harness		
1	4/46B:39	Engine Control Module (ECM)	VO	8/75:1	Valve, fuel cut-off DFCO
2	4/46B:50	Engine Control Module (ECM)	P-SB	6/105:2	Fuel distributor, gas
3	4/46B:32	Engine Control Module (ECM)	W	6/105:1	Fuel distributor, gas

54/8

2-pin gray

No.	Engine compartment harness		Auxiliary light harness		
1	11B/5:2	Fuse in engine compartment fuse box	R-SB	30-feed	-
2	4/56C:9	Central Electronic Module (CEM)	BN-W	Signal ground	-

Connectors

54/9 - 54/10

54/9

6-pin gray

No.	Engine compartment harness			Heater harness		
1	11B/4:2	Fuse in engine compartment fuse box	R	4/7:9	Combustion Preheater Module (CPM)	R
2	54/3.1:17	Connector	Y	9/30	Auxiliary heater	Y
3	53/331	Branching point	BN-SB	4/7:3 9/30	Combustion Preheater Module (CPM) Auxiliary heater	SB
4	4/56B:10	Central Electronic Module (CEM)	VO-W	4/7:15	Combustion Preheater Module (CPM)	VO-W
5	-		-	-		-
6	4/56C:32	Central Electronic Module (CEM)	GN-W	4/7:6	Combustion Preheater Module (CPM)	GN-W

54/10

12-pin black

No.	Passenger compartment harness			Front left door harness		
1	11C/5:2	Fuses in passenger compartment fuse box	R	3/126B:12	Driver/Passenger Door Module (DDM)/(PDM)	R
2	4/56A:8	Central Electronic Module (CEM)	BL-R	6/62:4	Left power exterior rearview mirror	BL-R
3	4/56D:39	Central Electronic Module (CEM)	W	3/126A:2	Driver/Passenger Door Module (DDM)/(PDM)	W
4	4/56D:54	Central Electronic Module (CEM)	GN	3/126A:3	Driver/Passenger Door Module (DDM)/(PDM)	GN
5	54/3.1:7	Connector	W	6/62:2	Left power exterior rearview mirror	OR-W
6	54/3.1:6	Connector	BN	6/62:3	Left power exterior rearview mirror	BN
7	4/56A:12 4/58A:21	Central Electronic Module (CEM), XC90 Rear Electronic Module (REM), XC90	GN-W	10/15:2	Direction indicator, front left fender, XC90	GN
8	4/58C:12	Rear Electronic Module (REM)	P	3/74:3	Left-hand front door lock unit	P
9	16/1B:1 54/14:1 16/105B:9	Audio Module (AUM), V70 Connector, V70 Audio Module (AUD), XC90	GR-R	16/4:1	Left-hand front door speaker	GR-R
10	16/1B:2 54/14:2 16/105B:1	Audio Module (AUM), V70 Connector, V70 Audio Module (AUD), XC90	GR	16/4:2	Left-hand front door speaker	GR
11	31/66	Ground connection	SB	3/126B:5 53/514	Driver/Passenger Door Module (DDM)/(PDM) Branching point	SB
12	4/56D:24 54/11:12	Central Electronic Module (CEM), LHD Connector	GN-W	27/3:5	Left Camera Module (LCM)	GN-W

Connectors

54/11 - 54/12 V70

54/11 12-pin black

No.	Passenger compartment harness			Front right door harness		
1	11C/4:2 Fuses in the passenger compartment fuse box, V70	R	3/127B:12 Passenger/Driver Door Module (PDM)/(DDM)		R	
	11C/6:2 Fuses in the passenger compartment fuse box, XC90					
2	4/56A:8 Central Electronic Module (CEM)	BL-R	6/63:4 Right power exterior rearview mirror		BL-R	
3	53/433 Branching point	W	3/127A:2 Passenger/Driver Door Module (PDM)/(DDM)		W	
4	53/434 Branching point	GN	3/127A:3 Passenger/Driver Door Module (PDM)/(DDM)		GN	
5	-	-	-		-	
6	-	-	-		-	
7	4/56A:29 Central Electronic Module (CEM), XC90 4/58A:20 Rear Electronic Module (REM), XC90	GN	10/16:2 Direction indicator, right front door, XC90		GN-W	
8	54/43:4 Connector	P	3/75:3 Right-hand front door lock unit		P	
9	16/1B:5 Audio Module (AUM), V70 54/14:5 Connector, V70 16/105B:11 Audio Module (AUD), XC90	GR-R	16/3:1 Right-hand front door speaker		GR-R	
10	16/1B:6 Audio Module (AUM), V70 54/14:6 Connector, V70 16/105B:3 Audio Module (AUD), XC90	GR	16/3:2 Right-hand front door speaker		GR	
11	53/501 Branching point	SB	3/127B:5 Passenger/Driver Door Module (PDM)/(DDM) 53/515 Branching point		SB	
12	4/56D:24 Central Electronic Module (CEM), RHD 54/10:12 Connector	GN-W	27/4:5 Right Camera Module (RCM)		GN-W	

54/12 4-pin orange, V70

No.	Passenger compartment harness			Airbag harness		
1	4/9B:12/40 Supplemental Restraint System module (SRS)	OR	8/31:1 Airbag igniter, passenger side		-	
2	4/9B:11/39 Supplemental Restraint System module (SRS)	OR-SB	8/31:2 Airbag igniter, passenger side		-	
3	4/9B:14/42 Supplemental Restraint System module (SRS)	GN-OR	8/32:2 Igniter, airbag stage 2, passenger side		-	
4	4/9B:13/41 Supplemental Restraint System module (SRS)	OR	8/32:1 Igniter, airbag stage 2, passenger side		-	

Connectors

54/12 XC90 - 54/13:1-13

54/12

6-pin orange, XC90

No.	Passenger compartment harness			Airbag harness		
1	4/9B:12/40	Supplemental Restraint System module (SRS)	OR	8/31:1	Airbag igniter, passenger side	-
2	4/9B:11/39	Supplemental Restraint System module (SRS)	OR-SB	8/31:2	Airbag igniter, passenger side	-
3	4/9B:13/41	Supplemental Restraint System module (SRS)	OR	8/32:1	Igniter, airbag stage 2, passenger side	-
4	4/9B:14/42	Supplemental Restraint System module (SRS)	GN-OR	8/32:2	Igniter, airbag stage 2, passenger side	-
5	4/9B:4/32	Supplemental Restraint System module (SRS), USA/CDN	OR	8/124:1	Igniter, airbag stage 3, passenger side, USA/CDN	-
6	4/9B:1/29	Supplemental Restraint System module (SRS), USA/CDN	GR-OR	8/124:2	Igniter, airbag stage 3, passenger side, USA/CDN	-

54/13

22-pin black

No.	Passenger compartment harness			Roof harness		
1	11C/6:2	Fuses in the passenger compartment fuse box, V70	R	53/534	Branching point	R
	11C/12:2	Fuses in the passenger compartment fuse box, XC90				
2	-		-	-		-
3	-		-	-		-
4	-		-	-		-
5	4/56D:38	Central Electronic Module (CEM)	W	4/70:3	Upper Electronic Module (UEM)	W
6	4/56D:53	Central Electronic Module (CEM)	GN	4/70:5	Upper Electronic Module (UEM)	GN
7	-		-	-		-
8	-		-	-		-
9	-		-	-		-
10	-		-	-		-
11	-		-	-		-
12	-		-	-		-
13	-		-	-		-
continues						

Connectors

54/13 - 54/14

54/13 22-pin black

No.	Passenger compartment harness			Roof harness		
14	4/56D:11	Central Electronic Module (CEM)	W	54/16:4	Connector	W
15	54/3.1:15	Connector	P	4/33A:4 4/70:21	Sun Roof Module (SRM) Upper Electronic Module (UEM)	P
16	4/58C:8	Rear Electronic Module (REM), V70	Y	7/136A:1	Right glass breakage coil, V70	Y
17	-		-	-		-
18	-		-	-		-
19	-		-	-		-
20	53/400	Branching point	BN	53/503	Branching point	BN
21	11C/7:2 11C/13:2	Fuses in the passenger compartment fuse box, V70 Fuses in the passenger compartment fuse box, XC90	R	4/33A:1	Sun Roof Module (SRM)	R
22	53/405	Branching point	SB	4/33A:10	Sun Roof Module (SRM)	SB

54/14 12-pin gray, V70

No.	Passenger compartment harness			Audio harness		
1	54/10:9	Connector	GR-R	16/2B:1	Amplifier	GR-R
2	54/10:10	Connector	GR	16/2B:2	Amplifier	GR
3	-		-	-		-
4	-		-	-		-
5	54/11:9	Connector	GR-R	16/2B:5	Amplifier	GR-R
6	54/11:10	Connector	GR	16/2B:6	Amplifier	GR
7	53/523	Branching point	GR-W	16/2B:7	Amplifier	GR-W
8	53/524	Branching point	GR	16/2B:8	Amplifier	GR
9-10	-		-	-		-
11	53/525	Branching point	GR-W	16/2B:11	Amplifier	GR-W
12	53/526	Branching point	GR	16/2B:12	Amplifier	GR

Connectors

54/16 - 54/20

54/16

5-pin green

No.	Roof harness			Rain sensor harness		
1	4/70:13	Upper Electronic Module (UEM)	GN	7/149:1	Rain Sensor Module (RSM)	GN
2	53/503	Branching point	BN	7/149:2	Rain Sensor Module (RSM)	BN
3	53/505	Branching point	VO-W	7/149:3	Rain Sensor Module (RSM)	VO-W
4	54/13:14	Connector	W	7/149:4	Rain Sensor Module (RSM)	W
5	-		-	-		-

54/20

12-pin black

No.	Passenger compartment harness			Rear left door harness		
1	53/523	Branching point	GR-W	16/6:1	Speaker, left rear door	GR-W
2	53/524	Branching point	GR	16/6:2	Speaker, left rear door	GR
3	4/58C:3	Rear Electronic Module (REM)	P	3/76:2	Lock unit, left rear door	P
4	4/58C:5	Rear Electronic Module (REM)	BL	3/76:5	Lock unit, left rear door	BL
5	4/58A:19	Rear Electronic Module (REM)	Y	3/85:1	Power window switch, left rear door	Y
6	4/58A:2	Rear Electronic Module (REM)	BL	3/85:3	Power window switch, left rear door	BL
7	4/58C:10	Rear Electronic Module (REM)	W	3/76:7	Lock unit, left rear door	W
8	4/58A:1	Rear Electronic Module (REM)	GN-BN	3/85:5	Power window switch, left rear door	GN-BN
9	4/58A:27	Rear Electronic Module (REM)	VO	2/138:1 3/76:8	Deadlock relay, left-hand rear door Lock unit, left rear door	VO
10	4/58A:24	Rear Electronic Module (REM)	GR	3/76:6	Lock unit, left rear door	GR
11	4/58A:23	Rear Electronic Module (REM)	Y	3/76:4	Lock unit, left rear door	Y
12	53/500	Branching point	SB	3/76:1 3/85:2	Lock unit, left rear door Power window switch, left rear door	SB

Connectors

54/21 - 54/22:1-7 V70

54/21

12-pin black

No.	Passenger compartment harness			Rear right door harness		
1	53/525	Branching point	GR-W	16/5:1	Speaker, right rear door	GR-W
2	53/526	Branching point	GR	16/5:2	Speaker, right rear door	GR
3	54/43:5	Connector	P	3/77:2	Lock unit, right rear door	P
4	54/43:11	Connector	BL	3/77:5	Lock unit, right rear door	BL
5	54/43:7	Connector	Y	3/86:1	Power window switch, right rear door	Y
6	54/43:1	Connector	BL	3/86:3	Power window switch, right rear door	BL
7	54/43:14	Connector	W	3/77:7	Lock unit, right rear door	W
8	54/43:8	Connector	GN-BN	3/86:5	Power window switch, right rear door	GN-BN
9	54/43:6	Connector	VO	2/139:1 3/77:8	Deadlock relay, right-hand rear door Lock unit, right rear door	VO
10	54/43:3	Connector	GR	3/77:6	Lock unit, right rear door	GR
11	54/43:2	Connector	Y	3/77:4	Lock unit, right rear door	Y
12	53/501	Branching point	SB	3/77:1 3/86:2	Lock unit, right rear door Power window switch, right rear door	SB

54/22

12-pin black, V70

No.	Engine compartment harness			Front left lamp housing harness		
1	53/398	Branching point	VO	6/38:3 10/1A:7	Motor, left headlight adjustment Lamp housing, front left	BL
2	4/56C:19	Central Electronic Module (CEM)	W	10/1A:3 10/71:1	Lamp housing, front left Side running light, front left	GR
3	4/56B:7	Central Electronic Module (CEM)	BL-W	10/1A:2	Lamp housing, front left	BL-Y
4	4/56B:8	Central Electronic Module (CEM)	BL-GN	10/1A:6	Lamp housing, front left	BL-GN
5	4/56C:1	Central Electronic Module (CEM)	GR-W	10/1A:5	Lamp housing, front left	GN
6	4/56C:12	Central Electronic Module (CEM)	GN-R	6/38:2	Motor, left headlight adjustment	GN-R
7	4/56B:27	Central Electronic Module (CEM)	BL	10/1A:1	Lamp housing, front left	W
continues						

Connectors

54/22:8-12 V70 - 54/22 XC90

54/22

12-pin black, V70

No.	Engine compartment harness			Front left lamp housing harness		
8	-	-	-	-	-	-
9	4/56B:31	Central Electronic Module (CEM)	GN	10/13:1	Direction indicator, front left	GN
10	53/301	Branching point	SB	6/38:1 10/1A:4 10/13:2 10/71:2	Motor, left headlight adjustment Lamp housing, front left Direction indicator, front left Side running light, front left	SB
11	-	-	-	-	-	-
12	-	-	-	-	-	-

54/22

10-pin black, XC90

No.	Engine compartment harness			Front left lamp housing harness		
1	4/56B:27	Central Electronic Module (CEM)	BL	10/1A:1	Lamp housing, front left	SB
2	4/56B:7	Central Electronic Module (CEM)	BL-W	10/1A:2	Lamp housing, front left	SB
3	4/56C:19	Central Electronic Module (CEM)	W	10/11:1 10/71:1	Running/parking light, front left Side running light, front left	SB
4	53/301	Branching point	SB	6/38:1 10/1A:4 10/11:2 10/13:2 10/71:2	Motor, left headlight adjustment Lamp housing, front left Running/parking light, front left Direction indicator, front left Side running light, front left	SB
5	4/56C:1	Central Electronic Module (CEM)	GR	10/1A:5	Lamp housing, front left	SB
6	4/56B:8	Central Electronic Module (CEM)	BL-GN	10/1A:6	Lamp housing, front left	SB
7	53/398	Branching point	VO	6/38:3 10/1A:3	Motor, left headlight adjustment Lamp housing, front left	SB
8	4/56C:12	Central Electronic Module (CEM)	GN-R	6/38:2	Motor, left headlight adjustment	SB
9	4/56B:31	Central Electronic Module (CEM)	GN	10/13:1	Direction indicator, front left	SB
10	-	-	-	-	-	-

Connectors

54/23 V70

54/23

12-pin black, V70

No.	Engine compartment harness			Front right lamp housing harness		
1	53/398	Branching point	VO	6/39:3 10/2A:7	Motor, right headlight adjustment Lamp housing, front right	BL
2	4/56C:20	Central Electronic Module (CEM)	GR	10/2A:3 10/73:1	Lamp housing, front right Side running light, front right	GR
3	4/56B:4	Central Electronic Module (CEM)	BL-Y	10/2A:2	Lamp housing, front right	BL-Y
4	4/56B:9	Central Electronic Module (CEM)	BL-P	10/2A:6	Lamp housing, front right	BL-GN
5	4/56C:2	Central Electronic Module (CEM)	GN	10/2A:5	Lamp housing, front right	GN
6	4/56C:11	Central Electronic Module (CEM)	GN-BN	6/39:2	Motor, right headlight adjustment	GN-R
7	4/56B:28	Central Electronic Module (CEM)	W	10/2A:1	Lamp housing, front right	W
8	-	-	-	-	-	-
9	4/56B:32	Central Electronic Module (CEM)	GN-W	10/14:1	Direction indicator, front right	GN
10	53/303	Branching point	SB	6/39:1 10/2A:4 10/14:2 10/73:2	Motor, right headlight adjustment Lamp housing, front right Direction indicator, front right Side running light, front right	SB
11	-	-	-	-	-	-
12	-	-	-	-	-	-

Connectors

54/23 XC90 - 54/24:1-5

54/23

10-pin black, XC90

No.	Engine compartment harness			Front right lamp housing harness		
1	4/56B:28	Central Electronic Module (CEM)	W	10/2A:1	Lamp housing, front right	SB
2	4/56B:4	Central Electronic Module (CEM)	BL-Y	10/2A:2	Lamp housing, front right	SB
3	4/56C:20	Central Electronic Module (CEM)	GR	10/12:1 10/73:1	Running/parking light, front right Side running light, front right	SB
4	53/303	Branching point	SB	6/39:1 10/2A:4 10/12:2 10/14:2 10/73:2	Motor, right headlight adjustment Lamp housing, front right Running/parking light, front right Direction indicator, front right Side running light, front right	SB
5	4/56C:2	Central Electronic Module (CEM)	GN	10/2A:5	Lamp housing, front right	SB
6	4/56B:9	Central Electronic Module (CEM)	BL-P	10/2A:6	Lamp housing, front right	SB
7	53/398	Branching point	VO	6/39:3 10/2A:3	Motor, right headlight adjustment Lamp housing, front right	SB
8	4/56C:11	Central Electronic Module (CEM)	GN-BN	6/39:2	Motor, right headlight adjustment	SB
9	4/56B:32	Central Electronic Module (CEM)	GN-W	10/14:1	Direction indicator, front right	SB
10	-	-	-	-	-	-

54/24

20-pin black

No.	Passenger compartment harness			Front left seat harness		
1	53/500	Branching point	SB	9/12A:1	Seat Heating Module (SHM), left-hand	-
2	4/56A:19	Central Electronic Module (CEM)	BL	9/12A:4	Seat Heating Module (SHM), left-hand	-
3	-	-	-	-	-	-
4	54/132:2	Connector	GN-W	9/12A:2	Seat Heating Module (SHM), left-hand	-
5	4/56D:10	Central Electronic Module (CEM), XC90 USA/CDN	OR-W	3/255:1	Driver's seat position sensor, XC90 USA/CDN	-
continues						

Connectors

54/24:6-20

54/24

20-pin black

No.	Passenger compartment harness			Front left seat harness		
6	4/56D:25	Central Electronic Module (CEM), XC90 USA/CDN	OR-SB	3/255:2	Driver's seat position sensor, XC90 USA/CDN	-
7	4/9A:4/4	Supplemental Restraint System module (SRS)	OR	8/51:1	Front left side airbag igniter	BL
8	4/9A:3/3	Supplemental Restraint System module (SRS)	BL-OR	8/51:2	Front left side airbag igniter	BN
9	16/60:5	Phone Module (PHM), V70 LHD	GR-R	16/78:1	Cellular phone speaker, V70 LHD	-
10	16/60:4	Phone Module (PHM), V70 LHD	GR	16/78:2	Cellular phone speaker, V70 LHD	-
11	4/56D:51	Central Electronic Module (CEM), LHD	GN	4/52B:3	Power Seat Module (PSM), LHD	GN
	4/56D:27	Central Electronic Module (CEM), XC90 RHD	Y	7/175:1	Passenger seat weight sensor, seat belt reminder, XC90 RHD	Y
12	4/56D:36	Central Electronic Module (CEM), LHD	W	4/52B:2	Power Seat Module (PSM), LHD	W
	4/56D:28	Central Electronic Module (CEM), XC90 RHD	VO	7/175:2	Passenger seat weight sensor, seat belt reminder, XC90 RHD	VO
13	53/500	Branching point	SB	8/51	Front left side airbag igniter	SB
14	4/56A:22	Central Electronic Module (CEM), RHD	VO	3/27:3	Switch unit, power passenger seat, RHD	GN-R
	53/437	Branching point, LHD	VO-W	4/52B:1	Power Seat Module (PSM), LHD	
15	11C/1:2	Fuses in the passenger compartment fuse box, V70 LHD	R	4/52A:1	Power Seat Module (PSM), V70 LHD	BL-R
	11C/2:2	Fuses in the passenger compartment fuse box, V70 RHD		3/27:1	Switch unit, power passenger seat, V70 RHD	
	11C/3:2	Fuses in the passenger compartment fuse box, XC90 LHD		4/52A:1	Power Seat Module (PSM), XC90 LHD	
	11C/4:2	Fuses in the passenger compartment fuse box, XC90 RHD		3/27:1	Switch unit, power passenger seat, XC90 RHD	
16	53/500	Branching point	SB	3/27:2	Switch unit, power passenger seat, RHD	SB
				4/52A:2	Power Seat Module (PSM), LHD	
				4/52B:4	Power Seat Module (PSM), LHD	
17	4/9A:25/25	Supplemental Restraint System module (SRS)	VO	3/93:1	Belt buckle contact, left seat	-
18	4/9A:26/26	Supplemental Restraint System module (SRS)	OR-SB	3/93:2	Belt buckle contact, left seat	-
19	-		-	-		-
20	-		-	-		-

Connectors

54/25:1-14

54/25

20-pin black

No.	Passenger compartment harness		Front right seat harness		
1	53/501	Branching point	SB	9/13A:1	Seat Heating Module (SHM), right-hand
2	4/56A:18	Central Electronic Module (CEM)	BL	9/13A:4	Seat Heating Module (SHM), right-hand
3	-	-	-	-	-
4	54/132:5	Connector	GN-W	9/13A:2	Seat Heating Module (SHM), right-hand
5	4/56D:18	Central Electronic Module (CEM), XC90 USA/CDN	GN-OR	3/256:1	Passenger seat position sensor, XC90 USA/CDN
6	4/56D:26	Central Electronic Module (CEM), XC90 USA/CDN	BL-OR	3/256:2	Passenger seat position sensor, XC90 USA/CDN
7	4/9C:4/60	Supplemental Restraint System module (SRS)	OR	8/52:1	Front right side airbag igniter
8	4/9C:3/59	Supplemental Restraint System module (SRS)	BL-OR	8/52:2	Front right side airbag igniter
9	16/60:5	Phone Module (PHM), V70 RHD	GR-R	16/78:1	Cellular phone speaker, V70 RHD
10	4/9C:1/57	Supplemental Restraint System module (SRS), USA/CDN	GN-W	7/93:E	Occupant Weight Sensor (OWS), USA/CDN
	16/60:4	Phone Module (PHM), V70 RHD	GR	16/78:2	Cellular phone speaker, V70 RHD
11	4/56D:51	Central Electronic Module (CEM), RHD	GN	4/52B:3	Power Seat Module (PSM), RHD
	4/56D:27	Central Electronic Module (CEM), XC90 LHD	Y	7/175:1	Passenger seat weight sensor, seat belt reminder, XC90 LHD
12	4/56D:36	Central Electronic Module (CEM), RHD	W	4/52B:2	Power Seat Module (PSM), RHD
	4/56D:28	Central Electronic Module (CEM), XC90 LHD	VO	7/175:2	Passenger seat weight sensor, seat belt reminder, XC90 LHD
13	53/501	Branching point	SB	8/52	Front right side airbag igniter
14	4/56A:22	Central Electronic Module (CEM), LHD	VO	3/27:3	Switch unit, power passenger seat, LHD
	53/437	Branching point, RHD	VO-W	4/52B:1	Power Seat Module (PSM), RHD

continues

Connectors

54/25:15-20 - 54/32

54/25

20-pin black

No.	Passenger compartment harness			Front right seat harness		
15	11C/1:2 11C/2:2 11C/3:2 11C/4:2	Fuses in the passenger compartment fuse box, V70 RHD Fuses in the passenger compartment fuse box, V70 LHD Fuses in the passenger compartment fuse box, XC90 RHD Fuses in the passenger compartment fuse box, XC90 LHD	R	4/52A:1 3/27:1 4/52A:1 3/27:1	Power Seat Module (PSM), V70 RHD Switch unit, power passenger seat, V70 LHD Power Seat Module (PSM), XC90 RHD Switch unit, power passenger seat, XC90 LHD	BL-R
16	53/501	Branching point	SB	3/27:2 4/52A:2 4/52B:4	Switch unit, power passenger seat, LHD Power Seat Module (PSM), RHD Power Seat Module (PSM), RHD	SB
17	4/9C:25/81	Supplemental Restraint System module (SRS)	VO	3/94:1	Belt buckle contact, right seat	-
18	4/9C:26/82	Supplemental Restraint System module (SRS)	OR-SB	3/94:2	Belt buckle contact, right seat	-
19	31/67	Ground connection, USA/CDN	BN	7/93:D	Occupant Weight Sensor (OWS), USA/CDN	-
20	53/437	Branching point, USA/CDN	VO-W	7/93:G	Occupant Weight Sensor (OWS), USA/CDN	-

54/32

3-pin gray

No.	Passenger compartment harness			Rear left angle sensor harness		
1	4/58C:11	Rear Electronic Module (REM)	GN-R	7/120:5	Rear left angle sensor, Four-C/Bi-Xenon	BL-R
2	4/58C:6	Rear Electronic Module (REM)	GR	7/120:4	Rear left angle sensor, Four-C/Bi-Xenon	GR-W
3	4/58C:9	Rear Electronic Module (REM)	BN-W	7/120:1	Rear left angle sensor, Four-C/Bi-Xenon	BN

Connectors

54/34 - 54/36

54/34

4-pin gray

No.	Passenger compartment harness		Fuel leakage pump harness		
1	54/3.2:1	Connector	GN-GR	6/67:4	Pump, fuel leakage control
2	54/3.2:2	Connector	GN-R	6/67:2	Pump, fuel leakage control
3	54/3.2:3	Connector	GN	6/67:3	Pump, fuel leakage control
4	54/3.2:4	Connector	BL-SB	6/67:1	Pump, fuel leakage control

54/35

4-pin gray

No.	Cargo compartment harness		Heated fuel filter harness		
1-2	-	-	-	-	-
3	4/58B:15	Rear Electronic Module (REM)	BL	8/85:1	Thermostatic switch and fuel filter heating
4	53/604	Branching point	SB	8/85:2	Thermostatic switch and fuel filter heating

54/36

6-pin gray

No.	Passenger compartment harness		Fuel tank harness		
1	4/56D:44	Central Electronic Module (CEM)	BL	6/33:4 6/33:A 6/33:P	Fuel pump Fuel pump Fuel pump
2	4/56D:45	Central Electronic Module (CEM)	BN	6/33:3 6/33:B 6/33	Fuel pump Fuel pump Fuel pump
3	4/56D:43	Central Electronic Module (CEM)	GN	6/33:2 6/33:E	Fuel pump Fuel pump
4	31/48	Ground connection	SB	53/579 4/83:3 6/33	Branching point Control module fuel pump Fuel pump
5	4/56A:16	Central Electronic Module (CEM)	BL	53/578 4/83:2 6/33	Branching point Control module fuel pump Fuel pump
6	54/3.1:8	Connector	Y	4/83:1	Control module fuel pump

Connectors

54/39 - 54/40C

54/39

4-pin orange, V70

No.	Passenger compartment harness			Belt tensioner harness		
1	4/9C:16/72	Supplemental Restraint System module (SRS)	OR	8/56:1	Igniter, right rear belt tensioner	OR
2	4/9C:15/71	Supplemental Restraint System module (SRS)	BL-OR	8/56:2	Igniter, right rear belt tensioner	BL-OR
3	4/9C:24/80	Supplemental Restraint System module (SRS)	OR	8/62:1	Belt tensioner igniter, center rear seat	OR
4	4/9C:23/79	Supplemental Restraint System module (SRS)	GN-OR	8/62:2	Belt tensioner igniter, center rear seat	GN-OR

54/40B

8-pin gray, XC90

No.	Passenger compartment harness			Cargo compartment harness	
1	4/9A:22/22	Supplemental Restraint System module (SRS)	OR-SB	8/66:2	Igniter, left inflatable curtain
2	4/9A:21/21	Supplemental Restraint System module (SRS)	OR	8/66:1	Igniter, left inflatable curtain
3	4/9A:11/11	Supplemental Restraint System module (SRS)	GN-OR	8/94:2	Left-hand belt tensioner igniter, third row of seats
4	4/9A:12/12	Supplemental Restraint System module (SRS)	OR	8/94:1	Left-hand belt tensioner igniter, third row of seats
5	4/9A:13/13	Supplemental Restraint System module (SRS)	BL-OR	8/96:2	Left-hand inflatable curtain igniter, third row of seats
6	4/9A:14/14	Supplemental Restraint System module (SRS)	OR	8/96:1	Left-hand inflatable curtain igniter, third row of seats
7-8	-	-	-	-	-

54/40C

2-pin black

No.	Passenger compartment harness			Cargo compartment harness	
1	53/415	Branching point	R	11E/6:2	Main fuses at battery
2	53/403	Branching point	R	11E/7:2	Main fuses at battery

Connectors

54/40D - 54/43

54/40D 2-pin black

No.	Passenger compartment harness			Cargo compartment harness		
1	4/56E:B	Central Electronic Module (CEM)	R	11E/4:2	Main fuses at battery	R
2	4/56E:A	Central Electronic Module (CEM)	R	11E/5:2	Main fuses at battery	R

54/43 14-pin gray

No.	Passenger compartment harness			Cargo compartment harness		
1	54/21:6	Connector	BL	4/58B:2	Rear Electronic Module (REM)	BL
2	54/21:11	Connector	Y	6/37:2	Lock motor, fuel filler flap	Y
3	54/21:10	Connector	GR	4/58B:12	Rear Electronic Module (REM)	GR
4	54/11:8	Connector	P	4/58D:29	Rear Electronic Module (REM)	P
5	54/21:3	Connector	P	4/58D:33	Rear Electronic Module (REM)	P
6	54/21:9	Connector	VO	4/58B:24	Rear Electronic Module (REM)	VO
7	54/21:5	Connector	Y	4/58B:30	Rear Electronic Module (REM)	Y
8	54/21:8	Connector	GN-BN	4/58B:1	Rear Electronic Module (REM)	GN-BN
9	53/525	Branching point	GR-W	16/58:1 53/652	Speaker, right-hand D-pillar Branching point, V70	GR-W
10	53/526	Branching point	GR	16/58:2 53/653	Speaker, right-hand D-pillar Branching point, V70	GR
11	54/21:4	Connector	BL	4/58D:28	Rear Electronic Module (REM)	BL
12	53/524	Branching point	GR	16/57:2 53/655	Speaker, left-hand D-pillar Branching point, V70	GR
13	53/523	Branching point	GR-W	16/57:1 53/654	Speaker, left-hand D-pillar Branching point, V70	GR-W
14	54/21:7	Connector	W	4/58D:4	Rear Electronic Module (REM)	W

Connectors

54/43B - 54/53

54/43B 8-pin gray, XC90

No.	Passenger compartment harness			Cargo compartment harness		
1	4/9C:21/77	Supplemental Restraint System module (SRS)	OR	8/67:1	Igniter, right inflatable curtain	OR
2	4/9C:22/78	Supplemental Restraint System module (SRS)	OR-SB	8/67:2	Igniter, right inflatable curtain	OR-W
3	4/9C:13/69	Supplemental Restraint System module (SRS)	OR	8/95:1	Right-hand belt tensioner igniter, third row of seats	OR
4	4/9C:14/70	Supplemental Restraint System module (SRS)	OR-W	8/95:2	Right-hand belt tensioner igniter, third row of seats	OR-W
5	4/9C:11/67	Supplemental Restraint System module (SRS)	OR	8/97:1	Right-hand inflatable curtain igniter, third row of seats	OR
6	4/9C:12/68	Supplemental Restraint System module (SRS)	GR-OR	8/97:2	Right-hand inflatable curtain igniter, third row of seats	GR-OR
7-8	-		-	-		-

54/50 2-pin gray

No.	Cargo compartment harness			Tailgate harness		
1	53/601	Branching point	SB	6/32:3 9/2C:1 6/32:3 9/2C:1	Rear window wiper motor, V70 Heated rear window, V70 Rear window wiper motor, XC90 Heated rear window, XC90	SB SB W W
2	-		-	-		-

54/53 4-pin gray

No.	Engine harness, 5-cyl. T & 6-cyl.			Knock sensor harness		
1	4/46A:46	Engine Control Module (ECM)	BN-SB	7/24:1	Front knock sensor	-
2	4/46A:64	Engine Control Module (ECM)	SB	7/24:2	Front knock sensor	-
3	4/46A:45	Engine Control Module (ECM)	BN	7/23:1	Rear knock sensor	-
4	4/46A:67	Engine Control Module (ECM)	Y-SB	7/23:2	Rear knock sensor	-

Connectors

54/54 - 54/56

54/54

8-pin gray, V70

No.	Cargo compartment harness			Fuel tank harness, Bi-Fuel		
1	4/58D:14	Rear Electronic Module (REM)	GR-R	7/156:1	Pressure and temperature sensor, Bi-Fuel	GR-R
2	4/58D:15	Rear Electronic Module (REM)	VO	7/156:2	Pressure and temperature sensor, Bi-Fuel	VO
3	4/58D:27	Rear Electronic Module (REM)	Y	7/156:3	Pressure and temperature sensor, Bi-Fuel	Y
4	4/58D:8	Rear Electronic Module (REM)	Y-GR	7/156:4	Pressure and temperature sensor, Bi-Fuel	Y-GR
5-6	-		-	-		-
7	54/106:1	Connector	Y-R	8/88:1	Solenoid, fuel tank, Bi-Fuel, rear	Y-R
8	53/604	Branching point	SB	8/88:2	Solenoid, fuel tank, Bi-Fuel, rear	SB

54/55

3-pin black, RHD

No.	Engine compartment harness			Brake pressure sensor harness		
1	4/16:19	Brake Control Module (BCM)	GN-BN	7/129:1	Brake pressure sensor 2	BN
2	4/16:20	Brake Control Module (BCM)	GN-W	7/129:2	Brake pressure sensor 2	W
3	4/16:18	Brake Control Module (BCM)	GR-W	7/129:3	Brake pressure sensor 2	GR

54/56

3-pin black, RHD

No.	Engine compartment harness			Brake pressure sensor harness		
1	4/16:21	Brake Control Module (BCM)	BL-BN	7/139:1	Brake pressure sensor 1	BN
2	4/16:23	Brake Control Module (BCM)	OR-W	7/139:2	Brake pressure sensor 1	W
3	4/16:22	Brake Control Module (BCM)	GR-OR	7/139:3	Brake pressure sensor 1	GR

Connectors

54/57.1 - 54/74

54/57.1 8-pin gray, I5D

No.	Automatic transmission harness			Engine compartment harness		
1	4/28A:1	Transmission Control Module (TCM)	R	11B/8:2	Fuse in engine compartment fuse box	R
2	-		-	-		-
3	4/28A:7	Transmission Control Module (TCM)	GN-W	54/3.1:5	Connector	GN-W
4	4/28A:11	Transmission Control Module (TCM)	BL-R	4/56C:13	Central Electronic Module (CEM)	BL-R
5	4/28A:5	Transmission Control Module (TCM)	Y	4/46B:34	Engine Control Module (ECM)	Y
6	4/28A:6	Transmission Control Module (TCM)	GN	53/353	Branching point	GN
7	4/28A:14	Transmission Control Module (TCM)	W	53/352	Branching point	W
8	4/28A:9	Transmission Control Module (TCM)	SB	53/329	Branching point	SB

54/66.1 2-pin gray, XC90

No.	Cargo compartment harness			Subwoofer harness		
1	31/73	Ground connection	SB	16/79A:1	Subwoofer Module (SUB)	SB
2	4/58B:19	Rear Electronic Module (REM)	R-W	16/79A:3	Subwoofer Module (SUB)	RW

54/66.2 2-pin black, XC90

No.	Cargo compartment harness			Subwoofer harness		
1	54/109:2	Connector	OR	16/79B:1	Subwoofer Module (SUB)	OR
2	16/110B:1	Antenna module (ATM)	OR	16/79B:2	Subwoofer Module (SUB)	OR

54/74 4-pin, yellow

No.	Passenger compartment harness			Differential Electronic Module (DEM) harness		
1	4/56D:47	Central Electronic Module (CEM) 53/568 Branching point, V70	GN	53/513	Branching point	GN
2	54/3.1:12	Connector	GN	53/513	Branching point	GN
3	4/56D:32	Central Electronic Module (CEM) 53/567 Branching point, V70	W	53/512	Branching point	W
4	54/3.1:11	Connector	W	53/512	Branching point	W

Connectors

54/74B - 54/106

54/74B
2-pin orange

No.	Passenger compartment harness		Differential Electronic Module (DEM) harness		
1	4/58A:14	Rear Electronic Module (REM)	BL	53/502	Branching point
2	31/46	Ground connection	SB	53/535 53/582	Branching point Branching point

54/98
5-pin green, XC90

No.	Cargo compartment harness		Rear seat entertainment harness		
1	4/58B:8	Rear Electronic Module (REM)	R-W	30-feed	-
2	4/58D:34	Rear Electronic Module (REM)	VO	X-feed	-
3	10/18A:4	Lamp housing, rear left	BL	Reversing lights	-
4	-		-	-	-
5	53/604	Branching point	SB	Ground connection	-

54/100
2-pin black

No.	I5D engine harness		Impulse sensor harness		
1	4/46A:77	Engine Control Module (ECM)	GR-R	7/25:1	Impulse sensor
2	4/46A:53	Engine Control Module (ECM)	GR	7/25:2	Impulse sensor

54/106
4-pin gray, V70

No.	Cargo compartment harness		Front fuel tank harness, Bi-Fuel		
1	4/58B:25 54/54:7	Rear Electronic Module (REM) Connector	Y-R	8/89:1 8/90:1	Solenoid, fuel tank, Bi-Fuel, frontleft Solenoid, fuel tank, Bi-Fuel, front right
2	53/604	Branching point	SB	8/89:2 8/90:2	Solenoid, fuel tank, Bi-Fuel, front left Solenoid, fuel tank, Bi-Fuel, front right
3	-		-	-	-
4	-		-	-	-

Connectors

54/107 - 54/112

54/107

10-pin gray, V70

No.	Passenger compartment harness			Rear Four-C harness		
1	4/84A:5	Suspension Module (SUM)	GN-GR	8/23:1	Shock absorber, Four-C, rear right	GN-GR
2	4/84A:4	Suspension Module (SUM)	W	8/23:2	Shock absorber, Four-C, rear right	W
3	4/84A:23	Suspension Module (SUM)	GR	7/120:1 7/121:1	Rear left angle sensor, Four-C/Bi-Xenon Rear right angle sensor, Four-C	GR
4	4/84A:14	Suspension Module (SUM)	Y	7/121:4	Rear right angle sensor, Four-C	Y
5	53/569	Branching point	R	7/121:5	Rear right angle sensor, Four-C	P
6	4/84A:25	Suspension Module (SUM)	R-W	7/120:5	Rear left angle sensor, Four-C/Bi-Xenon	R-W
7	4/84A:28	Suspension Module (SUM)	Y-R	7/120:4	Rear left angle sensor, Four-C/Bi-Xenon	Y-R
8	4/84A:2	Suspension Module (SUM)	GN-GR	8/22:1	Shock absorber, Four-C, rear left	GN-GR
9	4/84A:1	Suspension Module (SUM)	BL	8/22:2	Shock absorber, Four-C, rear left	BL
10	-		-	-		-

54/109

2-pin black, XC90

No.	Passenger compartment harness			Cargo compartment harness	
1	16/94C:1	Infotainment Control Module (ICM)	OR	16/110B:2 Antenna module (ATM)	
2	16/105D:2	Audio Module (AUD)	OR	16/110B:1 Antenna module (ATM) 54/66.2:1 Connector	

54/112

4-pin gray, XC90

No.	Passenger compartment harness			Infotainment harness	
1	53/452	Branching point	VO-W	30-feed	
2	53/454	Branching point	VO	Extended D-feed	
3	-		-	-	
4	53/438	Branching point	BN	Ground connection	

Connectors

54/113 - 54/132

54/113 2-pin black, XC90

No.	Engine compartment harness		Front left impact sensor harness		
1	54/3.1:1	Connector	OR	7/179:1	Front impact sensor, left
2	54/3.1:2	Connector	OR-SB	7/179:2	Front impact sensor, left

54/117 2-pin orange, XC90

No.	Passenger compartment harness		Belt tensioner harness		
1	4/9C:24/80	Supplemental Restraint System module (SRS)	OR	8/62:1	Belt tensioner igniter, center rear seat
2	4/9C:23/79	Supplemental Restraint System module (SRS)	GN-OR	8/62:2	Belt tensioner igniter, center rear seat

54/122 2-pin black, XC90

No.	Passenger compartment harness		Front right impact sensor harness		
1	54/3.1:3	Connector	GN-OR	7/178:1	Front impact sensor, right
2	54/3.1:4	Connector	OR	7/178:2	Front impact sensor, right

54/132 6-pin gray

No.	Passenger compartment harness		Climate control system harness		
1	53/437	Branching point	VO-W	53/458	Branching point
2	3/112A:12 54/24:4	Climate Control Module (CCM) Connector	GN-W	53/461	Branching point
3	3/112A:5	Climate Control Module (CCM)	VO	7/41:4	Temperature sensor evaporator
4	3/112A:13	Climate Control Module (CCM)	BN	7/41:3	Temperature sensor evaporator
5	3/112A:7 54/25:4	Climate Control Module (CCM) Connector	GN-W	53/460 6/96:2	Branching point Damper Motor Module (DMM), temperature, right side, RHD MCC
6	53/438	Branching point	BN	53/459	Branching point
					BL

Connectors

54/274

54/274

10-pin gray, XC90

No.	Screen harness		Rear seat entertainment (RSE) harness		
1	54/276:1	Connector	W	16/124:1	Rear Seat Entertainment module (RSE)
2	54/276:2	Connector	BN	16/124:2	Rear Seat Entertainment module (RSE)
3	54/276:3	Connector	GN	16/124:3	Rear Seat Entertainment module (RSE)
4	54/276:4	Connector	Y	16/124:4	Rear Seat Entertainment module (RSE)
5	54/276:5	Connector	GR	16/124:5	Rear Seat Entertainment module (RSE)
6	54/276:6	Connector	P	16/124:6	Rear Seat Entertainment module (RSE)
7	54/276:7	Connector	BL	16/124:7	Rear Seat Entertainment module (RSE)
8	54/276:8	Connector	R	16/124:8	Rear Seat Entertainment module (RSE)
9	54/276:9	Connector	SB	16/124:9	Rear Seat Entertainment module (RSE)
10	54/276:10	Connector	VO	16/124:10	Rear Seat Entertainment module (RSE)

Connectors

54/275 - 54/276

54/275 10-pin gray, XC90

No.	Screen harness		Rear seat entertainment (RSE) harness		
1	54/277:1	Connector	W	16/124:11	Rear Seat Entertainment module (RSE)
2	54/277:2	Connector	BN	16/124:12	Rear Seat Entertainment module (RSE)
3	54/277:3	Connector	GN	16/124:13	Rear Seat Entertainment module (RSE)
4	54/277:4	Connector	Y	16/124:14	Rear Seat Entertainment module (RSE)
5	54/277:5	Connector	GR	16/124:15	Rear Seat Entertainment module (RSE)
6	54/277:6	Connector	P	16/124:16	Rear Seat Entertainment module (RSE)
7	54/277:7	Connector	BL	16/124:17	Rear Seat Entertainment module (RSE)
8	54/277:8	Connector	R	16/124:18	Rear Seat Entertainment module (RSE)
9	54/277:9	Connector	SB	16/124:19	Rear Seat Entertainment module (RSE)
10	54/277:10	Connector	VO	16/124:20	Rear Seat Entertainment module (RSE)

54/276 10-pin gray, XC90

No.	Screen		Screen harness		
1	16/81A:1	Screen, LH head restraint	W	54/274:1	Connector
2	16/81A:2	Screen, LH head restraint	BN	54/274:2	Connector
3	16/81A:3	Screen, LH head restraint	GN	54/274:3	Connector
4	16/81A:4	Screen, LH head restraint	Y	54/274:4	Connector
5	16/81A:5	Screen, LH head restraint	GR	54/274:5	Connector
6	16/81A:6	Screen, LH head restraint	P	54/274:6	Connector
7	16/81A:7	Screen, LH head restraint	BL	54/274:7	Connector
8	16/81A:8	Screen, LH head restraint	R	54/274:8	Connector
9	16/81A:9	Screen, LH head restraint	SB	54/274:9	Connector
10	16/81A:10	Screen, LH head restraint	VO	54/274:10	Connector

Connectors

54/277 - 54/303

54/277 10-pin gray, XC90

No.	Screen		Screen harness		
1	16/81B:1	Screen, LH head restraint	W	54/275:1	Connector
2	16/81B:2	Screen, LH head restraint	BN	54/275:2	Connector
3	16/81B:3	Screen, LH head restraint	GN	54/275:3	Connector
4	16/81B:4	Screen, LH head restraint	Y	54/275:4	Connector
5	16/81B:5	Screen, LH head restraint	GR	54/275:5	Connector
6	16/81B:6	Screen, LH head restraint	P	54/275:6	Connector
7	16/81B:7	Screen, LH head restraint	BL	54/275:7	Connector
8	16/81B:8	Screen, LH head restraint	R	54/275:8	Connector
9	16/81B:9	Screen, LH head restraint	SB	54/275:9	Connector
10	16/81B:10	Screen, LH head restraint	VO	54/275:10	Connector

54/303 3-pin gray, XC90

No.	Rear seat entertainment harness		Fuses in cargo compartment auxiliary fuse box		
1	2/237:1	Disconnect relay, rear speaker	BL	54/98:3	Connector
2	16/124(CN2)B:1	Rear Seat Entertainment module (RSE)	VO	11F/2:2	Fuses in cargo compartment auxiliary fuse box
3	53/728	Branching point	R	11F/1:2	Fuses in cargo compartment auxiliary fuse box

Connectors

54/1300 - 54/1400

54/1300

6-pin gray

No.	PAM harness, engine compartment		PAM harness, bumper	
1	54/1400:1 Connector	BL	7/204:1 Front parking assistance sensor 5 7/205:1 Front parking assistance sensor 6 7/206:1 Front parking assistance sensor 7 7/207:1 Front parking assistance sensor 8	BL
2	54/1400:2 Connector	GN	7/207:2 Front parking assistance sensor 8	GN
3	54/1400:3 Connector	VO	7/206:2 Front parking assistance sensor 7	VO
4	54/1400:4 Connector	Y	7/205:2 Front parking assistance sensor 6	Y
5	54/1400:5 Connector	W	7/204:2 Front parking assistance sensor 5	W
6	54/1400:6 Connector	SB	7/204:3 Front parking assistance sensor 5 7/205:3 Front parking assistance sensor 6 7/206:3 Front parking assistance sensor 7 7/207:3 Front parking assistance sensor 8	SB

54/1400


6-pin gray

No.	PAM harness, passenger compartment		PAM harness, engine compartment	
1	4/86B:2 Parking Assistance Module (PAM)	BL	54/1300:1 Connector	BL
2	4/86B:8 Parking Assistance Module (PAM)	GN	54/1300:2 Connector	GN
3	4/86B:7 Parking Assistance Module (PAM)	VO	54/1300:3 Connector	VO
4	4/86B:6 Parking Assistance Module (PAM)	Y	54/1300:4 Connector	Y
5	4/86B:5 Parking Assistance Module (PAM)	W	54/1300:5 Connector	W
6	4/86B:1 Parking Assistance Module (PAM)	SB	54/1300:6 Connector	SB


Branching points

53/301 - 53/314


53/301




53/304 8-cyl.




53/302




53/305




53/303




53/309




53/304 5-cyl. normally aspirated




53/309 8-cyl.



53/304 5-cyl. T/6-cyl.




53/314




Branching points

53/315 - 53/331 V70


53/315




53/315 8-cyl.




53/319




53/323




53/324




53/326




53/328




53/328 8-cyl.



53/329




53/331 V70




Branching points

53/331 XC90 - 53/360


53/331 XC90




53/353




53/332




53/354




53/335




53/355




53/335 I5D




53/359



53/352




53/360




Branching points

53/360 8-cyl. - 53/374


53/360 8-cyl.




53/370




53/366




53/371




53/367




53/372




53/368




53/373



53/369




53/374




Branching points

53/375 - 53/396


53/375




53/382




53/375 8-cyl.




53/384




53/376




53/394




53/376 8-cyl.




53/395



53/377




53/396




Branching points

53/397 - 53/423


53/397




53/405




53/398




53/406




53/399




53/408




53/400




53/415



53/403




53/423




Branching points

53/425 - 53/438


53/425 V70




53/434




53/425 XC90




53/435




53/430




53/436




53/431




53/437



53/433




53/438




Branching points

53/443 - 53/460


53/443




53/452




53/448 V70




53/454




53/448 XC90




53/458




53/449




53/459



53/450




53/460




Branching points

53/461 - 53/513


53/461




53/505




53/500




53/508




53/501




53/509




53/502




53/512



53/503




53/513




Branching points

53/514 - 53/534 XC90


53/514




53/524




53/515




53/525




53/516




53/526




53/517




53/534 V70



53/523




53/534 XC90




Branching points

53/535 - 53/579


53/535




53/575




53/567




53/576




53/568




53/577




53/569




53/578



53/570



53/579




Branching points

53/582 - 53/655


53/582




53/606




53/601



53/652




53/602



53/653




53/604



53/654



53/605




53/655



Branching points


53/663 - 53/737

53/663




P20589_53-663

53/734




P20589_53-734

53/664




P20589_53-664

53/735




P20477_53-735

53/728




P20477_53-728

53/736




P20477_53-736

53/731




P20477_53-731

53/737




P20477_53-737

53/733




P20589_53-733


Cable harness routine in vehicle
Engine harness, gasoline




Cable harness routine in vehicle
Engine harness, diesel




Cable harness routine in vehicle
Engine harness, I5D




Cable harness routine in vehicle
Engine compartment harness LHD, V70




Cable harness routine in vehicle
Engine compartment harness RHD, V70




Cable harness routine in vehicle
Engine compartment harness LHD, XC90




Cable harness routine in vehicle
Engine compartment harness RHD, XC90




Cable harness routine in vehicle
Passenger compartment harness LHD, V70




Cable harness routine in vehicle
Passenger compartment harness RHD, V70




Cable harness routine in vehicle
Passenger compartment harness LHD, XC90




Cable harness routine in vehicle
Passenger compartment harness RHD, XC90




Cable harness routine in vehicle
Cargo compartment harness V70




Cable harness routine in vehicle
Cargo compartment harness XC90




Cable harness routine in vehicle
Roof harness & Inflatable curtain harness V70




Tailgate harness V70







Cable harness routine in vehicle
Roof harness XC90







Tailgate harness XC90




Cable harness routine in vehicle
Door harness V70




Cable harness routine in vehicle
Door harness XC90



Cable harness routine in vehicle
Bi-Fuel harnesses V70




Cable harness routine in vehicle
Rear seat entertainment XC90




Component illustrations

1/1 - 2/91


1/1 Battery V70




2/35 Relay, starter motor




1/1 Battery XC90




2/64 Relay, auxiliary lights V70




2/14 Relay, glow plug unit




2/64 Relay, auxiliary lights XC90




2/22 Relay, climate control system




2/90 Relay, windshield wiper, low/high speed



2/32 Main relay, engine management system




2/91 Relay, intermittent wiping




Component illustrations

2/138 - 3/1 V70


2/138 Deadlock relay, left rear door V70




2/191 Relay, remote parking heater start, radio signal




2/138 Deadlock relay, left rear door XC90




2/192 Relay, electric engine heater V70




2/139 Deadlock relay, right rear door V70




2/192 Relay, electric engine heater XC90




2/139 Deadlock relay, right rear door XC90




2/237 Disconnect relay, rear speaker



2/182 Relay, high pressure headlight washer motor




3/1 Ignition switch V70




Component illustrations

3/1 XC90 - 3/25 V70


3/1 Ignition switch XC90




3/4 Steering Wheel Switch Left (SWSL) V70




3/4 Steering Wheel Switch Left (SWSL) XC90




3/6 Switch, hazard warning flashers




3/8 Switch, heated rear window/door mirrors V70




3/8 Switch, heated rear window/door mirrors XC90




3/9 Brake light contact V70




3/9 Brake light contact XC90



3/10 Reversing light contact




3/25 Switch, power sunroof V70




Component illustrations

3/25 XC90 - 3/60 V70


3/25 Switch, power sunroof XC90




3/47 Parking brake contact V70




3/26 Switch unit, power driver's seat




3/47 Parking brake contact, XC90




3/27 Switch unit, power passenger seat




3/59 Headlight adjustment control V70




3/37 Horn contact V70




3/59 Headlight adjustment control XC90



3/37 Horn contact XC90




3/60 Switch, auxiliary lights V70




Component illustrations

3/60 XC90 - 3/75 V70


3/60 Switch, auxiliary lights XC90




3/73 Power Child Lock (PCL) switch V70




3/62 Hood alarm contact V70




3/73 Power Child Lock (PCL) switch XC90




3/62 Hood alarm contact XC90




3/74 Lock unit, front left door, V70




3/71 Contacts gear selector AW51




3/74 Lock unit, front left door, XC90



3/71 Contacts gear selector 4T65AWD




3/75 Lock unit, right front door, V70




Component illustrations

3/75 XC90 - 3/82 V70


3/75 Lock unit, right front door, XC90




3/78 Lock unit, tailgate V70




3/76 Lock unit, rear left door, V70




3/78 Lock unit, tailgate XC90




3/76 Lock unit, rear left door XC90




3/80 Switch, central locking, left V70




3/77 Lock unit, rear right door, V70




3/80 Switch, central locking, left XC90



3/77 Lock unit, rear right door XC90




3/82 Switch, central locking, right V70



Component illustrations


3/82 XC90 - 3/93 V70

3/82 Switch, central locking, right XC90




P204_3-82_XC90

3/85 Power window switch, rear left door V70




P204_3-85_V70

3/85 Power window switch, rear left door XC90




P204_3-85_XC90

3/86 Power window switch, rear right door rear V70




P204_3-86_V70

3/86 Power window switch, rear right door XC90




P204_3-86_XC90

3/91 Switch, left heated seat V70




P204_3-91_V70

3/91 Switch, left heated seat XC90




P204_3-91_XC90

3/92 Switch, right heated seat V70




P204_3-92_V70

3/92 Switch, right heated seat XC90



P204_3-92_XC90

3/93 Belt buckle contact, left seat V70




P204_3-93_V70


Component illustrations

3/93 XC90 - 3/117 V70


3/93 Belt buckle contact, left seat XC90




3/111 Light Switch Module (LSM), V70




3/94 Belt buckle contact, right seat V70




3/111 Light Switch Module (LSM), XC90




3/94 Belt buckle contact, right seat XC90




3/112 Climate Control Module (CCM) V70




3/95 Spin control switch V70




3/112 Climate Control Module (CCM) XC90



3/95 Spin control switch XC90




3/117 Ceiling light switch unit, V70




Component illustrations

3/117 XC90 - 3/155


3/117 Ceiling light switch unit, XC90




3/126 Driver/Passenger Door Module (DDM)/(PDM), V70




3/126 Driver/Passenger Door Module (DDM)/(PDM), XC90




3/127 Passenger/Driver Door Module (PDM)/(DDM), V70




3/127 Passenger/Driver Door Module (PDM)/(DDM), XC90




3/131 Steering Wheel Switch Right (SWSR) V70




3/131 Steering Wheel Switch Right (SWSR) XC90




3/135 RTI switch



3/155 Program selector, automatic transmission V70




3/155 Program selector, automatic transmission XC90




Component illustrations

3/156 - 3/174


3/156 Gear Selector Module (GSM) V70




3/156 Gear Selector Module (GSM) XC90




3/157 Switch, front passenger airbag V70




3/157 Switch, front passenger airbag XC90




3/171 Switch, retractable door mirrors V70




3/171 Switch, retractable door mirrors XC90




3/173 Switch, tailgate private lock V70




3/173 Switch, tailgate private lock XC90



3/174 Switch, reduced alarm V70




3/174 Switch, reduced alarm XC90



Component illustrations


3/225 - 4/28

3/225 Switch unit continuous damping control (CCD)




P204_3-225

4/7 Combustion Preheater Module (CPM) XC90




P204_4-7_XC90

3/254 Steering Wheel Module (SWM)




P204_3-254

4/9 Supplemental Restraint System module (SRS)




P204_4-9

3/255 Position sensor, driver's seat




P204_3-255

4/16 Brake Control Module (BCM) V70




P204_4-16_V70

3/256 Position sensor, passenger seat




P204_3-256

4/16 Brake Control Module (BCM) XC90




P204_4-16_XC90

4/7 Combustion Preheater Module (CPM) V70



P204_4-7_V70

4/28 Transmission Control Module (TCM), TF-80SC




P20485_4-28


Component illustrations

4/28 - 4/50


4/28 Transmission Control Module (TCM), V70




4/28 Transmission Control Module (TCM), XC90




4/31 Fan control module




4/33 Sun Roof Module (SRM), V70




4/33 Sun Roof Module (SRM), XC90




4/46 Engine Control Module (ECM), V70




4/46 Engine Control Module (ECM), XC90




4/46 Engine Control Module (ECM), 8-cyl.



4/46 Engine Control Module (ECM), I5D




4/50 Electronic Throttle Module (ETM)




Component illustrations

4/52 - 4/71


4/52 Power Seat Module (PSM)




4/68 Steering Wheel Angle Sensor Module (SAS)




4/56 Central Electronic Module (CEM), V70




4/70 Upper Electronic Module (UEM), V70




4/56 Central Electronic Module (CEM), XC90




4/70 Upper Electronic Module (UEM), XC90




4/58 Rear Electronic Module (REM), V70




4/71 Cooling fan module V70



4/58 Rear Electronic Module (REM), XC90




4/71 Cooling fan module XC90




Component illustrations

4/71 - 4/86 V70


4/71 Cooling fan module I5D




4/76 Remote control unit for garage door opener




4/78 Accessory Electronic Module (AEM) V70




4/78 Accessory Electronic Module (AEM) XC90




4/82 Differential Electronic Module (DEM) V70




4/82 Differential Electronic Module (DEM) XC90




4/83 Control module fuel pump




4/83 Fuel pump module, 8-cyl.



4/84 Suspension Module (SUM)




4/86 Parking Assistance Module (PAM) V70



Component illustrations


4/86 XC90 - 6/1 V70

4/86 Parking Assistance Module (PAM)
XC90




P204_4-86_XC90

4/110 Trailer module V70




P204_4-110_V70

4/99 Electronic power steering control module




P204_4-99

4/110 Trailer module XC90




P204_4-110_XC90

4/106 Control module, remote parking heater start




P204_4-106

5/1 Driver Information Module (DIM) V70




P204_5-1_V70

4/107 Control module, parking heater, Call start




P204_4-107

5/1 Driver Information Module (DIM) XC90




P204_5-1_XC90

4/109 Glow plug control module



4-109_88

6/1 Windshield wiper motor V70




P204_6-1_V70


Component illustrations

6/1 XC90 - 6/20


6/1 Windshield wiper motor XC90




6/16 Motor driver's seat, backrest angle




6/3 Right-hand headlight wiper motor




6/17 Motor driver's seat, up/down front edge




6/4 Left-hand headlight wiper motor




6/18 Motor driver's seat, up/down rear edge




6/15 Sunroof motor, V70




6/19 Motor driver's seat, fore/aft



6/15 Sunroof motor, XC90




6/20 Motor passenger seat, fore/aft




Component illustrations

6/25 - 6/33 V70


6/25 Starter motor V70




6/29 Motor, electric cooling fan




6/25 Starter motor XC90




6/29 Cooling fan motor, I5D




6/26 Alternator Control Module (ACM) V70




6/32 Rear window wiper motor, V70




6/26 Alternator Control Module (ACM)
XC90




6/32 Rear window wiper motor XC90



6/28 Motor, passenger compartment fan




6/33 Fuel pump V70




Component illustrations

6/33 XC90 - 6/48


6/33 Fuel pump XC90




6/38 Motor, left headlight adjustment




6/35 Fuel pump, auxiliary heater V70




6/39 Motor, right headlight adjustment




6/35 Fuel pump, auxiliary heater XC90




6/44 Cooling fan, electrics box, engine compartment V70




6/37 Lock motor, fuel filler flap V70




6/44 Cooling fan, electrics box, engine compartment XC90



6/37 Lock motor, fuel filler flap XC90




6/48 Damper Motor Module (DMM), recirculation




Component illustrations

6/58 - 6/65


6/58 Front left power window motor, V70




6/62 Left power door mirror, XC90




6/58 Front left power window motor, XC90




6/63 Right power door mirror, V70




6/60 Front right power window motor, V70




6/63 Right power door mirror, XC90




6/60 Front right power window motor, XC90




6/64 Motor passenger seat, backrest angle



6/62 Left power door mirror, V70




6/65 Motor passenger seat, up/down front edge




Component illustrations

6/66 - 6/93 V70


6/66 Motor passenger seat, up/down rear edge




6/73 Coolant pump, auxiliary heater XC90




6/67 Pump, fuel leakage control, V70




6/76 Climate control system, rear




6/67 Pump, fuel leakage control XC90




6/92 Rear left power window motor V70




6/69 Damper Motor Module (DMM), ventilation/floor/defroster




6/92 Rear left power window motor XC90



6/73 Coolant pump, auxiliary heater V70




6/93 Rear right power window motor V70




Component illustrations

6/93 XC90 - 6/114


6/93 Rear right power window motor XC90




6/95 Damper Motor Module (DMM), temperature, left-hand side




6/96 Damper Motor Module (DMM), temperature, right-hand side




6/102 Damper Motor Module (DMM), defroster




6/103 Damper Motor Module (DMM), floor/ventilation




6/104 High pressure headlight washer motor V70




6/104 High pressure headlight washer motor XC90




6/105 Fuel distributor, gas



6/113 Coolant pump, 8-cyl.




6/114 Vacuum pump




Component illustrations

6/118 - 7/5 V70


6/118 Regulator motor, swirl throttle




6/127 Washer motor V70




6/120 Throttle body motor V70




6/127 Washer motor XC90




6/120 Throttle body motor XC90




6/143 Regulator motor, turbo




6/120 Throttle body motor 8-cyl.




7/4 Brake fluid level sensor



6/120 Throttle body motor, I5D




7/5 Washer fluid level sensor V70



Component illustrations


7/5 XC90 - 7/12 V70

7/5 Washer fluid level sensor XC90




P204_7-5_XC90

7/8 Pressure sensor, climate control system, 8-cyl.




P204B5_7-8

7/6 Oil pressure monitor V70




P204_7-6_V70

7/10 Interior temperature sensor




P204_7-10

7/6 Oil pressure monitor XC90




P204_7-6_XC90

7/11 Outside temperature sensor V70




P204_7-11_V70

7/8 Pressure sensor, climate control system V70




P204_7-8_V70

7/11 Outside temperature sensor XC90




P204_7-11_XC90

7/8 Pressure sensor, climate control system XC90



P204_7-8_XC90

7/12 Solar sensor, twilight sensor and indicator alarm V70




P204_7-12_V70


Component illustrations

7/12 XC90 - 7/17


7/12 Solar sensor, twilight sensor and indicator alarm XC90




7/16 Coolant temperature sensor V70




7/15 Heated oxygen sensor, 5-cyl.




7/16 Coolant temperature sensor XC90




7/15 Heated oxygen sensor, 6-cyl.




7/16 Coolant temperature sensor, 8-cyl.




7/15 Front heated oxygen sensor, bank 2, 8-cyl.




7/17 Mass air flow sensor (MAF) V70



7/15 Heated oxygen sensor, I5D




7/17 Mass air flow sensor (MAF) XC90




Component illustrations

7/17 - 7/25


7/17 Mass air flow sensor (MAF), 8-cyl.




7/25 Impulse sensor, gasoline & I5D V70




7/23 Rear knock sensor




7/25 Impulse sensor, diesel V70




7/23 Rear knock sensor, 8-cyl.




7/25 Impulse sensor, gasoline & I5D XC90




7/24 Front knock sensor




7/25 Impulse sensor, diesel XC90



7/24 Front knock sensor, 8-cyl.




7/25 Impulse sensor, 8-cyl.




Component illustrations

7/31 - 7/61


7/31 Sensor ABS, front left




7/51 Accelerator pedal sensor XC90




7/32 Sensor ABS, front right




7/56 Sensor ABS, rear left




7/35 Oil level sensor




7/57 Rear right ABS sensor




7/41 Temperature sensor evaporator




7/61 Sensor, input speed AW51



7/51 Accelerator pedal sensor V70




7/61 Sensor, input speed 4T65AWD



Component illustrations


7/61 - 7/81

7/61 Sensor, input speed TF-80SC




P20485_7-61

7/62 Sensor, output speed AW51




P204_7-62_AW 50

7/62 Sensor, output speed 4T65AWD




P204_7-62_4T65AWD

7/62 Sensor, output speed TF-80SC




P20485_7-62

7/73 Coolant level sensor V70




P204_7-73_V70

7/73 Coolant level sensor XC90




P204_7-73_XC90

7/74 Fluid temperature sensor, automatic transmission AW51




P204_7-74_AW 50

7/74 Sensor oil temperature automatic transmission 4T65AWD




P204_7-74_4T65AWD

7/74 Fluid temperature sensor, automatic transmission, TF-80SC



P20485_7-74

7/81 Pressure sensor, intake manifold




P204_7-81_V70


Component illustrations

7/81 - 7/93


7/81 Pressure sensor, intake manifold, 8-cyl.




7/82 Heated oxygen sensor, diagnostics 1, 5-cyl.




7/82 Heated oxygen sensor, diagnostics 1, 6-cyl.




7/82 Front heated oxygen sensor, bank 1, 8-cyl.




7/87 Acceleration sensor, Four-C, front left




7/88 Acceleration sensor, Four-C, front right




7/89 Acceleration sensor, Four-C, rear left




7/91 Steering wheel angle sensor V70



7/91 Steering wheel angle sensor XC90




7/93 Occupant Weight Sensor (OWS)




Component illustrations

7/100 - 7/109 V70


7/100 Inclination Sensor Module (ISM) V70




7/100 Inclination Sensor Module (ISM) XC90




7/103 Heated oxygen sensor 3




7/103 Rear heated oxygen sensor, bank 2, 8-cyl.




7/104 Rear heated oxygen sensor, bank 1, 8-cyl.




7/105 Outside temperature sensor, engine control module V70




7/105 Outside temperature sensor, engine control module XC90




7/108 Side impact sensor, rear left V70



7/108 Side impact sensor, rear left XC90




7/109 Side impact sensor, rear right V70




Component illustrations

7/109 XC90 - 7/120 V70


7/109 Side impact sensor, rear right XC90




7/116 Side impact sensor, front right V70




7/110 Left-hand seat temperature sensor




7/116 Side impact sensor, front right XC90




7/111 Right-hand seat temperature sensor




7/118 Acceleration sensor, shock absorber, Four-C, front left




7/115 Side impact sensor, front left V70




7/119 Acceleration sensor, shock absorber, Four-C, front right



7/115 Side impact sensor, front left XC90




7/120 Rear left angle sensor, Four-C/Bi-Xenon V70




Component illustrations

7/120 - 7/129


7/120 Rear left angle sensor, Four-C/Bi-Xenon XC90




7/123 Clutch pedal sensor XC90




7/121 Rear right angle sensor, Four-C




7/124 Brake pedal sensor V70




7/122 Mass Movement Sensor Module (MMS), front V70t




7/124 Brake pedal sensor XC90




7/122 Mass Movement Sensor Module (MMS), front XC90




7/129 Brake pressure sensor 2 V70



7/123 Clutch pedal sensor V70




7/129 Brake pressure sensor 2 XC90




Component illustrations

7/130 - 7/139 V70


7/130 Fuel level sensor, ejector side V70




7/134 Rear parking assistance sensor 4




7/130 Fuel level sensor, ejector side XC90




7/135 Glass breakage sensor, left-hand




7/131 Rear parking assistance sensor 1




7/136 Glass breakage sensor, right-hand




7/132 Rear parking assistance sensor 2




7/137 Glass breakage sensor, tailgate



7/133 Rear parking assistance sensor 3




7/139 Brake pressure sensor 1 V70




Component illustrations

7/139 XC90 - 7/159


7/139 Brake pressure sensor 1 XC90




7/154 Fuel temperature sensor, I5D




7/143 Fuel level sensor, pump side V70




7/156 Pressure and temperature sensor, Bi-Fuel




7/143 Fuel level, pump side XC90




7/156 Pressure and temperature sensor fuel




7/149 Rain Sensor Module (RSM), V70




7/158 Mass Movement Sensor (MMS), rear



7/149 Rain Sensor Module (RSM), XC90




7/159 Air Quality Sensor (AQS)




Component illustrations

7/162 - 7/173


7/162 Fuel rail pressure sensor V70




7/166 Oil level sensor, I5D




7/162 Fuel rail pressure sensor XC90




7/172 Position sensor camshaft, intake side




7/162 Fuel rail pressure sensor I5D




7/172 Intake camshaft position sensor, bank 2, 8-cyl.




7/164 Body Sensor Cluster Stability Sensor (BSC)




7/173 Position sensor camshaft exhaust side Diesel



7/165 Pressure and temperature sensor, intake manifold




7/173 Position sensor camshaft exhaust side Gasoline




Component illustrations

7/173 - 7/201


7/173 Exhaust camshaft position sensor, bank 2, 8-cyl.




7/188 Intake camshaft position sensor, bank 1, 8-cyl.




7/174 Differential pressure sensor, particle filter




7/189 Exhaust camshaft position sensor, bank 1, 8-cyl.




7/175 Weight sensor passenger seat, seat belt reminder




7/190 Temperature sensor, exhaust gases upstream of particle filter




7/178 Front impact sensor, right




7/191 Temperature sensor, exhaust gases downstream of particle filter



7/179 Front impact sensor, left




7/201 Pressure and temperature sensor, gas




Component illustrations

7/204- 8/17 V70


7/204 Front parking assistance sensor 5




8/3 Electromagnetic clutch, climate control system XC90




7/205 Front parking assistance sensor 6




8/3 Electromagnetic clutch, climate control system, 8-cyl.




7/206 Front parking assistance sensor 7




8/6-10 Injection valves, diesel




7/207 Front parking assistance sensor 8




8/6-11 Injection valves, gasoline



8/3 Electromagnetic clutch, climate control system V70




8/17 EGR valve, diesel V70




Component illustrations

8/17 XC90 - 8/23


8/17 EGR valve, diesel XC90




8/19 Solenoid, variable valve timing, intake, bank 2, 8-cyl.




8/18 EVAP valve V70




8/20 Shock absorber, Four-C, front left




8/18 EVAP valve XC90




8/21 Shock absorber, Four-C, front right




8/18 EVAP valve, 8-cyl.




8/22 Shock absorber, Four-C, rear left



8/19 Solenoid, variable valve timing, intake




8/23 Shock absorber, Four-C, rear right




Component illustrations

8/28 - 8/34 V70


8/28 Turbocharger control valve V70




8/32 Igniter, airbag stage 2, passenger side V70




8/28 Turbocharger control valve XC90




8/32 Igniter, airbag stage 2, passenger side XC90




8/30 Airbag igniter, driver's side




8/33 Front left belt tensioner igniter V70




8/31 Airbag igniter, passenger side V70




8/33 Front left belt tensioner igniter XC90



8/31 Airbag igniter, passenger side XC90




8/34 Front right belt tensioner igniter V70



Component illustrations


8/34 XC90 - 8/39

8/34 Front right belt tensioner igniter XC90




P204_8-34_XC90

8/38 Shift solenoid 1 AW51




P204_8-38-41_AW50

8/36 Solenoid shift lock




P204_8-36_AUTO

8/38 Shift solenoid 1 4T65AWD




P204_8-38-41_4T65AWD

8/37 Automatic transmission AW51




P204_8-37_AW50

8/38 Shift solenoid 1 TF-80SC




P20485_8-38

8/37 Automatic transmission 4T65AWD




P204_8-37_4T65AWD

8/39 Shift solenoid 2 AW51




P204_8-38-41_AW50

8/37 Automatic transmission TF-80SC



P20485_8-37

8/39 Shift solenoid 2 4T65AWD




P204_8-38-41_4T65AWD


Component illustrations

8/39 - 8/51


8/39 Shift solenoid 2 TF-80SC




8/41 Pressure solenoid 4T65AWD




8/40 Lock-up solenoid AW51




8/46 Activation unit DSTC V70




8/40 Lock-up solenoid 4T65AWD




8/46 Activation unit DSTC XC90




8/40 Lock-up solenoid TF-80SC




8/51 Side airbag igniter, front left V70



8/41 Pressure solenoid AW51




8/51 Side airbag igniter, front left XC90



Component illustrations


8/52 - 8/66 V70

8/52 Side airbag igniter, front right V70




P204_8-52_V70

8/62 Belt tensioner igniter, center rear seat V70




P204_8-62_V70

8/52 Side airbag igniter, front right XC90




P204_8-52_XC90

8/62 Belt tensioner igniter, center rear seat XC90




P204_8-62_XC90

8/55 Igniter, left rear belt tensioner




P204_8-55_XC90

8/64 Solenoid valve, engine pad, diesel V70




P204_8-64_V70

8/56 Igniter, right rear belt tensioner




P204_8-56_XC90

8/64 Solenoid valve, engine pad, diesel XC90




P204_8-64_XC90

8/61 Igniter, airbag stage 2, driver's side



P204_8-61

8/66 Left inflatable curtain igniter V70




P204_8-66_V70


Component illustrations

8/66 XC90 - 8/78


8/66 Left inflatable curtain igniter XC90




8/72 Shift solenoid 3 AW51




8/67 Right inflatable curtain igniter V70




8/73 Shift solenoid 4 AW51




8/67 Right inflatable curtain igniter XC90




8/74 Shift solenoid 5 AW51




8/71 Throttle solenoid AW51




8/75 Valve, fuel cut-off DFCO



8/71 Throttle solenoid TF-80SC




8/78 Oil pressure sensor




Component illustrations

8/81 - 8/89


8/81 Solenoid, variable valve timing exhaust V70




8/81 Solenoid, variable valve timing exhaust XC90




8/81 Solenoid, variable valve timing, exhaust, bank 2, 8-cyl.




8/82 Solenoid, variable turbo geometry, diesel V70




8/82 Solenoid, variable turbo geometry, diesel XC90




8/84 Switch, vacuum pump




8/85 Thermostatic switch and fuel filter heating V70




8/85 Thermostatic switch and fuel filter heating XC90



8/88 Solenoid, fuel tank, Bi-Fuel, rear




8/89 Solenoid, fuel tank, Bi-Fuel, front left




Component illustrations

8/90 - 8/113


8/90 Solenoid, fuel tank, Bi-Fuel, front right




8/94 Left-hand belt tensioner igniter, third row of seats




8/95 Right-hand belt tensioner igniter, third row of seats




8/96 Left-hand inflatable curtain igniter, third row of seats




8/97 Right-hand inflatable curtain igniter, third row of seats




8/98 Fuel pressure control valve, i5D




8/99 Igniter, steering column




8/107 Valve, variable intake, 8-cyl.



8/111 Solenoid valve, high-pressure diesel




8/113 Fuel pressure bypass valve




Component illustrations

8/117 - 8/145


8/117 Solenoid, variable valve timing,
intake, bank 1, 8-cyl.




8/118 Solenoid, variable valve timing,
exhaust, bank 1, 8-cyl.




8/120 EGR valve




8/123 Igniter airbag driver side stage 3,
XC90




8/124 Igniter passenger side airbag stage 3,
XC90




8/134 Solenoid, reverse interlock, manual




8/142 Linear pressure solenoid SLB1
TF-80SC AWD




8/143 Linear pressure solenoid SLC1
TF-80SC AWD



8/144 Linear pressure solenoid SLC2
TF-80SC AWD



8/145 Linear pressure solenoid SLC3
TF-80SC AWD




Component illustrations


8/146 - 9/18

8/146-


8/153 Injection valves, 8-cyl.




9/1 Front 12V outlet V70




9/1 Front 12V outlet XC90




9/2 Heated rear window V70




9/2 Heated rear window XC90




9/12 Seat Heating Module (SHM), left-hand




9/13 Seat Heating Module (SHM), right-hand




9/16 Left-hand backrest heating element



9/17 Right-hand backrest heating element




9/18 Left-hand seat heating element




Component illustrations

9/19 - 10/1


9/19 Right-hand seat heating element




9/32 PTC-resistor air preheating




9/25 Rear 12 V outlet V70




9/33 Left heated exterior rearview mirror




9/25 Rear 12 V outlet XC90




9/34 Right heated exterior rearview mirror




9/30 Auxiliary heater V70




10/1 Left front lamp housing V70



9/30 Auxiliary heater XC90




10/1 Left front lamp housing XC90



Component illustrations


10/2 - 10/11

10/2 Right front lamp housing V70




P204_10-2_V70

10/5 Fog light, front left XC90




P204_10-5_XC90

10/2 Right front lamp housing XC90




P204_10-2_XC90

10/6 Fog light, front right V70




P204_10-6_V70

10/3 License plate lighting V70




P204_10-3_V70

10/6 Fog light, front right XC90




P204_10-6_XC90

10/3 License plate lighting XC90




P204_10-3_XC90

10/11 Running/parking light, front left V70




P204_10-11_V70

10/5 Fog light, front left V70



P204_10-5_V70

10/11 Running/parking light, front left XC90




P204_10-11_XC90


Component illustrations

10/12 - 10/16


10/12 Running/parking light, front right V70




10/12 Running/parking light, front right XC90




10/13 Direction indicator, front left V70




10/13 Direction indicator, front left XC90




10/14 Direction indicator, front right V70




10/14 Direction indicator, front right XC90




10/15 Direction indicator, front left fender V70




10/15 Direction indicator, left front door XC90



10/16 Direction indicator right front fender, V70




10/16 Direction indicator, right front door, XC90




Component illustrations

10/17 - 10/43 V70


10/17 Lamp housing, rear right V70




10/19 Auxiliary brake light XC90




10/17 Lamp housing, rear right XC90




10/25 Ceiling light, cargo compartment




10/18 Lamp housing, rear left V70




10/29 Glove compartment lighting V70




10/18 Lamp housing, rear left XC90




10/29 Glove compartment lighting XC90



10/19 Auxiliary brake light V70




10/43 Brake light, right V70




Component illustrations

10/43 XC90 - 10/48


10/43 Brake light, right XC90




10/46 Fog light, right rear XC90




10/44 Tail light 1, right V70




10/47 Direction indicator, rear right V70




10/44 Tail light 1, right XC90




10/47 Direction indicator, right rear XC90




10/45 Tail light 2, right V70




10/48 Reversing light, right V70



10/46 Fog light, rear right V70




10/48 Reversing light, right XC90




Component illustrations

10/50 - 10/55 V70


10/50 Brake light, left V70




10/53 Fog light, rear left V70




10/50 Brake light, left XC90




10/53 Fog light, rear left XC90




10/51 Tail light 1, left V70




10/54 Direction indicator, rear left V70




10/51 Tail light 1, left XC90




10/54 Direction indicator, rear left XC90



10/52 Tail light 2 left, V70




10/55 Reversing light, left V70




Component illustrations

10/55 XC90 -10/71 V70


10/55 Reversing light, left XC90




10/66 Low beam, right V70




10/64 High beam, right V70




10/66 Low beam, right XC90




10/64 High beam, right XC90




10/68 High beam, left V70




10/65 Auxiliary light, front right V70




10/68 High beam, left XC90



10/65 Auxiliary light, front right XC90




10/69 Auxiliary light, front left V70




Component illustrations

10/69 - 10/114


10/69 Auxiliary light, front left XC90




10/72 Front ashtray lighting




10/70 Low beam, left V70




10/73 Side running light, front right V70




10/70 Low beam, left XC90




10/73 Side running light, front right XC90




10/71 Side running light, front left V70




10/114 Vanity mirror lighting, left V70



10/71 Side running light, front left XC90




10/114 Vanity mirror lighting, left XC90




Component illustrations

10/115 - 10/150


10/115 Vanity mirror lighting, right V70




10/126 Courtesy lighting, front right XC90




10/115 Vanity mirror lighting, right XC90




10/148 Left exterior rearview mirror lighting




10/125 Courtesy lighting, front left V70




10/149 Door mirror lighting, right




10/125 Courtesy lighting, front left XC90




10/150 Rear reading light V70



10/126 Courtesy lighting, front right V70




10/150 Rear reading light XC90




Component illustrations

10/172 - 11F


10/172 Reading light, third row of seats




11C Fuses in the passenger compartment fuse box, V70



10/173 Cargo compartment lighting, tailgate




11C Fuses in the passenger compartment fuse box, XC90




Component illustrations

15/31 - 16/6 V70


15/31 Distribution box in engine compartment




16/4 Speaker, front left door V70




16/1 Audio Module (AUM)




16/4 Speaker, front left door XC90




16/2 Amplifier




16/5 Speaker, rear right door V70




16/3 Speaker, front right door V70




16/5 Speaker, rear right door XC90



16/3 Speaker, front right door XC90




16/6 Speaker, rear left door V70




Component illustrations

16/6 XC90 - 16/35


16/6 Speaker, rear left door XC90




16/16 LH window antenna amplifier 1




16/10 Horn 1, V70




16/26 Center dashboard speaker V70




16/10 Horn 1 XC90




16/26 Center dashboard speaker XC90




16/11 Horn 2




16/35 Siren (SCM) V70



16/15 CD changer




16/35 Siren (SCM) XC90




Component illustrations

16/46 - 16/57


16/36 TV receiver, V70




16/46 RTI display, Turn-by-Turn




16/45 Road Traffic Information module (RTI)




16/47 GPS antenna, RTI




16/45 Traffic information module, Turn-by-Turn




16/49 Traffic Message Channel module




16/46 RTI display, V70




16/50 Left-hand rear window antenna



16/46 Multimedia display, XC90




16/54 Right-hand rear window antenna




Component illustrations

16/57 - 16/65


16/55 Treble speaker, front left door V70




16/57 Speaker, left D-pillar XC90




16/55 Treble speaker, front left door XC90




16/58 Speaker, right D-pillar V70




16/56 Treble speaker, front right door V70




16/58 Speaker, right D-pillar XC90




16/56 Treble speaker, front right door XC90




16/60 Phone Module (PHM) V70



16/57 Speaker, left D-pillar V70




16/60 Phone Module (PHM) XC90




Component illustrations

16/65 - 16/79


16/62 Hand unit, cellular phone V70




16/65 Antenna ring/ignition switch lighting
XC90




16/62 Hand unit, cellular phone XC90




16/67 Amplifier antenna, bumper




16/64 Antenna, cellular phone V70




16/68 Antenna, bumper




16/64 Antenna, cellular phone XC90




16/71 Window antenna amplifier 1, right



16/65 Antenna ring/ignition switch lighting
V70




16/73 Window antenna amplifier 2, left




Component illustrations

16/79 - 16/105


16/74 Window antenna amplifier 2, right




16/79 Subwoofer Module (SUB), XC90




16/77 Microphone, cellular phone V70




16/81 Screen, accessory




16/77 Microphone, cellular phone XC90




16/81A Screen, LH head restraint




16/78 Speaker, cellular phone




16/81B Screen, RH head restraint



16/79 Subwoofer, V70




16/82 DVD-player




Component illustrations

16/106 - 16/125


16/82 DVD-player accessory




16/106 CD Player Module (MP2)




16/93 Control module, cellular phone handsfree, V70




16/107 MD Player Module (MP1)




16/93 Control module, cellular phone handsfree XC90




16/108 Multimedia Module (MMM)




16/94 Infotainment Control Module (ICM)




16/110 Antenna module (ATM)



16/105 Audio Module (AUD)




16/111 Outlet, rear left headphones




Component illustrations

16/126 - 17/19


16/112 Outlet, rear right headphones




16/122 Rear Audio Separation module (RAS)




16/123 External equipment outlet (AUX)




16/124 Rear Seat Entertainment module (RSE)




16/125 IR transmitter




16/126 Holder, cellular phone handsfree V70




16/126 Holder, cellular phone handsfree XC90




16/127 Microphone, cellular phone handsfree V70



16/127 Microphone, cellular phone handsfree XC90




16/145 Satellite radio receiver




Component illustrations

17/19 - 18/4


16/149 MP3 player




17/13 Data link connector V70




17/13 Data link connector XC90




17/17 Jump start connection




17/19 12V outlet, cargo compartment V70




17/19 12V outlet, cargo compartment XC90




17/37 4-pin outlet, tow hitch cable harness V70




17/37 4-pin outlet, tow hitch cable harness XC90



17/38 7-pin outlet, tow hitch cable harness, V70




17/38 7-pin outlet, tow hitch cable harness, XC90 EU/OS




Component illustrations

20/3-8 - 31/1


17/38 7-pin outlet, tow hitch cable harness,
XC90 USA




17/39 13-pin outlet, tow hitch cable harness
V70




17/39 13-pin outlet, tow hitch cable harness
XC90




18/4 Contact reel V70




18/4 Contact reel XC90




20/3-8 Spark plug and ignition coil




20/16 Capacitor




20/22-26Glow plug



20/46-53Spark plug with ignition coil, 8-cyl.




26/4 Converter, tow hitch cable harness
V70




Component illustrations

31/20 - 31/46


26/4 Converter, tow hitch cable harness
XC90




31/2 Ground connection, left MacPherson strut tower, V70




27/3 Left Camera Module (LCM)




31/2 Ground connection, left MacPherson strut tower, XC90




27/4 Right Camera Module (RCM)




31/4 Ground connection, engine




31/1 Ground connection, right MacPherson strut tower, V70




31/6 Ground connection, A-pillar, left side V70



31/1 Ground connection, right MacPherson strut tower, XC90




31/6 Ground connection, A-pillar, left side XC90




Component illustrations

31/46 - 31/67


31/10 Ground connection, A-pillar, right side V70




31/10 Ground connection, A-pillar, right side XC90




31/44 Ground connection, left-hand side member, lower engine compartment V70




31/44 Ground connection, left-hand side member, lower engine compartment XC90




31/46 Ground connection, rear left seat riser V70




31/46 Ground connection, rear left seat riser XC90




31/47 Ground connection, rear left seat riser V70




31/47 Ground connection, rear left seat riser XC90



31/48 Ground connection, rear right seat riser V70




31/48 Ground connection, rear right seat riser XC90




Component illustrations

31/67 - 31/84


31/53 Ground connection, firewall, V70




31/53 Ground connection, firewall XC90




31/66 Ground connection, front seat riser, left-hand side V70




31/66 Ground connection, front seat riser, left-hand side XC90




31/67 Ground connection, front seat riser, right-hand side V70




31/67 Ground connection, front seat riser, right-hand side XC90




31/70 Ground connection, left-hand side member, lower engine compartment V70




31/70 Ground connection, left-hand side member, lower engine compartment XC90



31/72 Ground connection, cargo compartment V70




31/72 Ground connection, cargo compartment XC90




Component illustrations

31/84 - 31/94


31/73 Ground connection, rear right seat riser V70




31/73 Ground connection, rear right seat riser XC90




31/83 Ground connection, A-pillar, left side V70




31/83 Ground connection, A-pillar, left side XC90




31/84 Ground connection, A-pillar, right side V70




31/84 Ground connection, A-pillar, right side XC90




31/88 Ground connection, engine ignition coils, group 1




31/88 Ground connection, engine ignition coils, 8-cyl.



31/89 Ground connection, engine ignition coils, group 2




31/89 Ground connection, engine ignition coils, 8-cyl.




Component illustrations

31/94 - 31/102


31/90 Ground connection, engine ignition coils, 8-cyl.




31/91 Ground connection, engine




31/93 Ground connection, left MacPherson strut tower, V70




31/93 Ground connection, left MacPherson strut tower, XC90




31/94 Ground connection, right MacPherson strut tower, V70




31/94 Ground connection, right MacPherson strut tower, XC90




31/95 Ground connection, left MacPherson strut tower, V70




31/95 Ground connection, left MacPherson strut tower, XC90



31/96 Ground connection, right MacPherson strut tower, V70




31/96 Ground connection, right MacPherson strut tower, XC90




Component illustrations

31/102 - 54/3.1


31/98 Ground connection, upper windshield member V70




31/98 Ground connection, upper windshield member XC90




31/99 Ground connection, Side window left




31/100 Engine ignition coils, 8-cyl.




31/102 Ground connection, front member V70




31/102 Ground connection, front member XC90




31/118 Ground connection, between front seats under the armrest




31/120 Ground connection, cargo compartment V70



31/120 Ground connection, cargo compartment XC90




54/1 Connector V70




Component illustrations

54/3.1 - 54/10


54/1 Connector XC90




54/3.1 Connector XC90




54/1B Connector V70




54/3.2 Connector V70




54/1B Connector XC90




54/3.2 Connector XC90




54/1C Connector




54/4 Connector



54/3.1 Connector V70




54/7 Connector




Component illustrations

54/10 - 54/20


54/8 Connector V70




54/10 Connector XC90




54/8 Connector XC90




54/11 Connector V70




54/9 Connector V70




54/11 Connector XC90




54/9 Connector XC90




54/12 Connector V70



54/10 Connector V70




54/12 Connector XC90




Component illustrations

54/21 - 54/35


54/13 Connector V70




54/21 Connector




54/13 Connector XC90




54/22 Connector V70




54/14 Connector




54/22 Connector XC90




54/16 Connector




54/23 Connector V70



54/20 Connector




54/23 Connector XC90




Component illustrations

54/36 - 54/50


54/24 Connector




54/36 Connector V70




54/25 Connector




54/36 Connector XC90




54/32 Connector




54/39 Connector




54/34 Connector




54/40B Connector



54/35 Connector




54/40C Connector




Component illustrations

54/53 - 54/66.2


54/40D Connector




54/53 Connector




54/43 Connector




54/54 Connector




54/43B Connector




54/55 Connector V70




54/50 Connector V70




54/55 Connector XC90



54/50 Connector XC90




54/56 Connector V70




Component illustrations

54/74 - 54/122


54/56 Connector XC90




54/74 Connector




54/57.1 Connector V70




54/74B Connector




54/57.1 Connector XC90




54/98 Connector




54/66.1 Connector




54/100 Connector



54/66.2 Connector




54/106 Connector




Component illustrations

54/132 - 54/1400


54/107 Connector




54/122 Connector




54/109 Connector




54/132 Connector V70




54/112 Connector




54/132 Connector XC90




54/113 Connector




54/274 Connector



54/117 Connector




54/275 Connector




Component illustrations

54/1400 - C1-6


54/303 Connector




54/1400 Connector V70




54/1300 Connector V70



54/1400 Connector XC90



54/1300 Connector XC90



4X/78 Connector interface, original car

9X/25 Connector interface, original car

16X/1 Connector interface, original car

16X/26 Connector interface, original car

16X/45 Connector interface, original car

16X/57 Connector interface, original car

16X/58 Connector interface, original car

16X/105 Connector interface, original car

54X/no. Connector interface, original car

A1 Connecting rail to 15/31

Index 1:2

12V outlet 109

A

Abbreviations 7
Accessories 93, 106, 107, 111, 112, 113, 124, 125, 126, 127, 128, 129, 130, 131, 132, 133, 135, 136, 138, 139, 169, 170, 171, 172
Accessory Electronic Module (AEM) 106, 107
Additional electrical equipment, Group 36 94
Alternator and voltage regulator, Group 32 79
Anti-theft alarm V70 103
Anti-theft alarm XC90 104
Audio V70 119
Audio with auxiliary amplifier V70 120
Audio XC90 122
Automatic transmission 142, 143, 144, 145
Auxiliary heater 168, 172
Auxiliary lights 93

B

Beam length adjustment V70 91
Beam length adjustment XC90 92
Bi-Fuel harnesses V70 235
Bi-Xenon V70 81
Bi-Xenon XC90 82
Brake control system 149
Brake lights 84
Brake system, Group 59 149
Branching points 205

C

Cable harness tow hitch, 4/7-pin 111
Cable harnesses 218
Cargo compartment harness V70 229
Cargo compartment harness XC90 230
CD changer V70 131
CD/MD player XC90 133
CD-Changer V70 130
Cellular phone V70 134
Central Electronic Module (CEM) 46
Central locking system V70 152
Central locking system XC90 153
Climate control system 164
Climate control system, Group 87 163
Climate control system, I5D & 8-cyl. 166
Color abbreviations 7
Component illustrations 237
Connectors 176
Control modules 42
Control modules, overview designations V70 43
Control modules, overview designations XC90 45
Control modules, overview positions V70 42
Control modules, overview positions XC90 44
Cooling fan 75
Cooling fan, I5D & 8-cyl. 76
Cooling system, Group 26 75
Countries/Markets, abbreviations 7
Cruise control 77

D

Data communication high speed CAN 50
Data communication low speed CAN V70 52
Data communication, LIN 54
Data communication low speed CAN XC90 53
Daytime running lights V70 81
Daytime running lights XC90 82

Diagnostics system 108
Differential Electronic Module (DEM) 148
Direction indicators V70 95
Direction indicators, XC90 96
Door harness V70 233
Door harness XC90 234
Doors and openings, Group 83 152
Driver information module 115, 116, 117, 118

E

Electrical distribution overview V70 10
Electrical distribution overview XC90 12
Electronic immobilizer 102
Electronic power steering 150
Emission control, 5-cyl. 72
Emission control, 5-cyl. turbo 73
Emission control, 6-cyl. turbo 73
Emission control, 8-cyl. 74
Engine compartment harness LHD, V70 221
Engine compartment harness LHD, XC90 223
Engine compartment harness RHD, V70 222
Engine compartment harness RHD, XC90 224
Engine control, Group 27 77
Engine harness, diesel 219
Engine harness, gasoline 218
Engine harness, I5D 220
Engine management system, 5-cyl. 60, 64
Engine management system, 5-cyl. Turbo 62
Engine management system, Bi-fuel 66
Engine management system, diesel 57
Explanations 7
Exterior decorative elements, etc., Group 84 156

F

Flashing hazard lights V70 95
Fog lights 83
Follow-me-home lighting 86
Four-C V70 151
Fuel system, Group 23 57
Fuses 14
Fuses by battery, 11E 23
Fuses in electrical distribution box, engine compartment 14
Fuses in engine compartment, 11A 14
Fuses in engine compartment, 11B 15
Fuses in extra fuse box cargo compartment XC90, 11F 24
Fuses in passenger compartment, 11C 23
Fuses in the passenger compartment, 11C 19

G

Geartronic 146
Ground connections 33
Groups 7

H

Handsfree MAX 128
Handsfree V70 126
Handsfree XC90 127
Hazard warning flashers XC90 96
Heated exterior rearview mirrors 158
Heated exterior rearview mirrors with camera function 157
Heated rear window 159
Heated seats 162
High and low beams (Bi-Xenon) XC90 82
High and low beams V70 81

Index 2:2

High pressure headlight washer	99
Horn	101
How to use the wiring diagrams	8

I

Ignition switch and relays	30
Ignition switch symbols	7
Inflatable curtain harness V70	231
Infotainment XC90	137
Instruments, Group 38	114
Interior equipment, Group 85	160
Interior lighting V70	89
Interior lighting XC90	90
Internal equipment, Group 88	173, 236

L

License plate lighting V70	87
License plate lighting XC90	88
Lighting, Group 35	81
List of components	319
List of symbols	9

M

MP3 player	132
------------------	-----

N

Navigation system	124
-------------------------	-----

O

Other, Group 39	119
-----------------------	-----

P

Parking assistance	105
Parking heater	168
Parking heater call start	171
Passenger compartment harness LHD, V70	225
Passenger compartment harness LHD, XC90	227
Passenger compartment harness RHD, V70	226
Passenger compartment harness RHD, XC90	228
Power driver's seat	160
Power exterior rearview mirrors	156
Power passenger seat	161
Power sunroof	155
Power supply	79
Power windows	154

R

Rain sensor	94
Rear climate control system XC90	163
Rear Electronic Module (REM)	48
Rear Seat Entertainment XC90	139
Rear seat entertainment XC90	236
Relay, electric engine heater	169
Relays	30
Relays, general	30
Remote garage door opener	173
Remote parking heater start	170
Reversing lights	85
Road Traffic Information module (RTI)	123, 125
Roof harness	231
Roof harness XC90	232
Running/parking lights V70	87
Running/parking lights XC90	88

S

Satellite radio	138
Seat belt reminder	114
Shift lock	147
Shock absorbers, Group 76	151
SRS	174, 175
Starting system	80
Starting system, Group 33	80
Steering, Group 64	150
Subwoofer	135, 136
Supplemental Restraint System module (SRS) V70	174
Supplemental Restraint System module (SRS) XC90	175

T

Table of Contents	3
Tail lights V70	87
Tail lights XC90	88
Tailgate harness V70	231
Tailgate harness XC90	232
Tow hitch cable harness, 13-pin	113
Tow hitch cable harness, 4-pin	110
Tow hitch cable harness, 7-pin	112
Transmission, Group 43	142
Turn-by-Turn	124

W

Wiper/Washer Headlights V70	98
Wiper/washer, rear window	100
Wiper/washer, windshield	97
Wiring and fuses, Group 37	108

List of components 1:9

1/1	Battery V70	3/75	Lock unit, right front door, V70
1/1	Battery XC90	3/75	Lock unit, right front door, XC90
2/14	Relay, glow plug unit	3/76	Lock unit, rear left door, V70
2/22	Relay, climate control system	3/77	Lock unit, rear left door XC90
2/32	Main relay, engine management system	3/77	Lock unit, rear right door, V70
2/35	Relay, starter motor	3/78	Lock unit, rear right door XC90
2/64	Relay, auxiliary lights V70	3/78	Lock unit, tailgate V70
2/64	Relay, auxiliary lights XC90	3/80	Lock unit, tailgate XC90
2/90	Relay, windshield wiper, low/high speed	3/80	Switch, central locking, left V70
2/91	Relay, intermittent wiping	3/82	Switch, central locking, left XC90
2/138	Deadlock relay, left rear door V70	3/82	Switch, central locking, right V70
2/138	Deadlock relay, left rear door XC90	3/85	Switch, central locking, right XC90
2/139	Deadlock relay, right rear door V70	3/85	Power window switch, rear left door V70
2/139	Deadlock relay, right rear door XC90	3/86	Power window switch, rear left door XC90
2/182	Relay, high pressure headlight washer motor	3/86	Power window switch, rear right door rear V70
2/191	Relay, remote parking heater start, radio signal	3/91	Power window switch, rear right door XC90
2/192	Relay, electric engine heater V70	3/91	Switch, left heated seat V70
2/192	Relay, electric engine heater XC90	3/92	Switch, left heated seat XC90
2/237	Disconnect relay, rear speaker	3/92	Switch, right heated seat V70
2/238	Relay, audio disconnection	3/93	Switch, right heated seat XC90
3/1	Ignition switch V70	3/94	Belt buckle contact, left seat V70
3/1	Ignition switch XC90	3/94	Belt buckle contact, right seat V70
3/4	Steering Wheel Switch Left (SWSL) V70	3/95	Belt buckle contact, right seat XC90
3/4	Steering Wheel Switch Left (SWSL) XC90	3/95	Spin control switch V70
3/6	Switch, hazard warning flashers	3/111	Spin control switch XC90
3/8	Switch, heated rear window/door mirrors V70	3/111	Light Switch Module (LSM), V70
3/8	Switch, heated rear window/door mirrors XC90	3/112	Light Switch Module (LSM), XC90
3/9	Brake light contact V70	3/112	Climate Control Module (CCM) V70
3/9	Brake light contact XC90	3/117	Climate Control Module (CCM) XC90
3/10	Reversing light contact	3/117	Ceiling light switch unit, V70
3/25	Switch, power sunroof V70	3/126	Ceiling light switch unit, XC90
3/25	Switch, power sunroof XC90	3/126	Driver/Passenger Door Module (DDM)/(PDM), V70
3/26	Switch unit, power driver's seat	3/126	Driver/Passenger Door Module (DDM)/(PDM), XC90
3/27	Switch unit, power passenger seat	3/127	Passenger/Driver Door Module (PDM)/(DDM), V70
3/37	Horn contact V70	3/127	Passenger/Driver Door Module (PDM)/(DDM), XC90
3/37	Horn contact XC90	3/127	Passenger/Driver Door Module (PDM)/(DDM), V70
3/47	Parking brake contact V70	3/131	Steering Wheel Switch Right (SWSR) V70
3/47	Parking brake contact, XC90	3/131	Steering Wheel Switch Right (SWSR) XC90
3/59	Headlight adjustment control V70	3/135	RTI switch
3/59	Headlight adjustment control XC90	3/155	Program selector, automatic transmission V70
3/60	Switch, auxiliary lights V70	3/155	Program selector, automatic transmission XC90
3/60	Switch, auxiliary lights XC90	3/156	Gear Selector Module (GSM) V70
3/62	Hood alarm contact V70	3/156	Gear Selector Module (GSM) XC90
3/62	Hood alarm contact XC90	3/157	Switch, front passenger airbag V70
3/71	Contacts gear selector AW51	3/157	Switch, front passenger airbag XC90
3/71	Contacts gear selector 4T65AWD		
3/73	Power Child Lock (PCL) switch V70		
3/73	Power Child Lock (PCL) switch XC90		
3/74	Lock unit, front left door, V70		
3/74	Lock unit, front left door, XC90		

List of components 2:9

3/171	Switch, retractable door mirrors V70	4/110	Trailer module XC90
3/171	Switch, retractable door mirrors XC90		
3/173	Switch, tailgate private lock V70	5/1	Driver Information Module (DIM) V70
3/173	Switch, tailgate private lock XC90	5/1	Driver Information Module (DIM) XC90
3/174	Switch, reduced alarm V70		
3/174	Switch, reduced alarm XC90	6/1	Windshield wiper motor V70
3/225	Switch unit continuous damping control (CCD)	6/1	Windshield wiper motor XC90
3/254	Steering Wheel Module (SWM)	6/3	Right-hand headlight wiper motor
3/255	Position sensor, driver's seat	6/4	Left-hand headlight wiper motor
3/256	Position sensor, passenger seat	6/15	Sunroof motor, V70
3/267	Switch unit, telematics	6/15	Sunroof motor, XC90
4/7	Combustion Preheater Module (CPM) V70	6/16	Motor driver's seat, backrest angle
4/7	Combustion Preheater Module (CPM) XC90	6/17	Motor driver's seat, up/down front edge
4/9	Supplemental Restraint System module (SRS)	6/18	Motor driver's seat, up/down rear edge
4/16	Brake Control Module (BCM) V70	6/19	Motor driver's seat, fore/aft
4/16	Brake Control Module (BCM) XC90	6/20	Motor passenger seat, fore/aft
4/28	Transmission Control Module (TCM), TF-80SC	6/25	Starter motor V70
4/28	Transmission Control Module (TCM), V70	6/25	Starter motor XC90
4/28	Transmission Control Module (TCM), XC90	6/26	Alternator Control Module (ACM) V70
4/31	Fan control module	6/26	Alternator Control Module (ACM) XC90
4/33	Sun Roof Module (SRM), V70	6/28	Motor, passenger compartment fan
4/33	Sun Roof Module (SRM), XC90	6/29	Motor, electric cooling fan
4/46	Engine Control Module (ECM), V70	6/29	Cooling fan motor, I5D
4/46	Engine Control Module (ECM), XC90	6/31	Feed pump, ejectors
4/46	Engine Control Module (ECM), 8-cyl.	6/32	Rear window wiper motor, V70
4/46	Engine Control Module (ECM), I5D	6/32	Rear window wiper motor XC90
4/50	Electronic Throttle Module (ETM)	6/33	Fuel pump V70
4/52	Power Seat Module (PSM)	6/33	Fuel pump XC90
4/56	Central Electronic Module (CEM), V70	6/35	Fuel pump, auxiliary heater V70
4/56	Central Electronic Module (CEM), XC90	6/35	Fuel pump, auxiliary heater XC90
4/58	Rear Electronic Module (REM), V70	6/37	Lock motor, fuel filler flap V70
4/58	Rear Electronic Module (REM), XC90	6/37	Lock motor, fuel filler flap XC90
4/68	Steering Wheel Angle Sensor Module (SAS)	6/38	Motor, left headlight adjustment
4/70	Upper Electronic Module (UEM), V70	6/39	Motor, right headlight adjustment
4/70	Upper Electronic Module (UEM), XC90	6/44	Cooling fan, electrics box, engine compartment V70
4/71	Cooling fan module V70	6/44	Cooling fan, electrics box, engine compartment XC90
4/71	Cooling fan module XC90		
4/71	Cooling fan module I5D	6/48	Damper Motor Module (DMM), recirculation
4/76	Remote control unit for garage door opener	6/58	Front left power window motor, V70
4/78	Accessory Electronic Module (AEM) V70	6/58	Front left power window motor, XC90
4/78	Accessory Electronic Module (AEM) XC90	6/60	Front right power window motor, V70
4/82	Differential Electronic Module (DEM) V70	6/60	Front right power window motor, XC90
4/82	Differential Electronic Module (DEM) XC90	6/62	Left power door mirror, V70
4/83	Control module fuel pump	6/62	Left power door mirror, XC90
4/83	Fuel pump module, 8-cyl.	6/63	Right power door mirror, V70
4/84	Suspension Module (SUM)	6/63	Right power door mirror, XC90
4/86	Parking Assistance Module (PAM) V70	6/64	Motor passenger seat, backrest angle
4/86	Parking Assistance Module (PAM) XC90	6/65	Motor passenger seat, up/down front edge
4/99	Electronic power steering control module	6/66	Motor passenger seat, up/down rear edge
4/106	Control module, remote parking heater start	6/67	Pump, fuel leakage control, V70
4/107	Control module, parking heater, Call start	6/67	Pump, fuel leakage control XC90
4/109	Glow plug control module	6/69	Damper Motor Module (DMM), ventilation/floor/defroster
4/110	Trailer module V70		

List of components 3:9

6/71	Valve, speed-dependent power steering	7/16	Coolant temperature sensor V70
6/73	Coolant pump, auxiliary heater V70	7/16	Coolant temperature sensor XC90
6/73	Coolant pump, auxiliary heater XC90	7/16	Coolant temperature sensor, 8-cyl.
6/76	Climate control system, rear	7/17	Mass air flow sensor (MAF) V70
6/92	Rear left power window motor V70	7/17	Mass air flow sensor (MAF) XC90
6/92	Rear left power window motor XC90	7/17	Mass air flow sensor (MAF), 8-cyl.
6/93	Rear right power window motor V70	7/23	Rear knock sensor
6/93	Rear right power window motor XC90	7/23	Rear knock sensor, 8-cyl.
6/95	Damper Motor Module (DMM), temperature, left-hand side	7/24	Front knock sensor
6/96	Damper Motor Module (DMM), temperature, right-hand side	7/24	Front knock sensor, 8-cyl.
6/102	Damper Motor Module (DMM), defroster	7/25	Impulse sensor, gasoline & I5D V70
6/103	Damper Motor Module (DMM), floor/ventilation	7/25	Impulse sensor, diesel V70
6/104	High pressure headlight washer motor V70	7/25	Impulse sensor, gasoline & I5D XC90
6/104	High pressure headlight washer motor XC90	7/25	Impulse sensor, diesel XC90
6/105	Fuel distributor, gas	7/25	Impulse sensor, 8-cyl.
6/113	Coolant pump, 8-cyl.	7/25	Sensor ABS, front left
6/114	Vacuum pump	7/25	Sensor ABS, front right
6/118	Regulator motor, swirl throttle	7/25	Oil level sensor
6/120	Throttle body motor V70	7/25	Temperature sensor evaporator
6/120	Throttle body motor XC90	7/25	Accelerator pedal sensor V70
6/120	Throttle body motor 8-cyl.	7/25	Accelerator pedal sensor XC90
6/120	Throttle body motor, I5D	7/25	Sensor ABS, rear left
6/127	Washer motor V70	7/25	Rear right ABS sensor
6/127	Washer motor XC90	7/25	Sensor, input speed AW51
6/143	Regulator motor, turbo	7/25	Sensor, input speed 4T65AWD
7/4	Brake fluid level sensor	7/25	Sensor, input speed TF-80SC
7/5	Washer fluid level sensor V70	7/25	Sensor, output speed AW51
7/5	Washer fluid level sensor XC90	7/25	Sensor, output speed 4T65AWD
7/6	Oil pressure monitor V70	7/25	Sensor, output speed TF-80SC
7/6	Oil pressure monitor XC90	7/25	Coolant level sensor V70
7/8	Pressure sensor, climate control system V70	7/25	Coolant level sensor XC90
7/8	Pressure sensor, climate control system XC90	7/25	Fluid temperature sensor, automatic transmission AW51
7/8	Pressure sensor, climate control system, 8-cyl.	7/25	Sensor oil temperature automatic transmission 4T65AWD
7/10	Interior temperature sensor	7/25	Fluid temperature sensor, automatic transmission, TF-80SC
7/11	Outside temperature sensor V70	7/25	Pressure sensor, intake manifold
7/11	Outside temperature sensor XC90	7/25	Pressure sensor, intake manifold, 8-cyl.
7/12	Solar sensor, twilight sensor and indicator alarm V70	7/25	Heated oxygen sensor, diagnostics 1, 5-cyl.
7/12	Solar sensor, twilight sensor and indicator alarm XC90	7/25	Heated oxygen sensor, diagnostics 1, 6-cyl.
7/15	Heated oxygen sensor, 5-cyl.	7/25	Front heated oxygen sensor, bank 1, 8-cyl.
7/15	Heated oxygen sensor, 6-cyl.	7/25	Acceleration sensor, Four-C, front left
7/15	Front heated oxygen sensor, bank 2, 8-cyl.	7/25	Acceleration sensor, Four-C, front right
7/15	Heated oxygen sensor, I5D	7/25	Acceleration sensor, Four-C, rear left
		7/25	Steering wheel angle sensor V70
		7/25	Steering wheel angle sensor XC90
		7/25	Occupant Weight Sensor (OWS)

List of components 4:9

7/100	Inclination Sensor Module (ISM) V70	7/158	Mass Movement Sensor (MMS), rear
7/100	Inclination Sensor Module (ISM) XC90	7/159	Air Quality Sensor (AQS)
7/103	Heated oxygen sensor 3	7/162	Fuel rail pressure sensor V70
7/103	Rear heated oxygen sensor, bank 2, 8-cyl.	7/162	Fuel rail pressure sensor XC90
7/104	Rear heated oxygen sensor, bank 1, 8-cyl.	7/162	Fuel rail pressure sensor I5D
7/105	Outside temperature sensor, engine control module V70	7/164	Body Sensor Cluster Stability Sensor (BSC)
7/105	Outside temperature sensor, engine control module XC90	7/165	Pressure and temperature sensor, intake manifold
7/108	Side impact sensor, rear left V70	7/166	Oil level sensor, I5D
7/108	Side impact sensor, rear left XC90	7/172	Position sensor camshaft, intake side
7/109	Side impact sensor, rear right V70	7/172	Intake camshaft position sensor, bank 2, 8-cyl.
7/109	Side impact sensor, rear right XC90	7/173	Position sensor camshaft exhaust side Diesel
7/110	Left-hand seat temperature sensor	7/173	Position sensor camshaft exhaust side Gasoline
7/111	Right-hand seat temperature sensor	7/173	Exhaust camshaft position sensor, bank 2, 8-cyl.
7/115	Side impact sensor, front left V70	7/174	Differential pressure sensor, particle filter
7/115	Side impact sensor, front left XC90	7/175	Weight sensor passenger seat, seat belt reminder
7/116	Side impact sensor, front right V70	7/178	Front impact sensor, right
7/116	Side impact sensor, front right XC90	7/179	Front impact sensor, left
7/118	Acceleration sensor, shock absorber, Four-C, front left	7/188	Intake camshaft position sensor, bank 1, 8-cyl.
7/119	Acceleration sensor, shock absorber, Four-C, front right	7/189	Exhaust camshaft position sensor, bank 1, 8-cyl.
7/120	Rear left angle sensor, Four-C/Bi-Xenon V70	7/190	Temperature sensor, exhaust gases upstream of particle filter
7/120	Rear left angle sensor, Four-C/Bi-Xenon XC90	7/191	Temperature sensor, exhaust gases downstream of particle filter
7/121	Rear right angle sensor, Four-C	7/201	Pressure and temperature sensor, gas
7/122	Mass Movement Sensor Module(MMS), front V70	7/204	Front parking assistance sensor 5
7/122	Mass Movement Sensor Module (MMS), front XC90	7/205	Front parking assistance sensor 6
7/123	Clutch pedal sensor V70	7/206	Front parking assistance sensor 7
7/123	Clutch pedal sensor XC90	7/207	Front parking assistance sensor 8
7/124	Brake pedal sensor V70	8/3	Electromagnetic clutch, climate control system V70
7/124	Brake pedal sensor XC90	8/3	Electromagnetic clutch, climate control system XC90
7/129	Brake pressure sensor 2 V70	8/3	Electromagnetic clutch, climate control system, 8-cyl.
7/129	Brake pressure sensor 2 XC90	8/6-10	Injection valves, diesel
7/130	Fuel level sensor, ejector side V70	8/6-11	Injection valves, gasoline
7/130	Fuel level sensor, ejector side XC90	8/17	EGR valve, diesel V70
7/131	Rear parking assistance sensor 1	8/17	EGR valve, diesel XC90
7/132	Rear parking assistance sensor 2	8/18	EVAP valve V70
7/133	Rear parking assistance sensor 3	8/18	EVAP valve XC90
7/134	Rear parking assistance sensor 4	8/18	EVAP valve, 8-cyl.
7/135	Glass breakage sensor, left-hand	8/19	Solenoid, variable valve timing, intake
7/136	Glass breakage sensor, right-hand	8/19	Solenoid, variable valve timing, intake, bank 2, 8-cyl.
7/137	Glass breakage sensor, tailgate	8/20	Shock absorber, Four-C, front left
7/139	Brake pressure sensor 1 V70	8/21	Shock absorber, Four-C, front right
7/139	Brake pressure sensor 1 XC90	8/22	Shock absorber, Four-C, rear left
7/143	Fuel level sensor, pump side V70	8/23	Shock absorber, Four-C, rear right
7/143	Fuel level, pump side XC90	8/28	Turbocharger control valve V70
7/149	Rain Sensor Module (RSM), V70	8/28	Turbocharger control valve XC90
7/149	Rain Sensor Module (RSM), XC90		
7/154	Fuel temperature sensor, I5D		
7/156	Pressure and temperature sensor, Bi-Fuel		
7/156	Pressure and temperature sensor fuel		

List of components 5:9

8/30	Airbag igniter, driver's side	8/78	Oil pressure sensor
8/31	Airbag igniter, passenger side V70	8/81	Solenoid, variable valve timing exhaust V70
8/31	Airbag igniter, passenger side XC90	8/81	Solenoid, variable valve timing exhaust XC90
8/32	Igniter, airbag stage 2, passenger side V70	8/81	Solenoid, variable valve timing, exhaust, bank 2, 8-cyl.
8/32	Igniter, airbag stage 2, passenger side XC90	8/82	Solenoid, variable turbo geometry, diesel V70
8/33	Front left belt tensioner igniter V70	8/82	Solenoid, variable turbo geometry, diesel XC90
8/33	Front left belt tensioner igniter XC90	8/84	Switch, vacuum pump
8/34	Front right belt tensioner igniter V70	8/85	Thermostatic switch and fuel filter heating
8/34	Front right belt tensioner igniter XC90	8/85	V70
8/36	Solenoid shift lock	8/85	Thermostatic switch and fuel filter heating
8/37	Automatic transmission AW51	8/85	XC90
8/37	Automatic transmission 4T65AWD	8/88	Solenoid, fuel tank, Bi-Fuel, rear
8/37	Automatic transmission TF-80SC	8/89	Solenoid, fuel tank, Bi-Fuel, front left
8/38	Shift solenoid 1 AW51	8/90	Solenoid, fuel tank, Bi-Fuel, front right
8/38	Shift solenoid 1 4T65AWD	8/94	Left-hand belt tensioner igniter, third row of seats
8/38	Shift solenoid 1 TF-80SC	8/95	Right-hand belt tensioner igniter, third row of seats
8/39	Shift solenoid 2 AW51	8/96	Left-hand inflatable curtain igniter, third row of seats
8/39	Shift solenoid 2 4T65AWD	8/97	Right-hand inflatable curtain igniter, third row of seats
8/39	Shift solenoid 2 TF-80SC	8/98	Fuel pressure control valve, I5D
8/40	Lock-up solenoid AW51	8/99	Igniter, steering column
8/40	Lock-up solenoid 4T65AWD	8/107	Valve, variable intake, 8-cyl.
8/40	Lock-up solenoid TF-80SC	8/111	Solenoid valve, high-pressure diesel
8/41	Pressure solenoid AW51	8/113	Fuel pressure bypass valve
8/41	Pressure solenoid 4T65AWD	8/117	Solenoid, variable valve timing, intake, bank 1, 8-cyl.
8/46	Activation unit DSTC V70	8/118	Solenoid, variable valve timing, exhaust, bank 1, 8-cyl.
8/46	Activation unit DSTC XC90	8/120	EGR valve
8/51	Side airbag igniter, front left V70	8/123	Igniter airbag driver side stage 3, XC90
8/51	Side airbag igniter, front left XC90	8/124	Igniter passenger side airbag stage 3, XC90
8/52	Side airbag igniter, front right V70	8/134	Solenoid, reverse interlock, manual
8/52	Side airbag igniter, front right XC90	8/142	Linear pressure solenoid SLB1
8/55	Igniter, left rear belt tensioner	8/143	TF-80SC AWD
8/56	Igniter, right rear belt tensioner	8/143	Linear pressure solenoid SLC1
8/61	Igniter, airbag stage 2, driver's side	8/144	TF-80SC AWD
8/62	Belt tensioner igniter, center rear seat V70	8/144	Linear pressure solenoid SLC2
8/62	Belt tensioner igniter, center rear seat XC90	8/145	TF-80SC AWD
8/64	Solenoid valve, engine pad, diesel V70	8/145	Linear pressure solenoid SLC3
8/64	Solenoid valve, engine pad, diesel XC90	8/146-	TF-80SC AWD
8/66	Left inflatable curtain igniter V70	8/153	Injection valves, 8-cyl.
8/66	Left inflatable curtain igniter XC90		
8/67	Right inflatable curtain igniter V70		
8/67	Right inflatable curtain igniter XC90		
8/71	Throttle solenoid AW51		
8/71	Throttle solenoid TF-80SC		
8/72	Shift solenoid 3 AW51		
8/73	Shift solenoid 4 AW51		
8/74	Shift solenoid 5 AW51		
8/75	Valve, fuel cut-off DFCO		

List of components 6:9

9/1	Front 12V outlet V70	10/45	Tail light 2, right V70
9/1	Front 12V outlet XC90	10/46	Fog light, rear right V70
9/2	Heated rear window V70	10/46	Fog light, right rear XC90
9/2	Heated rear window XC90	10/47	Direction indicator, rear right V70
9/12	Seat Heating Module (SHM), left-hand	10/47	Direction indicator, right rear XC90
9/13	Seat Heating Module (SHM), right-hand	10/48	Reversing light, right V70
9/16	Left-hand backrest heating element	10/48	Reversing light, right XC90
9/17	Right-hand backrest heating element	10/50	Brake light, left V70
9/18	Left-hand seat heating element	10/50	Brake light, left XC90
9/19	Right-hand seat heating element	10/51	Tail light 1, left V70
9/25	Rear 12 V outlet V70	10/51	Tail light 1, left XC90
9/25	Rear 12 V outlet XC90	10/52	Tail light 2 left, V70
9/30	Auxiliary heater V70	10/53	Fog light, rear left V70
9/30	Auxiliary heater XC90	10/53	Fog light, rear left XC90
9/32	PTC-resistor air preheating	10/54	Direction indicator, rear left V70
9/33	Left heated exterior rearview mirror	10/54	Direction indicator, rear left XC90
9/34	Right heated exterior rearview mirror	10/55	Reversing light, left V70
		10/55	Reversing light, left XC90
10/1	Left front lamp housing V70	10/64	High beam, right V70
10/1	Left front lamp housing XC90	10/64	High beam, right XC90
10/2	Right front lamp housing V70	10/65	Auxiliary light, front right V70
10/2	Right front lamp housing XC90	10/65	Auxiliary light, front right XC90
10/3	License plate lighting V70	10/66	Low beam, right V70
10/3	License plate lighting XC90	10/66	Low beam, right XC90
10/5	Fog light, front left V70	10/68	High beam, left V70
10/5	Fog light, front left XC90	10/68	High beam, left XC90
10/6	Fog light, front right V70	10/69	Auxiliary light, front left V70
10/6	Fog light, front right XC90	10/69	Auxiliary light, front left XC90
10/11	Running/parking light, front left V70	10/70	Low beam, left V70
10/11	Running/parking light, front left XC90	10/70	Low beam, left XC90
10/12	Running/parking light, front right V70	10/71	Side running light, front left V70
10/12	Running/parking light, front right XC90	10/71	Side running light, front left XC90
10/13	Direction indicator, front left V70	10/72	Front ashtray lighting
10/13	Direction indicator, front left XC90	10/73	Side running light, front right V70
10/14	Direction indicator, front right V70	10/73	Side running light, front right XC90
10/14	Direction indicator, front right XC90	10/114	Vanity mirror lighting, left V70
10/15	Direction indicator, front left fender V70	10/114	Vanity mirror lighting, left XC90
10/15	Direction indicator, left front door XC90	10/115	Vanity mirror lighting, right V70
10/16	Direction indicator right front fender, V70	10/115	Vanity mirror lighting, right XC90
10/16	Direction indicator, right front door, XC90	10/125	Courtesy lighting, front left V70
10/17	Lamp housing, rear right V70	10/125	Courtesy lighting, front left XC90
10/17	Lamp housing, rear right XC90	10/126	Courtesy lighting, front right V70
10/18	Lamp housing, rear left V70	10/126	Courtesy lighting, front right XC90
10/18	Lamp housing, rear left XC90	10/148	Left exterior rearview mirror lighting
10/19	Auxiliary brake light V70	10/149	Door mirror lighting, right
10/19	Auxiliary brake light XC90	10/150	Rear reading light V70
10/25	Ceiling light, cargo compartment	10/150	Rear reading light XC90
10/29	Glove compartment lighting V70	10/150	Rear reading light
10/29	Glove compartment lighting XC90	10/151	Left-hand rear door switch lighting
10/43	Brake light, right V70	10/172	Reading light, third row of seats
10/43	Brake light, right XC90	10/173	Cargo compartment lighting, tailgate
10/44	Tail light 1, right V70	10/218	Indicator light, remote start
10/44	Tail light 1, right XC90		

List of components 7:9

11A	Main fuses in engine compartment fuse box	16/64	Antenna, cellular phone V70
11B	Fuses in engine compartment fuse box	16/64	Antenna, cellular phone XC90
11C	Fuses in the passenger compartment fuse box, V70	16/65	Antenna ring/ignition switch lighting V70
11C	Fuses in the passenger compartment fuse box, XC90	16/65	Antenna ring/ignition switch lighting XC90
11E	Main fuses at the battery V70	16/71	Amplifier antenna, bumper
11E	Main fuses at the battery XC90	16/73	Antenna, bumper
11F	Fuses in cargo compartment auxiliary fuse box	16/74	Window antenna amplifier 1, right
		16/77	Window antenna amplifier 2, left
		16/77	Window antenna amplifier 2, right
		16/77	Microphone, cellular phone V70
		16/77	Microphone, cellular phone XC90
15/31	Distribution box in engine compartment	16/78	Speaker, cellular phone
		16/79	Subwoofer, V70
16/1	Audio Module (AUM)	16/79	Subwoofer Module (SUB), XC90
16/2	Amplifier	16/81	Screen, accessory
16/3	Speaker, front right door V70	16/81A	Screen, LH head restraint
16/3	Speaker, front right door XC90	16/81B	Screen, RH head restraint
16/4	Speaker, front left door V70	16/82	DVD-player
16/4	Speaker, front left door XC90	16/82	DVD-player accessory
16/5	Speaker, rear right door V70	16/93	Control module, cellular phone handsfree, V70
16/5	Speaker, rear right door XC90	16/93	Control module, cellular phone handsfree XC90
16/6	Speaker, rear left door V70	16/94	Infotainment Control Module (ICM)
16/6	Speaker, rear left door XC90	16/105	Audio Module (AUD)
16/10	Horn 1, V70	16/106	CD Player Module (MP2)
16/10	Horn 1 XC90	16/107	MD Player Module (MP1)
16/11	Horn 2	16/108	Multimedia Module (MMM)
16/15	CD changer	16/110	Antenna module (ATM)
16/16	LH window antenna amplifier 1	16/111	Outlet, rear left headphones
16/26	Center dashboard speaker V70	16/112	Outlet, rear right headphones
16/26	Center dashboard speaker XC90	16/122	Rear Audio Separation module (RAS)
16/35	Siren (SCM) V70	16/123	External equipment outlet (AUX)
16/35	Siren (SCM) XC90	16/124	Rear Seat Entertainment module (RSE)
16/36	TV receiver, V70	16/125	IR transmitter
16/45	Road Traffic Information module (RTI)	16/126	Holder, cellular phone handsfree V70
16/45	Traffic information module, Turn-by-Turn	16/126	Holder, cellular phone handsfree XC90
16/46	RTI display, V70	16/127	Microphone, cellular phone handsfree V70
16/46	Multimedia display, XC90	16/127	Microphone, cellular phone handsfree XC90
16/46	RTI display, Turn-by-Turn	16/145	Satellite radio receiver
16/47	GPS antenna, RTI	16/149	MP3 player
16/49	Traffic Message Channel module		
16/50	Left-hand rear window antenna		
16/54	Right-hand rear window antenna		
16/55	Treble speaker, front left door V70	17/13	Data link connector V70
16/55	Treble speaker, front left door XC90	17/13	Data link connector XC90
16/56	Treble speaker, front right door V70	17/17	Jump start connection
16/56	Treble speaker, front right door XC90	17/19	12V outlet, cargo compartment V70
16/57	Speaker, left D-pillar V70	17/19	12V outlet, cargo compartment XC90
16/57	Speaker, left D-pillar XC90	17/37	4-pin outlet, tow hitch cable harness V70
16/58	Speaker, right D-pillar V70	17/37	4-pin outlet, tow hitch cable harness XC90
16/58	Speaker, right D-pillar XC90	17/38	7-pin outlet, tow hitch cable harness, V70
16/59	Antenna, remote control	17/38	7-pin outlet, tow hitch cable harness, XC90
16/60	Phone Module (PHM) V70	17/38	EU/OS
16/60	Phone Module (PHM) XC90	17/38	7-pin outlet, tow hitch cable harness, XC90 USA
16/62	Hand unit, cellular phone V70	17/39	13-pin outlet, tow hitch cable harness V70
16/62	Hand unit, cellular phone XC90	17/39	13-pin outlet, tow hitch cable harness XC90
16/63	GPS antenna, cellular phone		

List of components 8:9

18/4	Contact reel V70	31/70	Ground connection, left-hand side member, lower engine compartment V70
18/4	Contact reel XC90	31/70	Ground connection, left-hand side member, lower engine compartment XC90
20/3-8	Spark plug and Ignition coil	31/72	Ground connection, cargo compartment V70
20/14	Condenser, 8-cyl.	31/72	Ground connection, cargo compartment XC90
20/16	Capacitor	31/73	Ground connection, rear right seat riser V70
20/22-26	Glow plug	31/73	Ground connection, rear right seat riser XC90
20/46-53	Spark plug with ignition coil, 8-cyl.	31/83	Ground connection, A-pillar, left side V70
26/4	Converter, tow hitch cable harness V70	31/83	Ground connection, A-pillar, left side XC90
26/4	Converter, tow hitch cable harness XC90	31/84	Ground connection, A-pillar, right side V70
27/3	Left Camera Module (LCM)	31/84	Ground connection, A-pillar, right side XC90
27/4	Right Camera Module (RCM)	31/88	Ground connection, engine ignition coils, group 1
31/1	Ground connection, right MacPherson strut tower, V70	31/89	Ground connection, engine ignition coils, 8-cyl.
31/1	Ground connection, right MacPherson strut tower, XC90	31/89	Ground connection, engine ignition coils, group 2
31/2	Ground connection, left MacPherson strut tower, V70	31/90	Ground connection, engine ignition coils, 8-cyl.
31/2	Ground connection, left MacPherson strut tower, XC90	31/91	Ground connection, engine
31/4	Ground connection, engine	31/93	Ground connection, left MacPherson strut tower, V70
31/6	Ground connection, A-pillar, left side V70	31/94	Ground connection, left MacPherson strut tower, XC90
31/6	Ground connection, A-pillar, left side XC90	31/94	Ground connection, right MacPherson strut tower, V70
31/10	Ground connection, A-pillar, right side V70	31/94	Ground connection, right MacPherson strut tower, XC90
31/10	Ground connection, A-pillar, right side XC90	31/95	Ground connection, left MacPherson strut tower, V70
31/44	Ground connection, left-hand side member, lower engine compartment V70	31/95	Ground connection, left MacPherson strut tower, XC90
31/44	Ground connection, left-hand side member, lower engine compartment XC90	31/96	Ground connection, right MacPherson strut tower, V70
31/46	Ground connection, rear left seat riser V70	31/96	Ground connection, right MacPherson strut tower, XC90
31/46	Ground connection, rear left seat riser XC90	31/96	Ground connection, right MacPherson strut tower, V70
31/47	Ground connection, rear left seat riser V70	31/98	Ground connection, upper windshield member V70
31/47	Ground connection, rear left seat riser XC90	31/98	Ground connection, upper windshield member XC90
31/48	Ground connection, rear right seat riser V70	31/99	Ground connection, Side window left
31/48	Ground connection, rear right seat riser XC90	31/100	Engine ignition coils, 8-cyl.
31/53	Ground connection, firewall, V70	31/102	Ground connection, front member V70
31/53	Ground connection, firewall XC90	31/102	Ground connection, front member XC90
31/66	Ground connection, front seat riser, left-hand side V70	31/118	Ground connection, between front seats under the armrest
31/66	Ground connection, front seat riser, left-hand side XC90	31/120	Ground connection, cargo compartment V70
31/67	Ground connection, front seat riser, right-hand side V70	31/120	Ground connection, cargo compartment XC90
31/67	Ground connection, front seat riser, right-hand side XC90		

List of components 9:9

53/no.	Branching point	54/40D	Connector
54/1	Connector V70	54/43	Connector
54/1	Connector XC90	54/43B	Connector
54/1B	Connector V70	54/50	Connector V70
54/1B	Connector XC90	54/50	Connector XC90
54/1C	Connector	54/53	Connector
54/3.1	Connector V70	54/54	Connector
54/3.1	Connector XC90	54/55	Connector V70
54/3.2	Connector V70	54/55	Connector XC90
54/3.2	Connector XC90	54/56	Connector V70
54/4	Connector	54/56	Connector XC90
54/7	Connector	54/57.1	Connector V70
54/8	Connector V70	54/57.1	Connector XC90
54/8	Connector XC90	54/66.1	Connector
54/9	Connector V70	54/66.2	Connector
54/9	Connector XC90	54/74	Connector
54/10	Connector V70	54/74B	Connector
54/10	Connector XC90	54/98	Connector
54/11	Connector V70	54/100	Connector
54/11	Connector XC90	54/106	Connector
54/12	Connector V70	54/107	Connector
54/12	Connector XC90	54/109	Connector
54/13	Connector V70	54/112	Connector
54/13	Connector XC90	54/113	Connector
54/14	Connector	54/117	Connector
54/16	Connector	54/122	Connector
54/20	Connector	54/132	Connector V70
54/21	Connector	54/132	Connector XC90
54/22	Connector V70	54/274	Connector
54/22	Connector XC90	54/275	Connector
54/23	Connector V70	54/303	Connector
54/23	Connector XC90	54/1300	Connector V70
54/24	Connector	54/1300	Connector XC90
54/25	Connector	54/1400	Connector V70
54/32	Connector	54/1400	Connector XC90
54/34	Connector	4X/78	Connector interface, original car
54/35	Connector	9X/25	Connector interface, original car
54/36	Connector V70	16X/1	Connector interface, original car
54/36	Connector XC90	16X/26	Connector interface, original car
54/39	Connector	16X/45	Connector interface, original car
54/40B	Connector	16X/57	Connector interface, original car
54/40C	Connector	16X/58	Connector interface, original car
		16X/105	Connector interface, original car
		54X/no.	Connector interface, original car
		A1	Connecting rail to 15/31

TP 3989202 (US English). Printed in Gothenburg, Sweden 08-2005